

MOTOROLA

AUTO RADIO

MODEL


556

TYPE - Universal automotive type superheterodyne receiver designed for underdash mounting. Receiver may be mounted in-dash with an AK-111A trim plate. This model contains an internal speaker.

TUNING RANGE - 540 to 1600 Kc


IF - 455 Kc

ALIGNMENT



Connect an output meter across the speaker voice coil. Set tone control to high and volume to maximum. Attenuate generator output to maintain 1.79 volts on output meter at all times to prevent overloading the receiver.

STEP	GENERATOR CONNECTION	GENERATOR FREQUENCY (400 cycle mod)	TUNER SET TO	ADJUST	REMARKS
IF ALIGNMENT					
1.	6BE6 grid (pin 7) through .1 mf capacitor & chassis	455 Kc	Hi end stop	1, 2, 3 & 4	Peak for maximum
RF ALIGNMENT					
2.	Ant recept through dummy (see Fig.)	1610 Kc	Hi end stop	5, 6 & 7	Peak for maximum
NOTE:	Do not perform steps 3, 4, 5 & 6 unless tuner has been tampered with or components have been replaced. Remove escutcheon to expose core screws. Before proceeding with step 3, back tuning cores 1" out of coils to eliminate their effect on trimmer adjustments.				
3.	Ant recept through dummy (see Fig.)	1610 Kc	Hi end stop	5, 6 & 7	Peak for maximum
4.	"	1180 Kc	19/64" from hi end stop	8, 9 & 10	Peak for maximum using alignment tool, Motorola Part No. 66A76278
5.	"	1610 Kc	Hi end stop	5, 6 & 7	Peak for maximum
6.	Repeat steps 4 and 5 until no further increase, then cement tuning cores in place.				
ANTENNA TRIMMER					
7.	-	Weak station around 1400 Kc	7		With radio installed in car and antenna fully extended, peak antenna trimmer for maximum.




NOTES -
CAPACITORS - DECIMAL VALUES IN MF. ALL OTHERS IN
MICRO UNLESS OTHERWISE SPECIFIED

VOLTAGES - MEASURED FROM POINT INDICATED TO CHASSIS
WITH A 175V NO SIGNAL INPUT ± 10%

INPUT VOLTAGE AT SWITCH T.V.


TUNING RANGE - 535 TO 1605 Kc

IF - 455KC



MOTOROLA INC.

Model 556



TO SET PUSHBUTTONS

This receiver has an automatic tuner, with 5 "Quick Set" pushbuttons for automatic station selection.

To set the pushbuttons for automatic tuning, proceed as follows:

1. Tune in the desired station with the manual tuning knob.

Tune carefully until you are exactly on the station.

2. Pull out the first pushbutton to be set, to unlock the button for station set-up, and then push button in firmly to set and lock the button.

3. Follow the above procedure for the remaining four buttons.