

Setting Push-Buttons on Models: -- 39-25 39-30 39-31 39-35 39-40 39-45

Circuits	Frequency Range
1 and 2	540 to 1030 kilocycles
3 and 4	670 to 1160 kilocycles
5 and 6	900 to 1470 kilocycles
7 and 8	1170 to 1600 kilocycles

- (C) Turn the receiver Tuning Range Selector to position two ("Manual Tuning") and tune the receiver to the station to be set on the first button.
- (D) Plug the output leads of the Station Setter into the "High" and "Gnd" jacks, and turn the output controls to maximum. Turn the modulation control to "Modulation Off." Connect the output lead of the Station Setter to the "ANT" and "GND" terminals of the receiver and tune to the frequency of the station being received. As the indicator is slowly tuned through the frequency of the station there will be two points at which a high pitched swish will be heard, one above and one below the frequency of the station. When the indicator is on the frequency of the station, minimum high pitched swish will be heard.
- (E) Set the modulation control of the Station Setter for "Modulation On." The modulated signal of the Station Setter will then be heard through the receiver.
- (F) Turn the receiver Tuning Range Selector to position one (Automatic Tuning) and push in the first button. Using the Part No. 45-2610 Insulated Screw Driver, turn the number 1 "OSC" screw until the modulated signal of the Station Setter is tuned in to maximum volume. Then adjust the number 1 "ANT" screw for maximum signal.
- (G) Remove the output lead of the Philco Station Setter from the "ANT" terminal of the receiver and turn its indicator off the frequency of the station. The program of the desired station will then be heard on the receiver.
- (H) With the volume of the receiver low, slowly turn the number 1 "OSC" back and forth until maximum output is received. Repeat the same procedure for the number 1 "ANT" screw.

After setting up the first station, the same procedure given under (C) to (H) is used for the other stations.