



Bottom View-Perma Circuit Panel Component Layout-Model ST984 INTERMEDIATE FREQUENCY: AM, 455 KHz

FM ALIGNMENT

FM, 10.7 MHz

SIGNAL GENERATOR			RADIO		
STEP	CONNECTION TO RADIO	DIAL	DIAL SETTING	SPECIAL INSTRUCTIONS	ADJUST
1	COLLECTOR OF Q1 THRU 01 MF CAPACITOR	10.7 MHZ ±75 KHZ SWEEP	TUNING GANG FULLY OPEN	ADJUST FOR MAXIMUM OUTPUT IN ORDER GIVEN. REDUCE GENERATOR OUTPUT AS NECESS.	T9A, T7, T5 &
2	SAME AS STEP 1	10.7 MHZ 30% AM	TUNING GANG FULLY OPEN	ADJUST FOR MINIMUM OUTPUT (A NULL BETWEEN TWO PEAKS)	Т9В
3	REPEAT STEPS 1 AND 2 UNTIL NO FURTHER IMPROVEMENT IS OBTAINED.				
4	CONNECT TO ANTENNA TERMINAL THRU 47 OHM RESISTOR	87.5 MHZ ±75 KHZ	TUNING GANG FULLY CLOSED	ADJUST FOR MAX, OUTPUT.	T3 (SEE NOTE
5	SAME AS STEP 4	108.5 MHZ ±75 KHZ	TUNING GANG FULLY OPEN	ADJUST FOR MAX. OUTPUT.	VCTB FC osc.
6	REPEAT STEPS 4 AND 5 UNTIL NO FURTHER IMPROVEMENT IS OBTAINED.				
7	SAME AS STEP 4	90 MHZ ±75 KHZ	90 MHZ	ADJUST FOR MAX OUTPUT.	Т2
8	SAME AS STEP 4	105 MHZ ±75 KHZ	105 MHZ	ADJUST FOR MAX. OUTPUT.	VCTA
9	REPEAT STEPS 7 AND 8 UNTIL NO FURTHER IMPROVEMENT IS OBTAINED.				