




RCA VICTOR

2-C-511 SERIES


Chassis No. RC1118



K = 1000
 ALL CAPACITANCE VALUES LESS THAN 1.0
 ARE IN MF., ABOVE 1.0 ARE IN MMF.
 EXCEPT AS INDICATED.

Step	Connect the high side of test-oscillator to—	Tune test-osc. to—	Turn radio dial to—	Adjust the following for max output
1	6B16 I-F grid through .01 mid. capacitor	455 kc	Quiet-point 1600 kc end of dial	T2 (top and bottom) 2nd I-F trans.
2	Stator of C1-A through .01 mid.	1620 kc	Min. cap.	T1 (top and bottom) 1st I-F trans.
3	Short wire placed near loop to radiate signal	1400 kc	1400 kc signal	osc. trimmer C1A-T
4		600 kc	600 kc (rock)	osc. coil L3
5		Repeat steps 3, 4, and 5		
6				

ALIGNMENT TABULATION



TUBE SERVICE—Disassembly—To make tubes accessible for testing, remove the volume and tuning control knobs by pulling off. Unscrew counterclockwise the alarm and time knobs from their shafts. Invert the cabinet and remove only the two cross-head screws along the back underside of the cabinet. Place the cabinet in its normal position. Using only firm hand pressure, press down alternately at front right and left sides of the cabinet top, midway between the "ON-OFF-AUTO" slide switch lever and the cabinet sides, forcing down and backward to disengage the molded-in plastic catches. Then lift off the cabinet rear cover.

TUNING

