


000

PHONO INPUT


4-C-541 SERIES


Chassis No. RC-1145

The material on this page and on the page adjacent at right, is exact for Models 4C541, 4C542, 4C543, 4C544, 4C545, 4C547, Chassis RC-1145. Models 4C531, 4C532, 4C533, 4C534, 4C535, Chassis RC-1144 are similar electrically to RC-1145, but omit radio-phono switch S2 and outlet J2. Models 4X551, 4X552, 4X553, 4X554, 4X555, Chassis RC-1146, and Models 5X560, 5X562, 5X564, Chassis RC-1150, are also similar electrically to Chassis RC-1145 described on these two pages, but omit clock mechanism.



Test-Oscillator—For all alignment operations, connect the low side of the test-oscillator to the receiver chassis, and keep the oscillator output as low as possible to avoid a-v-c








Diagram of Drive Cord with Condenser Rotor Closed (Extreme Counter-clockwise Position)

Tube and Trimmer Locations

