TRUETONE

MODEL D-2634

ALIGNMENT—Sets are properly aligned at the factory with precision equipment and the adjustments should not be disturbed unless a coil, tuning condenser or IF transformer has to be replaced or the set has been subject to damage or tampering. Alignment should only be done with the oid of an accurate signal generator and output indicating instrument.

TO PROPERLY ALIGN—Remove chassis from cabinet, and align I. F. Transformers in the conventional manner with a Signal Generator adjusted to 455 KC, connected to the grid of the 6SA7 through a .1 Mfd. condenser, with the tuning condenser set at minimum capacity. To align tuning condenser, carefully place loop in normal relation to chassis, connect Signal Generator to antenna clip through a .0001 Mfd. condenser. Adjust oscillator trimmer condenser (located on left top) to 1620 KC with tuning condenser at minimum capacity (complete out of mesh). The antenna ond R. F. sections are trimmed at 1400 KC. Antenna trimmer is top right; R. F. trimmer is below at right. Dial pointer may be adjusted to scale by slipping pointer coupling on dial cord.

