*These voltage readings will be either lower or practically zero if taken with a 1000 ohms-per-volt meter.

DIAL CORD STRINGING

To string the dial cord, close the tuning gang. Start stringing at the tension spring and run the dial cord in the direction indicated by the arrow. See illustration below. Draw the dial cord tight to apply tension on the spring and prevent slipping at the tuning shaft.

VOLTAGE DATA

Voltages shown on schematic diagram.

All voltages taken between tube socket terminals and B minus (pin 7 of 1U5 tube).

Dial set at low frequency end; volume control at minimum.

IF=455 KC
COMMON GROUND (B-)
CHASSIS GROUND

TUBE AND TRIMMER LOCATION

Adjustments A and C are made from underside of chassis.

Admiral

CHASSIS 4Y1
MODELS 4Y11, 4Y12, 4Y18, 4Y19