Emerson Radio

MODEL – 875-B
CHASSIS – 120365B

TYPE OF TUBES:

- V-1 – 12BE6, converter
- V-2 – 12BA6, i-f amplifier
- V-3 – 12AT6, detector, a.v.c. a-f
- V-4 – 50C5, power output
- V-5 – 35W4, rectifier

DISASSEMBLY INFORMATION

1. Remove all knobs, remove three screws mounting masonite back, remove back, remove 45 r.p.m. spindle holder.
2. Loosen four screws securing changer mounting board to cabinet. Tilt changer mounting board up and back while disconnecting two 3-prong plugs.
3. Remove two screws securing chassis mounting board to cabinet, unclip pilot light. Chassis may be moved back. To remove chassis completely from cabinet, speaker leads must be unsoldered.
4. To reassemble, reverse procedure #1 through #3.