

[illegible]






Figure 2. View of Chassis.



With the gang condenser fully closed, place the pointer slide nearest the volume control as shown in the figure above. The three punched holes indicate tracking points.

VOLTAGE DATA

Voltages shown on schematic diagram.

All readings made between tube socket terminals and B minus.

Dial turned to low frequency end; volume control at minimum.

Measured on 117 Volts AC line.

Voltages measured with vacuum-tube voltmeter.

The chassis of this receiver is connected directly to one side of the power line. To avoid possibility of damage to test equipment or to printed circuit wiring, do not place the chassis directly on a metal service bench, tools or other metal objects.