

Precautionary Lead Dress .--

- Dress the power cable to switch on the volume control close to the chassis and away from all grid and diode leads and condensers.
- 2. Dress capacitors in the 12SQ7 grid circuit away from all wiring.
- Green and black phono wires should be twisted and dressed away from other parts and leads.
- 4. 50L6-GT filament wires should be dressed to rear of chassis and away from the second I-F transformer leads.
- Dress brown lead from second I-F transformer to 12SQ7 away from power cable.
- Dress wire to No. 1 grid of the 12SA7 away from pilot lamp leads.
- 7. Dress wire from loop to variable condenser away from chassis.
- Dress all capacitors, leads, etc. which come close to oscillator coil rigidly and as far as possible from it.