


(Continued on the next page)



Bottom of PC board showing location of top components in solid outlines. Tube pin numbering is for bottom of socket.

WESTINGHOUSE Chassis V-2510-7 and V-2511-5, Models H-M1310B, H-M1311B, H-M1312B, H-M1313B, H-M1410, H-M1411, H-M1412, H-M1413.

(Continued from the preceding page)

