

JBL Driver / Repair Kit Goes Into List

<u>Driver Number</u>	<u>Repair Kit</u>	<u>Goes Into Model</u>					
010	***	J216					
011	***	J220	J320	J325	J350		
012	***	J216A	J220A	J320A	J325A	J350A	
020Nd	***	HT1D	HT1F				
022Ti	***	JBL 62T	JBL82T	JBL630T	JBL830T	JBL940T	
024	D4R024	LT-1					
026Ti	***	HP420 S118	HP520	LX22	LX44	LX55	S116
027Ti	***	LX300 LXE770	LX440 LXE990	LX500	LX600	LXE330	LXE550
029Ti	***	S3	S4				
033	D8R033	L40	L40A	L110	L110A	L150	
034	D8R034	L15	L46	L56	L86		
035Ti	D8R035Ti	L20T	L60T	L80T	L100T		
035TiA	D8R035TiA	L1 L80T3	L3 L100T3	L5	L7	L20T3	L40T3
035TiA-1	D8R035TiA	250TiBQ					
044	D8R044	L96	L112	L150A	L150A-B		
044-1	D8R044-1	L250					
044Ti	D8R044Ti	18Ti	120Ti	240Ti	250Ti		
046Ti-1	D8R046Ti	S1M	XPL90A	XPL140A	XPL160A	XPL200A	
046Ti-1S	D8R046Ti	S2M	S3M				
066	D8R066	L166	L166A	L212	L212C		
075	D8R075	D4400WX	D4400WXA	S38	S508	S608	
076	D8R076	L220	L220A	L222	L222A		
077	D16R2405	L55A	L65	L65A	L65B	L300	L300A
093Ti	D4R093Ti	XPL140A	XPL160A	XPL200A			
10-601-S	***	M5	J50				
12C70DU-01CW	***	Pro III	Pro III Plus				
16K70DU-01DW	***	Pro VIII					
58P60DH-01CD	***	ProIII	Pro III Plus				
58P60DH-01HD	***	Pro VIII					
104H	C8R104	120Ti	240Ti	250Ti	250TiBQ		
104H-2	C8R104-2	L80T	L80T3	L100T	L100T3		
108H	C8R108	250Ti	250TiBQ	L250			
112A	C8R112A	L212					
112H	C8R112A	L212C					
115H	C8R115	L15					
115H-1	C8R115H-1	18Ti	L20T	L20T3	XPL90A	XPL200A	
116A	C8R116A	L16	L19				
116H	C8R116A	L19A					
116H-1	C8R116H-1	L60T					
116H-2	C8R116H-2	L40T3					
116H-3	C8R116A	XPL140A					
117H-1	C8R117	L46	L86				
118H	C8R118	L56					
120T3	C8R120T3	L200T3					
121A	C8R121A	L212					
121H	C8R121A	L212C					
122A	C8R129H	L65A	L166				

JBL Driver / Repair Kit Goes Into List

<u>Driver Number</u>	<u>Repair Kit</u>	<u>Goes Into Model</u>					
122A-1	C8R129H	L166A					
123A-1	C8R2212	L55A	L88	L88-1	L88A	L88P	L88P-A
		L100	L100A	S70			
123A-2	C8R2212	S106					
123A-3	C8R2213	L100ALM					
125A	C8R127A	L25	L26	L26A	L36	L36A	L120
		L120A					
126A	C8R126A	L65					
127A	C8R127A	L40	L50				
127H	C8R127A	L40A	L50A				
127H-1	C8R127H-1	L80T	L80T3	XPL160A			
128H	C8R128H	L112	L150	L150A	L150A-B		
128H-1	C8R128H-1	120Ti					
129H	C8R129H	L65B					
130A	C8R2220	L45	S36				
135A	C8R2235	L45A	L45B	L71	L71A		
136A	C8R2235	L200B	L300				
136H	C8R2235	L300A					
136HS	C8R136	S2S					
150-4C	16R1504	D30085					
150-4H	C8RE145	DD55000					
203G	***	G50	G100	P10			
205H	***	LC310-1	LC312-1	G300	G500	P30	P40
		P50					
206H	***	G200	P20				
208H	***	G300	G500	P30	P50	T88	
210H	***	P40					
276nd	D8R2425	S1C-S	S2C	S2M			
303G	C4R303G-2	502VX	702VX	902VX			
303G-1	C4R303G-2	502VXA					
303G-2	C4R303G-2	702VXA	902VXA				
304GS	***	Pro Perf.	Pro Perf. Plus				
305G	C4R305G-1	702VX	702VXA	902VX	902VXA	905VX	
305G-1	C4R305G-1	R103	R123	R133			
305G-2	C4R305G-2	J320	J325	J350			
305G-3	***	J320A	J325A	J350A			
305G-3A	***	JBL52TQX	S3				
305G-3A-1	***	HT1D	J2045	J2050	JBL2500	S2A	S115
305G-3A-1S	***	HT1F	SC305				
305G-4	***	JBL940	JBL940T				
306G-2	C4R306G-2	J216					
306G-3	***	J216A					
306G-4	***	JBL62	JBL630				
306G-4A	***	JBL62T	JBL630T				
308G	C4R308G-1	502VX	502VXA				
308G-1	C4R308G-1	R82					
308G-2	C4R308G-2	J220	J320				
308G-3	***	J220A	J320A				
308G-4	***	JBL82	JBL82T	JBL830	JBL830T	JBL940	JBL940T
308-HS	***	S2	S119				

*** Repair kit not available.
Defective driver should be replaced.

JBL Driver / Repair Kit Goes Into List

<u>Driver Number</u>	<u>Repair Kit</u>	<u>Goes Into Model</u>				
308SW	***	Pro Perf. Plu	Pro III Plus	S1		
310G	C4R310G-1	702VX	702VXA	905VX		
310G-1	C4R310G-1	R103	R133			
310G-2	C4R310G-2	J325	J325A	J350		
310G-3	***	J350A				
310G-4	***	JBL940	JBL940T			
312G	C4R312G-1	902VX	902VXA			
312G-1	C4R312G-1	R123				
375	D16R2440	D30085	D44000WX	S508	S608	
376	D16R2441	D44000WXA				
405G	***	HP420	HP520	LX44	LX55	S118
405G-1	***	LX500	LX600			
405G-2	***	LXE770	LXE990			
406G	***	HP520	LX22	S116		
406G-1	***	LX300				
406G-2	***	LXE330				
408G	***	LX44	S118			
408G-1	***	LX440	LX500			
408G-2	***	LXE550	LXE770			
410G	***	LX55				
410G-1	***	LX600				
410G-2	***	LXE990				
505G	***	G400	J5120	JBL3800	JBL4800	
506G	***	HP420	J2060	JBL2600		
506G-1	***	S4				
508G	***	HP520	J2080	JBL2800	JBL3800	
510G	***	G400	JBL4800			
512G	***	J5120				
512GS	***	HT1S				
704G	***	L5	L7			
705GS	***	S1M	S2M			
706G-1	***	L1	L5			
706G-1S	***	S3HC	S3VC			
708G-1	***	L3	L5	L7		
726GS	***	S2C	S2M			
2118H-2	C8R2118	S1C-2S				
2118J-2	C16R2118	S1A	S1C	S1M		
2118JS	C16R2118	S1C-S				
2213H	C8R2213	4312				
2214H	C8R2214	L100T				
2214H-1	C8R2214	L100T3	XPL200A			
2235H	C8R2235	B380				
2245H	C8R2245	B460	S1S			
2405H	D16R2405	DD55000				
2416H	D8R2416-1	L200T3	S1A EARLY	S1C EARLY	S1C-2S EAR	S1M EARLY
2416H-1	D8R2416-1	S1A	S1C	S1C-2S	S1M	
2425H	D8R2425	DD55000				
69455	***	S2	S119			
70391	***	JBL52TQX				
70740	***	JBL2500	JBL2600	JBL2800	JBL3800	JBL4800 S115

*** Repair kit not available.

Defective driver should be replaced.

June 1995

Page 3

JBL Driver / Repair Kit Goes Into List

<u>Driver Number</u>	<u>Repair Kit</u>	<u>Goes Into Model</u>					
72273	***	M5	J50				
72274	***	T88					
72773	***	FLIX					
73715-02	***	S3M					
73959	***	G50	G100	G400	P10		
74447	***	J2045	J2050	J2060	J2080	J5120	SC305
74860	***	Center	Sat 2				
75017	***	LC310-1	LC312-1				
75017-01	***	LC312-1					
75019	***	LC310-1					
75020	***	LC312-1					
75133	***	Sat 2					
75133-01	***	Sat 1					
75245	***	S2A					
76316	***	S3HC	S3M	S3VC			
302343-001	***	MR25	MR26	MR Center	J Center		
302354-001	***	MR28	MR38	MRV308	MRV310		
305062-001	***	J520M	J620M				
306572-001	***	J820M	J830M	J900MV	J1000MV		
CT-249-S	***	FLIX					
CT-350	***	FLIX					
D130	C8RE130	S38					
D280	C8R2110	L57					
LE5-2	C8RLE52	L88P S106	L88P-A	L100	L100A	L100ALM	S70
LE5-3	C8RLE59	L71	L71A	S105			
LE5-5	C8RLE59	L45A	L45B	L55A	L65	L65A	L65B
LE5-6	C8RLE510	L36	L36A	L120	L120A		
LE5-8	C8RLE510	L166	L166A				
LE5-9	C8RLE59	L212	L212C	L220	L220A	L222	L222A
LE5-10	C8RLE510	L50	L50A	L110	L110A	L150	
LE5-11	C8RLE59	L250					
LE5-12	C8RLE510	4312	L86	L96	L112	L150A	L150A-B
LE8	C8RLE8T	L33					
LE85	D16R2421	L200 S61K	L200A S61P	L200B S72	L300 S507	L300A S607	S51
LE8T	C8RLE8T	L44	L54	L59	L75	L80	
LE8T-2	C8R2115	S109					
LE10	C8RLE10A	L66					
LE10A	C8RLE10A	L77	Minigon	S105			
LE10H-1	8RLE10H-	L96					
LE14A	C8RLE14A	L55 SC99	L101	L220	L222	S56	S99
LE14H	C8RLE14A	L220A	L222A				
LE14H-1	8RLE14H-	240Ti	250Ti	250TiBQ	L250		
LE15A	C16R2215	D44000WX S508	S51 S607	S61K S608	S61P	S72	S507
LE15B	C8RLE15B	L200	L200A				
LE15H	C8RLE15H	D44000WXA					

*** Repair kit not available.

Defective driver should be replaced.

June 1995

Page 4

JBL Driver / Repair Kit Goes Into List

Driver Number	Repair Kit	Goes Into Model					
LE20-1	D8RLE20	L55 S56 SC99	L66 S70	L77 S99	L88 S105	L88-1 S106	L100 S109
LE25	D8RLE25	L25 L88P	L45A L88P-A	L45B L100A	L71 L100ALM	L71A	L88A
LE25-2	D8RLE252	L16 R133	L26	L36	R82	R103	R123
LE25-3	D8RLE252	L120					
LE25-4	D8RLE254	L26A	L36A				
LE25-5	D8RLE254	L120A					
LE26	D8RLE26	L19	L19A	L50	L50A		
LE30	***	Minigon					
LE85	D16R2421	L200 S61K	L200A S61P	L200B S72	L300 S507	L300A S607	S51
LE111A	C8RLE111	L110					
LE111H	C8RLE111	L110A					
LE120H-1	8RLE120-	L7					
LE120H-1S	8RLE120-	S3S					
LE175	D16R2410	L45	L101	S36			
LT-1	RLT-1, D4R0	LT-1					
P205G	***	MR25	J520M				
P206G	***	MR26	J620M				
P206H	***	MR38	J830M				
P206HS	***	MRV308	MRV310	J900MV	J1000MV		
P208G	***	MR28	J820M				
P208H	***	MR38	J830M				
P208HS	***	MRV308	J900MV				
P210HS	***	MRV310	J1000MV				
PR8	CRPR8	L44	L54	L57	L59	L75	L80
PR10	CRPR10	L77					
PR12	<i>OBSOLETE</i>	S70					
PR15	CRPR15C	S507	S508	S607	S608		
PR15C	CRPR15C	L220	L222	L222A			
PR15D	CRPR15C	L220A					
PR300	CRPR300	L150	L150A	L150A-B			
PR310	***	905VX					
PR310-1	***	R133					
PR310-2	***	J350					
PR310-3	***	J350A					
S8C200-104	***	GT-M80					
S10C290-48	***	GT-M100					
SE3.5G	***	Sat 1					
SE3.5HB	***	MR Center	J Center				
SE5H	***	Bass 1	Basswave				
SE5HS	***	Bass 1	Basswave				
TLX-1	***	JBL62	JBL82				
TLX-2	***	JBL630	JBL830	JBL940			
TWO25XE	***	G200 P50	G300	G500	P20	P30	P40
WPS100	***	PS100					

*** Repair kit not available.
Defective driver should be replaced.

June 1995

JBL Driver / Repair Kit Goes Into List

<u>Driver Number</u>	<u>Repair Kit</u>	<u>Goes Into Model</u>
WPS120	***	PS120
WPS60	***	PS60

*** Repair kit not available.
Defective driver should be replaced.