



NOTES:
 CAPACITORS: Unless otherwise specified decimal values in MF; all others in MMF.
 VOLTAGES: Measured from point indicated to B- with a VTVM, $\pm 10\%$. No signal in.
 ∇ = B- \perp = CHASSIS --- = RECORD CHANGER FRAME

CHASSIS REMOVAL

1. From bottom of cabinet, disconnect all leads and cables connected to chassis (on SK100-4, remove bottom panel first).
2. From inside record changer compartment, remove 3 control knobs and loosen large hex nuts located under knobs; then grasp the chassis from bottom and loosen nuts completely.
3. Remove chassis from cabinet.

