





RCA VICTOR

Models VFP 09E, T, VFP 11A, B, G, use Chassis RP-219-39
 Models VFP 19E, T, VFP 21A, T, VFP 32E, G, use RP-219-49
 Models VFP 43A, VFP 49E, use Chassis RP-219-42
 Models VFP 58A, VFP 60E, use Chassis RP-219A-12



RP-219-42, -49



RP-219A-12
Wiring Side

