





**CHASSIS 5W3**  
**MODELS 5W32 • 5W33 • 5W34 • 5W38**  
**5W39 • 5B42 • 5B43 • 5B48**



ALL READINGS TAKEN WITH A VACUUM TUBE VOLTMETER.

COMMON GND,  
IF=455 KC

- Set volume control full on.
- Connect output meter across speaker voice coil.

\*Adjustments "C" and "E" made from underside of chassis

