

slug tuned instead of trimmer capacitor tuned. The power line antenna is used when there is no external dipole and is utilized by attaching the blue wire on the cabinet back to the top dipole terminal. This should be disconnected when a dipole is used. For best reception with a power line antenna, the power cord should not be coiled up.

## TUNING BAND:

FM	 	88-108 mc

## INTERMEDIATE FREQUENCY:

FM	*****************	10.7 mc

## GENERAL ELECTRIC

**RADIO** 

SERVICE DATA FOR MODELS 356, 357 AND 358



Model 356-Mahogany Piastic Model 357—Ivory Plastic