



GENERAL ELECTRIC

MODELS 431A, 432A, 431B, 432B, 433B AND 431BH



The 431 and 432 are identical to the 431A and 431B respectively, except as noted in the schematic in regard to S1 and S2. A B+ switch was added to the volume control and the former

The 431B, 432B and 433B chassis are identical. These models also employ the same arrangement of combination Radio-Phono volume control and B+ switch, and Tone control with power On-Off switch, as is used on the Models 431A and 432A. Tone control circuit components, however, were changed as shown in the schematic diagram for the 431B, 432B and 433B receivers. In addition, the ceramic couplate, C12A, B, C, D, used on the other receivers, was replaced by separate capacitors.



GENERAL ELECTRIC

MODEL 442, 443 and 444

