



MODELS
475
476
477




ALIGNMENT NOTE KEEP SIGNAL
INPUT LOW AND VOLUME CONTROL
AT MAX SO A.V.C. WILL NOT AFFECT
OUTPUT.


Schematic Diagram



Tube and Trimmer Location



Bullplate



Dial Cording