


MODELS
Red & Tweed
Two Tone Blue



Capacitors - decimal values in MF all others in MMF unless otherwise specified.
 Voltages - measured from point indicated to B— with a VTVM.

PARTS LOCATIONS

To Remove Chassis from Cabinet

1. Pull off two knobs from front of cabinet.
2. Remove screws which mount baffle and remove baffle.
3. Remove four screws from corners of phono mounting board.
4. Remove mounting board from cabinet.
5. Remove two screws which hold chassis to mounting board and remove chassis.

MODEL
37F1 Gray & Pink
37F2 Green & Black

CHASSIS
HS-541

