



MOTOROLA



NOTES
CAPACITORS - Decimal values in MF; all others in MMF unless otherwise specified.
VOLTAGES - Measured from point indicated to ground with a VTVM. No signal input, vol at max.
TUNING RANGE - 530 to 1620 KC.
IF - 455 KC.
Resistances measured with transistor out of associated circuit



ALIGNMENT

Connect generator output across 5" diameter, 5 turn loop and couple inductively to receiver loop. Keep radiation loop at least 12" from receiver antenna. Connect a low range output meter across the speaker voice coil and set volume control to maximum. Attenuate generator output to maintain .05 watts on output meter to prevent overloading the receiver.

MODELS
7611 Charcoal
7612 Brown
CHASSIS
HS-507

