



TRIGGER TUBE VOLTAGES
V1-NORMAL OPERATION, RELAY AT OPEN
V2-WHEN SEARCHING, RELAY AT CLOSED

TO SET PUSHBUTTONS

Stations may be set up in any order. However, for convenience in remembering, it is suggested that stations be set up in frequency sequence.

1. Turn receiver on and allow to operate for fifteen minutes. Antenna should be fully extended.
2. Unlock pushbuttons by pulling them to the left and out.
3. Accurately tune in a station with the manual tuning.
4. Lock one pushbutton to that station by pushing in firmly.
5. Repeat above procedure for remaining pushbuttons.

