



BEFORE STARTING STRINGING, ROTATE GANG SHAFT & PULLEY FULLY COUNTERCLOCKWISE; THEY SHOULD BE IN POSITION AS SHOWN.

BEFORE INSTALLING DIAL SCALE, REMOVE MTG SCREW BUT HOLD ONTO PULLEY.

MODEL XP3C DIAL STRINGING DETAIL




PARTS LOCATION

MOTOROLA


MODEL XP3C

CHASSIS HS-66202




MOTOROLA

MODEL XP3C
CHASSIS HS-66202



TOP VIEW MODEL XP3C PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM COMPONENT SIDE OF BOARD)



BOTTOM VIEW MODEL XP3C PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)