


FM-R301



S₁
BAND
SELECTOR
1. HI-F
2. SOFT
3. SW.
4. F.M.
5. A.F.C.

S₂
INPUT
SELECTOR
1. RADIO
2. PHONO
3. AUX.

S₃ RUMBLE FILTER

S. A. C.

