



SW/MW/FM STEREO RECEIVER

KX-333

UNIT \ ROUND LABEL	FSAW					
TUNER UNIT	AWE-006					
FM FRONT END						
FM IF UNIT						
MPX UNIT						
AM UNIT	AWA-001					
MUTING UNIT						
AF UNIT	W36-007					
CONTROL AMP UNIT						
MAIN AMP UNIT						
POWER SUPPLY UNIT						
SWITCH UNIT						
SWITCH UNIT						
SWITCH UNIT						
TONE COLOR UNIT						
CONTROL UNIT						
MIC AMP UNIT						
REVERBE AMP UNIT						
REVERBE UNIT						





SWITCHES

- S₁ INPUT SELECTOR**
1. SW₁
 2. SW₂
 3. FM MONO
 4. FM AUTO
 5. PHONO
 6. AUX / TAPE PB

- S₂ POWER SWITCH**
1. OFF
 2. ON

- S₃ LINE VOLTAGE SELECTOR**

RESISTORS

- NON MARK : OHM
K : KILOHM
M : MEGOHM

CAPACITORS

- NON MARK : μF
P : μμF

→ DC CURRENT AT NO INPUT SIGNAL

V DC VOLTAGE AT NO INPUT SIGNAL

(V) DC VOLTAGE AT MAXIMUM OUTPUT

□ SIGNAL VOLTAGE AT 8 W / 8 Ω 1 KHZ


8 V / 8 Ω

AWE-006

AM UNIT

AM UNIT

AWA-001



AF UNIT

AF UNIT

W36-007

