



# Model LX-300T



# AM TUNER UNIT W14-009

AM TUNER UNIT


W14 - 009




# FM FRONTEND W11-019

FM FRONT END

W11-019




## W12-021



## MPX UNIT W13-020

MPX UNIT


W 13 - 020



# SWITCHING UNIT W13-017

SWITCHING UNIT

W13-017



① IN

③  $-10.5V$

② GND


④ OUT

# COIL UNIT W18-009


COIL UNIT

W18-009

Q<sub>90</sub> 25A102



## W15-001






# CONTROL AMP UNIT

## W15-013

CONTROL AMP UNIT


W15-013



MAIN AMP UNIT W15-014

MAIN AMP UNIT

W15-014



POWER SUPPLY UNIT  
W16-002

