




# LW/MW/FM STEREO RECEIVER

## LX-440


| UNIT              | ROUND LABEL |  |  |  |  |  |
|-------------------|-------------|--|--|--|--|--|
|                   | FVW         |  |  |  |  |  |
| TUNER UNIT        | W35-009     |  |  |  |  |  |
| FM FRONT END      |             |  |  |  |  |  |
| FM IF UNIT        |             |  |  |  |  |  |
| MPX UNIT          |             |  |  |  |  |  |
| AM UNIT           | W14-014     |  |  |  |  |  |
| MUTING UNIT       |             |  |  |  |  |  |
| AUDIO UNIT        | W15-073     |  |  |  |  |  |
| CONTROL AMP UNIT  |             |  |  |  |  |  |
| MAIN AMP UNIT     |             |  |  |  |  |  |
| POWER SUPPLY UNIT | W16-021     |  |  |  |  |  |
| SWITCH UNIT       |             |  |  |  |  |  |
| SWITCH UNIT       |             |  |  |  |  |  |
| SWITCH UNIT       |             |  |  |  |  |  |
| TONE COLOR UNIT   |             |  |  |  |  |  |
| CONTROL UNIT      |             |  |  |  |  |  |
| MIC AMP UNIT      |             |  |  |  |  |  |
| REVERBE AMP UNIT  |             |  |  |  |  |  |
| REVERBE UNIT      |             |  |  |  |  |  |
|                   |             |  |  |  |  |  |
|                   |             |  |  |  |  |  |








W14-014



W15-073



# POWER SUPPLY UNIT

POWER SUPPLY UNIT

W16 - 021

