


QUADRALIZER AMPLIFIER

QL-600

UNIT	ROUND LABEL	FW					
FM FRONT END							
FM IF UNIT							
MPX UNIT							
AM TUNER UNIT							
Q UNIT		AWM-001					
HEAD AMP UNIT							
CONTROL AMP UNIT		AWG-009					
MAIN AMP UNIT		AWH-005					
POWER SUPPLY UNIT							
METER AMP UNIT		AWM-012					
SWITCH UNIT							
OUT PUT UNIT		AWM-009					
TONE COLOR UNIT							
CONTROL UNIT							
MIC AMP UNIT							
REVERBE AMP UNIT							
REVERBE UNIT							





S₁ MODE
 1. 2 CH. STEREO
 2. 4 CH. STEREO
 3. MATRIX
 4. PHASE SHIFT

S₂ 4 CH. TAPE MONITOR
 OFF-ON
 S₃ 2 CH. TAPE MONITOR
 OFF-ON

S₄ POWER SWITCH
 ON-OFF


: SIGNAL VOLTAGE AT 13W/8Ω OUTPUT
 : DC VOLTAGE AT NO INPUT SIGNAL
 : DC CURRENT AT NO INPUT SIGNAL
 : DC VOLTAGE AT MAX INPUT SIGNAL

RESISTORS
 NON MARK : OHM K : KILOHM
 M : MEGOHM
 CAPACITORS
 NON MARK : μF
 P : μμF


(SPEAKERS)
 REAR
 (L CH.) (R CH.)
 CH.2 CH.4

OUTPUT UNIT
 AWM-009
 10.2V/8Ω
 13W


Q UNIT



CONTROL AMP UNIT




OUTPUT UNIT



METER AMP UNIT

METER AMP UNIT

AWM-012



MAIN AMP UNIT

MAIN AMP UNIT

AWH-005

