




QT-6100



- S1 FWD-REV SELECTOR SW (FWD POSITION)
S2, S3 REC.-PB. SELECTOR SW (PB. POSITION)
S4 EQUALIZER SELECTOR SW.
S5 (7 1/2 IPS POSITION)
S6 MODE SW. (4 CHANNEL POSITION)
S7 MUTING SW. (PLAY POSITION)
S8 CONTACT OFF SW. (PLAY / STOP POSITION)
S9 PRE SET SW.
S10 PLUNGER SW. (FWD POSITION)
S11 MOTOR SW.
S12 SHUT OFF SW.
S13 POWER SW.
S14 OSC. SW.
- RL1 FWD-REV SELECTOR SW (FWD POSITION)
- VR1, 101 PB. EQUALIZER ADJ (FWD POSITION)
VR2 PB. EQUALIZER ADJ (REV POSITION)
VR3, 103 PB. LEVEL ADJ (FWD POSITION)
VR4 PB. LEVEL ADJ (REV POSITION)
VR5 REC. LEVEL
VR6, 106 REC. LEVEL ADJ
VR7 REC. LEVEL ADJ
VR8 LEFT BIAS ADJ
VR9 RIGHT BIAS ADJ
VR10 OSC INTENSITY ADJ

FRONT
REAR