


QUADRAPHONIC RECEIVER

QX-9900


FW

27


Protection ass'y AWM-028





Logic ass'y AWM-032




Control amp ass'y AWG-013




CR ass'y AWW-037 AM, FM ass'y AWE-015




Level control ass'y AWW-034




Protection ass'y AWM-029




Reverb amp ass'y AWM-036




Power supply ass'y AWR-024




SP switch ass'y A AWS-041




Balance volume ass'y AWW-035




Decoder ass'y AWM-031




Main amp ass'y AWH-015




Mini switch ass'y AWS-025




SP switch ass'y B AWS-042




Level meter switch ass'y AWS-028




Head amp ass'y W21-002




Tone control ass'y AWG-014




MIC amp ass'y W21-003







QX-9900 2




AM/FM ass'y AWE015




Protection ass'y AWM-029




Power supply ass'y AWR-024




Head amp ass'y W21-002




SP switch ass'y B AWS-042




Protection ass'y AWM-028




Decoder circuit ass'y AWM-031




Mini switch ass'y AWS-025




Mic amp ass'y W21-003




SP switch ass'y A AWS-041




Main amp ass'y AWH-015




Level control ass'y AWX-034




Balance volume ass'y AWX-035




Tone control ass'y AWG-014




Reverb amp ass'y AWM-036




Control amp ass'y AWG-013




CR ass'y AWX-037



Logic ass'y AWM-032



Level meter switch ass'y AWS-028



Headphone ass'y AWX-036

