




STEREO TAPE DECK

RT-71


F

32


Power supply ass'y RWR-019



REC switch ass'y W18-442




OSC ass'y W37-402



S13 FWD-REV SELECTOR SW.

REC/PB amp ass'y W15-422



NOTES:

SEMICONDUCTORS

Q1~Q3 2SC458 LG B or C
Q4~Q6 2SC458 C or D
D1 1N34A

SWITCHES

S1 FWD-REV SELECTOR SW.
S2 REC-P.B. SELECTOR SW.

