



# CONSOLE STEREO SYSTEM

## S-550

| UNIT \ ROUND LABEL | N       |  |  |  |  |  |
|--------------------|---------|--|--|--|--|--|
| TUNER UNIT         | W35-028 |  |  |  |  |  |
| FM FRONT END       |         |  |  |  |  |  |
| FM IF UNIT         |         |  |  |  |  |  |
| AF UNIT            | AWK-005 |  |  |  |  |  |
| AM TUNER UNIT      |         |  |  |  |  |  |
| MUTING UNIT        |         |  |  |  |  |  |
| HEAD AMP UNIT      |         |  |  |  |  |  |
| CONTROL AMP UNIT   |         |  |  |  |  |  |
| MIC UNIT           | AWM-006 |  |  |  |  |  |
| POWER SUPPLY UNIT  |         |  |  |  |  |  |
| DEMISWITCH UNIT    | W26-012 |  |  |  |  |  |
| SWITCH UNIT        |         |  |  |  |  |  |
| SWITCH UNIT        |         |  |  |  |  |  |
| TONE COLOR UNIT    |         |  |  |  |  |  |
| CONTROL UNIT       |         |  |  |  |  |  |
| MIC AMP UNIT       |         |  |  |  |  |  |
| REVERBE AMP UNIT   |         |  |  |  |  |  |
| REVERBE UNIT       |         |  |  |  |  |  |
|                    |         |  |  |  |  |  |
|                    |         |  |  |  |  |  |










## MIC UNIT

MIC UNIT


AWM-006



## DEMI-SWITCH UNIT


DEMI SWITCH UNIT

W 26 - 012



## SPEAKER SYSTEM

S - 550/N · CS



# TURNTABLE UNIT

S-550/N · PL

