


AM/FM STEREO RECEIVER


SX-1500TD

UNIT \ ROUND LABEL	FVZW	FW	KLW			
TUNER UNIT						
FM FRONT END	AWB-001	W11-028	W11-028			
FM IF UNIT	W12-032	W12-032	W12-032			
MPX UNIT	W13-026	W13-026	W13-026			
AM TUNER UNIT	W14-008	W14-008	W14-008			
MUTING UNIT	W18-026	W18-026	W18-026			
HEAD AMP UNIT	W21-001	W21-001	W21-001			
CONTROL AMP UNIT	W15-079	W15-079	W15-079			
MAIN AMP UNIT	W23-002	W23-002	W23-002			
POWER SUPPLY UNIT	W16-026	W16-026	W16-026			
SWITCH UNIT	W15-081	W15-081	W15-081			
SWITCH UNIT	W15-082	W15-082	W15-082			
SWITCH UNIT						
TONE COLOR UNIT						
CONTROL UNIT	W15-080	W15-080	W15-080			
MIC AMP UNIT	W15-106	W15-106	W15-106			
REVERBE AMP UNIT						
REVERBE UNIT						
INDICATOR UNIT	W18-012	W18-012	W18-012			






SX-1500TD for KLV model




SX-1500TD for FW model



FM FRONT END

FM FRONT END


AWB-001




FM FRONT END for FW KLV model

FM FRONT END


W11-028



FM IF UNIT




MPX UNIT



AM TUNER UNIT

AM TUNER UNIT


W14-008



MUTING UNIT

MUTING UNIT


W18-026



HEAD AMP UNIT

HEAD AMP UNIT


W21-001



CONTROL AMP UNIT

CONTROL AMP UNIT


W15-079



POWER SUPPLY UNIT

POWER SUPPLY UNIT


W16-026



MAIN AMP UNIT

MAIN AMP UNIT


W23-002



PUSH SWITCH UNIT

PUSH SWITCH UNIT


W15-081



PUSH SWITCH UNIT

PUSH SWITCH UNIT


W15-082




CONTROL UNIT

CONTROL UNIT

W15-080



W 18 - 012



W15-106

