



Model **SX-1500TD** / FW



AM TUNER UNIT W14-008

AM TUNER UNIT

W14-008




W11-028


FM IF UNIT W12-025

FM IF UNIT

W12-025




IC Q₁ ~ Q₄



MUTING UNIT W18-026

MUTING UNIT


W18 - 026



INDICATOR UNIT W18-012

INDICATOR UNIT


W18 - 012



FM MPX UNIT W13-024

FM MPX UNIT


W13 - 024



HEAD AMP UNIT W21-001

HEAD AMPL UNIT


W21-001



PUSH SWITCH UNIT W15-081

PUSH SWITCH UNIT

W15 - 081




CONTROL AMP UNIT

W15-079

CONTROL AMPL UNIT


W15 - 079



CONTROL UNIT W15-080

CONTROL UNIT


W 15 - 080



PUSH SWITCH UNIT W15-082

PUSH SWITCH UNIT


W15 - 082



MIC AMP UNIT W15-106

MIC AMPL UNIT


W15-106



MAIN AMP UNIT W23-002


MAIN AMPL UNIT

W23-002



POWER SUPPLY UNIT

W16-026



POWER SUPPLY UNIT

W16-026