


AM/FM STEREO RECEIVER

SX-2500

ROUND LABEL UNIT	FVW	FVZW				
FM FRONT END	W11-041	W11-041				
FM IF UNIT	W12-034	W12-034				
MPX UNIT	W13-026	W13-026				
AM TUNER UNIT	W14-016	W14-016				
MUTING UNIT	W15-101	W15-101				
HEAD AMP UNIT	W21-002	W21-002				
CONTROL AMP UNIT	W15-050	W15-050				
MAIN AMP UNIT	W23-004	W23-004				
POWER SUPPLY UNIT	W16-027	W16-027				
SWITCH UNIT	W26-004	W26-004				
SWITCH UNIT	W26-005	W26-005				
SWITCH UNIT	W26-006	W26-006				
SWITCH UNIT	W26-007	W26-007				
CONTROL UNIT						
AUTO TUNING UNIT	W18-015	W18-015				
PROTECTOR UNIT	AWM-004	AWM-004				
REVERBE UNIT						
INDICATOR UNIT	W18-016	W18-016				






FM FRONT END

FM FRONT END



W11-041



FM IF UNIT

FM IF UNIT


W12-034



MPX UNIT

MPX UNIT


W13-026




AM TUNER UNIT

AM TUNER UNIT


W14-016




MUTING UNIT




HEAD AMP UNIT



CONTROL AMP UNIT




POWER SUPPLY UNIT



MAIN AMP UNIT

MAIN AMP UNIT

W23-004



TH₁ ~ TH₂ THERMISTOR D22A


SEMICONDUCTORS

Q₁, Q₂ 2SC458 LG
 Q₃, Q₄ 2SC627-10r2
 Q₅, Q₆ 2SC984-CorB
 Q₇, Q₈ 2SC484-YorBL
 Q₉, Q₁₀ 2SA484-YorBL
 Q₁₁ ~ Q₁₄ 2SC1079
 D₁, D₂ SIB01-005
 D₃ ~ D₄ VB-11

SWITCH UNIT

SWITCH UNIT


W26-004



SWITCH UNIT



SWITCH UNIT

W26-005




SWITCH UNIT

SWITCH UNIT




AUTO TUNING UNIT



PROTECTOR UNIT

PROTECTOR UNIT

AWM-004



INDICATOR UNIT

INDICATOR UNIT

W18-016

