



Model SX-300T (New type)



AM TUNER UNIT W14-003

AM TUNER UNIT


W14 - 003



FM FRONTEND W11-019

FM FRONT END


W11-019



FM IF UNIT W12-013

FM IF UNIT


W12-013



MPX UNIT W13-020

MPX UNIT


W13-020



SWITCHING UNIT W13-017

SWITCHING UNIT

W13-017



① IN

② GND


③ -10.5V

④ OUT

PRE AMP UNIT W15-001

PRE AMP UNIT


W15-001



CONTROL AMP UNIT W15-013

CONTROL AMP UNIT

W15-013



POWER SUPPLY UNIT
W16-002

