



Model SX-51 OT



FM FRONTEND WII-030

FM FRONT END



W 11-030



FM IF UNIT W12-019

FM IF UNIT


W12-019



AM FRONTEND W18-007

AM FRONT END


W18-007



AM IF UNIT W14-007

AM IF UNIT


W14-007



MPX UNIT W13-024

MPX UNIT

W13-024




POWER SUPPLY UNIT

W16-011

POWER SUPPLY UNIT


W16-011



HEAD AMP UNIT W15-032

HEAD AMP UNIT


W15-032



CONTROL AMP UNIT W15-033

CONTROL AMP UNIT

W15-033



MAIN AMP UNIT W15-034

MAIN AMP UNIT

W15-034

