




RCA VICTOR

7-EY-2JJ and 7-EY-2HH

Chassis No. RS-155A
Record Changer RP-190D-2



RCA VICTOR

Portable Automatic Record Player

MODEL 6-ES-5

Chassis No. RS-157
Record Changer RP-198-5A

CRITICAL LEAD DRESS

1. Dress all leads away from R_5 and R_7 .
2. Dress R_3 down next to chassis.
3. Dress all A.C. leads away from audio input circuit.
4. Dress power cord and other leads away from moving parts of record changer.

