





RCA Victor T-2 Series, Chassis RC-1189A.
T-1 Series, Chassis RC-1189, and PT-1
Series, Chassis RC-1189B, are practi-
cally the same.



Chassis Wiring and Components — View from Wiring Side

Damage can result from trying to pull or pry the tuning knob off from the front. To remove—remove the three chassis mounting screws, grasp the tuning capacitor and pull it out of the knob.



Chassis Layout — View from Component Side