





CHASSIS: 1-602-9
MODELS: 2302



CHASSIS-REMOVAL

Disconnect power cord from AC outlet.

Remove clock control, tuning and volume knobs.

Remove (3) chassis bolts underneath cabinet.

Slide chassis, clock and backcover from cabinet.

SCHEMATIC DIAGRAM—SYLVANIA RADIO CHASSIS NO. 1-602-9

SCHEMATIC NOTES

1. Volt gnd measured to negative B using Sylvania only meter. Line voltage 117 V AC and signal input kept to minimum.
2. Coil resistances are average values and are taken with component connected in circuit.
3. Voltages or resistance readings are not shown where too small or widely variable.
4. Intermediate frequency 455 KC.
5. Combined values of X and Y equals 100 Maf.