

TABELLA DELLE TENSIONI APPLICATE

Valvola	V _K	V _{g1}	V _{g2}	V _{g3-5}	V _{g4}	V _A
6K7 G	4		80	4		250
6A8 G	—	-3	160	80	—	250
6K7 G	—		80	—		250
6Q7 G	2	—				80
6V6 G	12		250			230
EM1	2			25		250
5Y3 G	330					

SCHEMA CON VALORI B. F.

