


6A7


6D6

75


6V6



WATT RADIO . MOD. «SABAUDIO II »



POSIZIONI COMMUTATORE	C O N T A T T I																			
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
I CORTISS	●	●	○	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●
II CORTE	●	○	○	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●
III MEDIE	○	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●
IV LUNGHE	○	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
V FONO	○	○	○	○	○	○	○	○	○	○	○	○	○	●	○	○	○	○	○	○



WATT RADIO. — Mod. « Sabaudo 110 » e « Augusto ». — Media frequenza: 485 kHz.