


Socket voltages are shown on the schematic diagram at the tube socket terminals. All voltages are between the socket terminal and chassis ground. Plate, screen and cathode voltages were taken with a 1000 ohm-per-volt meter with a 300 volt scale used for plate and screen voltages. Audio grid voltages were read with a vacuum tube volt-meter. Conditions of measurement are:

Line voltage ......117 Volts AC Signal Input ......None A Variation of ±10% is usually permissible.



MODEL D2027A Factory Model 227A96-906 FM AND BROADCAST RADIO