



DIAL DRIVE MECHANISM




- NOTE—
1. VOICE COIL DISCONNECTED.
 2. ALL VOLTAGES MEASURED FROM CHASSIS (GND.) USING 20,000 OHMS/VOLT METER. READINGS SHOULD APPROXIMATE THE VALUES SHOWN WITHIN 20 PERCENT.
 3. NOT USED ON ALL CHASSIS.

INTERMEDIATE FREQUENCY: 455KC

Westinghouse
RADIO • TELEVISION

MODEL H-133



WESTINGHOUSE - MOD. « H 133 »