



Westinghouse CHASSIS V-2164-2

Models H-400P4, H-401P4, H-402P4, H-403P4.



Connect Signal Generator to —	Signal Generator Frequency	Radio Dial	Adjust for Maximum Output —
Stator of R-F tuning capacitor (A) through a 0.1 mfd	455 kc.	minimum capacity	Top and bottom slugs in 2nd and 1st I-F trans. in order given
Same as step 1	1625 kc.	minimum capacity	Osc. trimmer (D)
Radiated Signal	1400 kc.	1400 kc.	Ant. trimmer (C)



CHASSIS LAYOUT