## **Emerson Radio**

## MODELS: DQ-333 and DQ-334 | MODELS: DQ1-333 and DQ1-334

L1 T4 T2 T3 R1 R3 R4	Loop antenna Oscillator coil I.F. transformers 20,000 ohm $\frac{1}{4}$ w. 140 ohm $\frac{1}{2}$ watt 3 megohm $\frac{1}{4}$ watt
R5 R2 R6	.5 megohm V.C.
	15 megohm $\frac{1}{4}$ w.
R7 R8	.5 megohm $\frac{1}{4}$ w.
R9	200,000 ohm ½ w.
C10	0.1 mfd. 200 v.
C14	0.05 mfd. 400 v.
C4 C15	0.0002 mfd. mica
C3 C16	0.002 mfd. 600 v.
020-21	Dual 20 mfd. 150
C22	0.2 mfd. 200 v.
C24	0.02 mfd. 400 v.
C25	0.01 mfd. 400 v.

## Location of Coils and Trimmer Adjustments

The first i-f transformer is mounted on top of the chassis deck to the right of the variable condenser. The trimmers are accessible through holes in the top of the can.

The second i-f transformer is mounted on top of the chassis between the variable condenser and the speaker. The trimmers are accessible through holes in the top of the can.

The trimmers for the antenna and oscillator coils are located on the variable condenser. The trimmer on the front section is for the oscillator coil.

The oscillator coil is located underneath the chassis. The loop antenna acts as the antenna coil.

An oscillator with frequencies of 455 and 1400 kc is required.

