




MODEL 4SJ4A1










MODEL 4SJ3A1 TOY RADIO-PHONOGRAPH SOCKET VOLTAGE DATA

128A7		128Q7		50L6GT		35Z5G/T	
Pin		Pin		Pin		Pin	
ì	Gnd	1	Gnd	1	0	1	
2	24VAC	2	0	2	24VAC	2	80VAC
3	95 V	3	Gnd	3	115V	3	90VAC
4	95V	4	0	4	95V	4	
5	6%V	5	0	5	0	5	110VAC
6	0	6	35V	6		6	
7	12VAC	7	0	7	75VAC	7	110VAC
8	0	8	12VAC	8	5V	8	120V



ALIGNMENT INSTRUCTIONS

- Turn S1 to Radio and volume to maximum. Connect an output meter across the speaker voice coil. Connect
 generator ground to B- through a .1 mfd. condensor, and the high side to pin 8 of the 12SA7 tube through .03
 mfd. Tune generator to 445 kc. and tune T1 trimmers for maximum output reading.
- 2. Remove generator connection to pin 8, unsolder antenna and attach generator to L1 through 25 mmfd. Turn tuning condenser of set fully open. Set generator to 1620 kc. Tune oscillator trimmer on tuning gang for maximum reading; set R.F. trimmer for maximum output reading. Use only enough generator output to get a reading on the output meter.