




KENWOOD® DC-20X/P/S

STEREO DECK AMPLI-TUNER/ STEREO POWER AMPLIFIER/SPEAKER

DC-20X




* Refer to Parts List on page 58.

STEREO DECK AMPLI-TUNER/Stereo Power Amplifier/Speaker


DISASSEMBLY FOR REPAIR

1. Removal of Plastic Cabinet


① Remove 3 screws.




② Push down on the right and left locking claws and pull out an AC power pack (AD-12).




③ Remove 6 screws.



④ Remove the screws.



⑤ Remove 4 screws.




⑥ The plastic cabinet can be removed.



When checking the circuit, cut 5 leads (black and red leads for power supply, brown and red leads for battery back-up and blue lead for FM rod antenna). Then connect the $\oplus$ terminal to the red lead and the $\ominus$ terminal to the blank lead, respectively.


2. Removal of Front Panel

① Remove 2 screws.




DISASSEMBLY FOR REPAIR

- ② Remove 2 screws.




3. Removal of Control PCB (X13-3280-10)

- ① Remove 7 screws.




The control PCB can be removed.

- ③ Remove 3 screws.




4. Moving of Rear Panel


- ① Remove 2 screws.



- ④ Remove 3 screws.



- ② The rear panel can be moved.




The front panel can be removed by pulling out the connectors as shown in the next photograph.


DISASSEMBLY FOR REPAIR

5. Removal of DISPLAY, SYNTH. and LOGIC PCBs


- ① Remove 4 screws.



- ② Pull out DISPLAY and SYNTH. PCBs toward you.




- ③ Remove 3 screws as shown in the above figure and the loudspeaker. Then turn LOGIC PCB as shown.




6. Removal of Cassette Deck Mechanism


- ① Remove 6 screws.



- ② Remove the loudspeaker.



- ③ Remove the top plate.




When checking the cassette deck mechanism, cut the wire bands and pull out the mechanism toward you.


DISASSEMBLY FOR REPAIR

7. Removal of Audio Amp and MPX Section


- ① Remove 4 screws (2 screws for each side) and loosen 2 screws (1 screw for each side).



- ② Move the audio amp and MPX section as shown.




- ③ Another view




8. Removal of Main Amp and Tone Amp PCBs.


- ① Remove 3 screws and 2 knobs and 3 holders.



- ② Remove the tone amp PCB.




- ③ The main amp PCB can be removed as shown.




DISASSEMBLY FOR REPAIR

Head base removal




- ① Remove the pinch roller.
- ② Remove the pinch roller spring.
- ③ Remove stopper (B).
- ④ Remove the head base stopper plate.
- ⑤ Remove the stopper spring.
- ⑥ Remove the head base.


Note: Ensure that relative positioning of the head base projection and play lever (2) is correct when installing the head base.



Relative positioning of levers



Belt routing



CHECKING PROCEDURES

Procedures for Checking the Display Section

- a) Fluorescent Display Tubes
All applicable display tube segments should light when "H" (+5V) is applied to the various segment inputs (connector 32) and the various digit inputs.
- b) Tuned LED, Stereo LED, Signal LED
Light when all input terminals (connector 33) are set to "L" (0V).
- c) DOLBY LED
Lights when the DOLBY input terminal (connector 8) is set to "L" (0V).
- d) DPSS LED, POSITION LED
All LEDs should light when +5V is applied to all input terminals (connectors 6, 7, and 8) via a few kilohms resistor.

Procedures for Checking the Logic Board (X05-2060-10) (D/7)

Remove the display board and the SYNTH board from the main unit. The logic board can then be checked from the back by removing the screws holding the logic board and removing the shield board.

Procedures for Checking the Synthesizer Section

- 1 Remove the DISPLAY board (X05-2060-10) (C/7) and the SYNTH board (X05-2060-10) (B/7) from the main unit.
- 2 Remove the SYNTH board from the molded display section, remove the shield case, then reattach the board to the molded display section.

Connect connectors 37b (B—, GND) and 33 (SYNTH B, GND) to check operation. It is not necessary to connect connector 35 (for back up power supply). Further, connectors 31 and 32 do not need to be connected for SYNTH operation, since they are used for the fluorescent display.

CASSETTE DECK MECHANISM OPERATION

Principle of Operation

Power from the motor selectively moves the FF lever and the REW lever, causing the head base and reel disk to operate according to the combinations in which the levers are raised or lowered.

Operation of both levers is accomplished by driving their corresponding solenoids.

1 Head base operation

All operation stops when both levers are lowered. In order to move from this state to one of the constant speed states (PLAY or REC), the two solenoids are activated simultaneously to raise the two levers. This cause the head base to move to the constant speed position. When the head base is to be returned from this state to the STOP position, the two solenoids are activated momentarily so that both levers are lowered together.

2 Take-up reel operation (FF)

The take-up reel rotates when only the FF lever is raised. To return from this state to the STOP position, the FF solenoid is driven so that the FF lever is lowered.

3 Supply reel operation

The supply reel rotates when only the REW lever is raised. To return from this state to the STOP position, the REW solenoid is driven so that the REW lever is lowered.

4 Movement to the sensor position

When the constant speed state is entered by raising the FF and REW levers simultaneously, after which one of the two levers is lowered, the head base drops to the sensor position and the reel disk rotates in either the fast forward or the rewind direction.

Basic Operations


Six types of basic operations can be performed according to the principles of operation described in paragraph 1.

1 STOP


The STOP state is entered and no operations take place when both the FF and REW levers are lowered.

2 PLAY

In this state, both the FF and REW levers are raised and the head base is in the constant speed position.




- ① When the PLAY key is pressed, the microprocessor momentarily activates the FF and REW solenoids.
- ② Stoppers (A) are pulled.
- ③ The cam gears rotate in the direction indicated by the arrow.



- ④ The projections on the cam gears raise the FF and REW levers.
- ⑤ The cam assembly is raised.
- ⑥ Play lever (3) is raised.


Also, the SW operational plate turns on the FF and REW switches, providing information to the microprocessor.

CASSETTE DECK MECHANISM OPERATION




3 FF

This state is entered when the FF lever is raised while in the STOP state, causing the take-up reel to rotate at high speed.



CASSETTE DECK MECHANISM OPERATION




4 REWIND


This state is entered when the REW lever is raised while in the STOP state, causing the supply reel to rotate at high speed. REWIND operation is the same as FF operation, except that the parts involved are different.

5 CUE


This state is entered when the REW lever is lowered while in the PLAY state, causing the take-up reel to rotate at high speed. At this time, the head base is lowered far enough for the pinch roller to break contact with the capstan (but the head remains in light contact with the tape).



CASSETTE DECK MECHANISM OPERATION



- ④ The REW lever drops.
- ⑤ The REW switch section of the SW operational plate is pressed, turning it OFF.
- ⑥ The right side of the cam assembly is lowered.
- ⑦ ⑧ The FF/REW lever assembly moves in the direction indicated by the arrow.
- ⑨ The FF/REW link rotates in the direction indicated by the arrow.
- ⑩ The FF/REW gear assembly moves to the right.
- ⑪ ⑫ The take-up side of the reel disk assembly meshes with the FF/REW gear assembly and the reel disk assembly rotates.




- ⑥ ⑦ Lowering the right side of the cam assembly causes play lever (3) to drop, but not all the way to the FF/REW position. Since the projection on the FF/REW lever assembly supports play lever (3), the head base is lowered slightly from its PLAY mode position.
- ⑬ The lever assembly rises slightly.
- ⑭ Play lever (2) drops slightly.
- ⑮ Since the head base drops slightly, the pinch roller drops slightly also.

CASSETTE DECK MECHANISM OPERATION

Brake Plate Operation

As was indicated in the explanation of CUE operation, the brake release lever drops and the brake plate is raised when the FF/REW link rotates. In other words, reel disk rotation becomes possible. (The same applies to CUE, FF, REWIND, and REVIEW.)




6 REVIEW

This state is entered when the FF lever is lowered while in the PLAY state, causing the supply reel to rotate at high speed. At this time, the head base is lowered far enough for the pinch roller to break contact with the capstan (but the head remains in light contact with the tape). REVIEW operation is the same as CUE operation, except that the parts involved are different.


Control Method (Relationship between cam gear operation time and repeat inhibit time)

Since all operations are coupled to rotation of the cam gear, another operation cannot be initiated while the cam gear is rotating.

1 Cam gear operation time



Cam gear sequence diagram



Cam gear operation time

One cam gear operation is completed each time the drive pin moves from A to B (or from C to D) as shown in the cam gear sequence diagram.

CASSETTE DECK MECHANISM OPERATION

SOLENOID SEQUENCE

Top level..... REW solenoid


Middle level..... FF solenoid

Bottom level..... Motor


↑ KEY ON points are indicated by arrows.

MODE AFTER SWITCHING CURRENT MODE	STOP	PLAY	FF	REWIND	CUE	REW	REC	STOP PAUSE	PLAY PAUSE	REC PLAY PAUSE	REC PAUSE	DETECT BLANK
STOP												
PLAY												
FF												
REWIND												
CUE												
REVIEW												
REC												
STOP PAUSE												
PLAY PAUSE												
REC PLAY PAUSE												
REC PAUSE												

BLOCK DIAGRAM



BLOCK DIAGRAM



CIRCUIT DESCRIPTION

I. FREQUENCY SYNTHESIZER

The block diagram of a frequency synthesized tuner is shown in Fig. 1. The local oscillator frequency is locked to the reference frequency (which is usually generated with a crystal controlled oscillator) by means of the phase locked loop (PLL).





Fig. 1 Frequency synthesizer (fixed frequency divider type)

Frequency comparison is performed by the PLL as follows.



The blocks shown in Fig. 1 are explained below.

1. Buffer AMP

This block is used to buffer the local oscillator and to obtain a voltage level sufficient to drive the prescaler.

2. Prescaler

This block divides the local frequency, since it is too high for the programmable divider to handle directly.

3. Programmable divider

This block is the core of the synthesized tuner. It divides the input frequency (prescaler output) to 25 kHz according to the division ratio given by the controller.

Example:

To receive a broadcast on 101.3 MHz

$$f = 101.3 \text{ MHz}$$

$$f_{osc} = 101.3 + 10.7 = 112 \text{ MHz}$$

f_{osc} is divided by 16 by the prescaler.

$$f_{in} = 112 \div 16 = 7 \text{ (MHz)}$$

The reference frequency is 25 kHz.

$$f_r = 25 \text{ kHz}$$

To divide 7 MHz into 25 kHz, f_{in} must be divided by 280. That is, the division ratio is 280 for receiving 101.3 MHz.

4. ϕ/D (phase detector)

This block compares the phase of the divided signal with that of the 25 kHz reference signal and outputs voltage which is proportional to the difference.

5. Frequency divider

This block divides the reference oscillator signal to 25 kHz.

6. Reference oscillator

This block uses a crystal to generate a 4.5 MHz reference signal.

7. LPF

This block filters the phase detector output signal to obtain a DC signal.

8. Local oscillator

This block generates a frequency which varies according to the DC signal output by the LPF.

9. Controller

This block determines the division ratio for the programmable divider.

PLL Operation

The phase detector (ϕ/D in Fig. 1) compares the phase of input signals f_r and f_r' . When there is a difference between the two, a difference signal is output to LPF, where it is converted to a DC signal. This DC signal is applied to the VCO (local oscillator) so that the frequency it generates is varied to reduce the difference between f_r and f_r' . Thus, a very accurate and stable local frequency is obtained.




Fig. 2 Charge pump and LPF

CIRCUIT DESCRIPTION

In practice, a charge pump circuit is placed between ϕ/D and LPF. Figure 2 shows an example of a charge pump circuit.

Assume that fr' leads fr in phase. Low and high level signals are applied to terminals PD and PU, respectively. The base current of Q1 flows since the emitter level is low. Q2 is reverse-biased, so it is OFF. Q3 and D1 conduct, so the base voltage of Q3 is about 1.5V. The level at the emitter of Q4 (or at the base of Q5) is about 3V because the level at the base of Q3 is half of the level at the emitter of Q4. At this time, the level at the emitter of Q5 is about 2.25V ($3V - V_{BE}$). This level is lower than the level at terminal PU (2.4V or higher in the case of TTL), so D2 is reverse-biased. Q6 and Q7 are ON since the Q5 emitter level is 2.25V. Therefore, the collector level of Q7 decreases.




Fig. 3 Input voltage VS. output frequency of the VCO

With the VCO, the frequency generated is generally in proportion to the input voltage as shown in Fig. 3. Therefore, the VCO frequency falls when the collector level of Q7 drops. Thus, fr' approaches fr .

On the other hand, assume that fr' lags fr in phase. In this case, high and low level signals are applied to terminals PD and PU, respectively. D2 is forward-biased, so the level at terminal UF is about 0.65V. Current flows through the base and collector of Q1 to the base of Q2. Q2 conducts, so Q4 cannot drive Q5. Since Q5 is OFF, the level at terminal UF is low and no base current flows into Q6. Therefore, the collector level of Q7 increases. As described above, the charge pump reverses the pulse signals generated according to the phase difference between fr and fr' and converts them to an appropriate level for application to LPF. When there is no phase difference between fr and fr' , high level signals are applied to terminals PD and PU, so that terminals DF and UF are floating. Therefore, the VCO oscillates, according to the voltage charged in the capacitor of LPF.

Pulse swallow system

In the PLL system, it is desirable that the reference frequency be set as high as possible to improve the C/N (carrier/noise) ratio. With the fixed division ratio prescaler, however, the reference frequency cannot be set very high when the division ratio is large.

The pulse swallow system solves this problem by using two frequency division ratios. The pulse swallow system allows the frequency input to the programmable divider to be lower and allows the VCO frequency to be changed in relation to the reference frequency by changing the division ratio of the programmable divider by one.




Fig. 4 DC-20X frequency synthesizer (pulse swallow system)

CIRCUIT DESCRIPTION

Tuning with the pulse swallow system

Table 1 Frequency table (U.S. band)

f (MHz)	f_{osc} (MHz)	f_{in} (MHz)	Total division ratio (N) : Decimal	Total division ratio (N) : Hexadecimal	n_1	NP
101.3	112.0	7.0	4480 ₁₀	1180 ₁₆ ($= \overbrace{1180}_{a} \overbrace{+0}_{b}$)	0	280
101.5	112.2	7.0	4488 ₁₀	1188 ₁₆ ($= 1180_{16} + 8_{10}$)	8 ₁₀	280
101.7	112.4	7.0	4496 ₁₀	1190 ₁₆ ($= 1180_{16} + 16_{10}$)	16 ₁₀	280
101.9	112.6	7.0	4504 ₁₆	1198 ₁₆ ($= 1180_{16} + 24_{10}$)	24 ₁₀	280
102.1	112.8	7.05	4512 ₁₀	11A0 ₁₆ ($= 11A0_{16} + 0$)	0	282
102.3	113.0	7.05	4520 ₁₀	11A8 ₁₆ ($= 11A0_{16} + 8_{10}$)	8 ₁₀	282
102.5	113.2	7.05	4528 ₁₀	11B0 ₁₆ ($= 11A0_{16} + 16_{10}$)	16 ₁₀	282

f : Receiving frequency
 f_{osc} : Local oscillator frequency
 f_{in} : Frequency input to μ PD1703C-016
 N : Total division ratio = $f_{osc} \div f_r$ ($= 25$ kHz)
 n_1 : Value of b in the total division ratio (division ratio of the swallow counter)
 N_p : Division ratio of the program counter (the value of a in the total division ratio divided by 16)

Assume that 101.3 MHz is received through preset tuning. In the U.S.A., local frequency f_{osc} is 10.7 MHz higher than the receiving frequency.


$$f_{osc} = 101.3 + 10.7 \text{ MHz} \\ = 112 \text{ MHz}$$

When the reference frequency is 25 kHz, the total division ratio is

$$N = f_{osc} \div f_r \\ = 112 \div 0.025 \\ = 4480_{10} \text{ (decimal)} \\ = 1180_{16} \text{ (hexadecimal)} \\ = 0001000110000000_2 \text{ (binary)}$$


Reference:

Total division ratio N is set in the N and NF registers of the microprocessor in binary.



As shown above, the least significant bit is set in the NF register and the most significant bit is set to 0. With this method, the contents of the N register are equal to the division ratio when $f_r = 50$ kHz. That is, the VCO frequency can be varied by 50 kHz by changing the contents of the N register by one. For use in the

U.S.A. (since the channel space is 200 kHz), the VCO frequency can be varied by 200 kHz by changing the contents of the N register by four. For example, by adding four to the value shown in the previous figure,



$$N = 1188_{16} \\ = 4488_{10}$$

This value is equal to the total division ratio (4488₁₀) when $f_{osc} = 112.2$ MHz.

When a prescaler with a fixed division ratio is used, it is difficult to set the reference frequency to 25 kHz, so it may be necessary to set it to a lower value. As described previously, the C/N ratio is degraded as the reference frequency is reduced. This problem is solved by using a prescaler with two division ratios.

In the DC-20X, μ PB553AC allows the division ratio to be set to 1/16, and 1/17 is used for the prescaler.





Fig. 5 μ PB553AC block diagram

CIRCUIT DESCRIPTION

 μ PB553AC Operation

- 1 When no pulse signal is applied to the PSC terminal, the prescaler outputs 1 pulse for every 16 pulses input to the IN terminal.
- 2 When a pulse applied to the PSC terminal rises, one of the pulses input to the IN terminal is ignored; that is, the prescaler outputs 1 pulse for every 17 pulses input to the IN terminal.

When $f = 101.3$ MHz ($f_{osc} = 112$ MHz), the number of pulses applied to the input terminal of the prescaler is 112,000,000 per second. At this time, the total division ratio is 4480, which is divisible by 16.

$$4480 \div 16 = 280$$

In this case, the prescaler can operate with a division ratio of 1/16 so that no pulse signal is applied to the PSC terminal.

The number of pulses is decreased to 7,000,000 by the prescaler, then decreased to 25,000 ($7000000 \div 280$) by the programmable counter. This means that the frequency of the programmable counter output signal is 25 kHz; that is, f_{osc} is divided to 25 kHz.

Consider the case in which $f = 101.5$ MHz ($f_{osc} = 112.2$ MHz). Here, the prescaler plays an important role. The total division ratio is not divisible by 16.

$$4488 \div 16 = 280 \dots 8$$

At this time, the programmable counter is set to 280 and the swallow counter is set to 8.

One pulse swallow operation is completed within 1/25000 seconds. Therefore, making the time unit 1/25000 seconds allows the operation to be understood more easily.

The number of pulses of the 112.2 MHz signal is 4488 per time unit (1/25000 seconds). 8 pulses are applied to

the PSC terminal during each time unit. This means that the prescaler outputs one pulse for every 17 input pulses until 8 pulses are output, then outputs one pulse for every 16 input pulses for the period during which (280 $\sim$ 8) pulses are output. Thus, the prescaler outputs 280 pulses for the period of the time unit (1/25000 seconds).

$$17 \times 8 + 16 \times (280 - 8) = 4488$$

(equal to total division ratio)

This number of pulses (280) is equal to that in the case in which $f_{osc} = 112$ MHz. 280 pulses in 1/25000 seconds means 7,000,000 pulses per second; that is, the frequency is 7 MHz.

As is described above and shown in Table 1, f_{in} is identical for 4 adjacent receiving frequencies (or channels).

After one pulse swallow operation has been completed, signal f_r is sent to the ϕ/D , and the swallow counter and programmable counter are reset to repeat the above operation.

Reference

In general, total division ratio N is represented by the sum of n_1 (for 1/17 division) and n_2 (for 1/16 division).

$$N = 17 \cdot n_1 + 16 \cdot n_2$$

(This is the basic principle of the pulse swallow system). Since the program counter division $N_p = n_1 + n_2$.

$$N = 17 \cdot n_1 + 16 \cdot (N_p - n_1) \\ = n_1 + 16N_p$$

This means that the quotient of N divided by 16 (N_p) is set to the programmable counter and the remainder (n_1) is set to the swallow counter.


CIRCUIT DESCRIPTION

II. SYNTHESIZER TUNER CHECKING

The fundamental check points of the synthesizer tuner are as follows.


- 1 The microprocessor power supply voltage
- 2 The microprocessor clock system

IC4-5 2V/cm, 10 μ s/cm, DC




- 3 f_{in} : Manually set the display frequency as shown in Table 1 and confirm that f_{in} (at pin 26 of the microprocessor IC) is equal to the value shown in the table.

IC4-26 0.5V/cm, 0.2 μ s/cm, AC



When a pulse is not applied to terminal PSC.




When a pulse is applied to terminal PSC.

- 4 PSC terminal: In the U.S.A., the number of pulses at the PSC terminal changes in the sequence 0, 8, 16, 24 (200 kHz steps); in Europe, the sequence is 0, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30 (50 kHz steps) when the ceramic filters of red color are used. When the ceramic filters other than red color are used, the number of pulses at the PSC terminal is different from the case of the ceramic filter of red color.

IC4-4 2V/cm, 2 μ s/cm, DC


When the ceramic filters of black color are used. (center frequency: 10.650 MHz)




$f = 101.3$ MHz



$f = 101.5$ MHz




$f = 101.7$ MHz



$f = 101.9$ MHz

- 5 Confirm that the (charge pump) waveform at pin 1 of the microprocessor is as shown in the photograph.

IC4-1 1V/cm, 20 μ s/cm, the white line indicates 1.2V.




- 6 Confirm that the collector voltage of Q26 varies continuously from about 1V to about 8V as the frequency varies from low to high.

For AM reception, the prescaler is not used and the local frequency is divided directly by the programmable divider.

IC4-2 1V/cm, 20 μ s/cm, the white line indicates 1.2V.



IC4-28 0.5V/cm, 0.5 μ s/cm, AC



CIRCUIT DESCRIPTION

III. FREQUENCY SYNTHESIZER USED IN THE DC-20X

The basic block diagram of the frequency synthesizer used in the DC-20X is almost the same as that shown in Figure 1; the prescaler, however, uses the pulse swallow system. Microprocessor μ PD1703C-016 for the PLL synthesizer and prescaler μ PB553AC are used to form the LW/MW/FM digital synthesizer tuner.

μ PD1703C-016

Features

- Capable of directly driving the segments of the FIP (fluorescent tube)
- Built-in PLL, swallow counter and controller
- Easily preset memory back-up (less than 10 μ A)
- Capable of displaying the preset memory channel address (by LED)
- High FM reference frequency (25 kHz) because of the pulse swallow system.
- Can be set for frequency ranges and channel spaces (LW/MW and FM) used in the USA, Europe or Japan
- Capable of storing 7 frequencies for FM and 7 frequencies for LW/MW
- Either the momentary switch or the alternate switch can be used as preset keys and band selector keys (MW and FM).
- Last channel memory for each band
- Capable of AUTO and MANUAL UP/DOWN tuning (sawtooth wave tuning)
- Off setable FM IF (4 frequencies in 25 kHz intervals)
- Built-in frequency presetting function for adjustment during mass production
- 4-1/2 digit display for the European FM band (4 digit display for other bands)
- Small 28-pin slim DIP
- Single power supply of 5V $\pm$ 10%

Outline of Functions

Receiving frequency, reference frequency, channel space and intermediate frequency.

		Frequency range	Channel space	Reference frequency	Intermediate frequency
U.S.A.	① MW1	530~1 620 kHz	10 kHz	10 kHz	450 kHz
	MW2	522~1 611 kHz	9 kHz	9 kHz	
	② FM	87.9~107.9 MHz	200 kHz	25 kHz	10.650, 10.675, 10.700, 10.725 MHz
Europe	③ MW	522~1 611 kHz	9 kHz	9 kHz	450 kHz
	LW	146~353 kHz	9 kHz	1 kHz	
	④ FM	87.50~108.00 MHz	50 kHz	25 kHz	10.650, 10.675, 10.700, 10.725 MHz
Japan	MW	522~1 611 kHz	9 kHz	9 kHz	450 kHz
	FM	76.1~89.9 MHz	100 kHz	25 kHz	10.675, 10.700, 10.725, 10.750 MHz

With the DC-20X, the channel spacing can be changed with the switch provided on the rear panel. When this switch is in the up position, the channel spacing is set as shown in ③ in the table above. When it is in the down position, the channel spacing is set as shown in ① in the table. The above channel space settings are not changed when the switch setting is changed after the power has been turned on. (To change the channel spacing after the power has been turned on, set the selector to a position other than AM (MW) or FM position, then return it to the AM (MW) or FM position.)

Tuning Function

(1) AUTO tuning (sawtooth wave mode)

- AUTO UP Tuning is automatically stopped
- AUTO DOWN when a high level signal is detected at the SD terminal and the signal is received.


(2) MANUAL tuning

- MANUAL UP Tuning in steps with the momentary switch. Fast tuning is performed when the switch is pressed for 0.5 seconds or more, and continues until the switch is released.
- MANUAL DOWN

(3) Preset memory tuning

7 stations for FM

A total of 7 stations for LW and MW (can be randomly accessed)



CIRCUIT DESCRIPTION

Pin No.	Symbol	Terminal name	Description
1 2	EO ₁ EO ₂	Error Out	Charge pump output for the phase detector which is one of the components of the PLL. When the divided local frequency is higher than the reference frequency, these terminals output high level signals. When it is lower, they output low level signals. When the frequencies are equal, these terminals float. EO ₁ and EO ₂ output identical signals simultaneously; therefore they may be connected to the LPF (low pass filter) for either MW/LW or FM.
3	CE	Chip Enable	Chip enable input. High level — Normal operation Low level — Memory backup operation (Display OFF, PLL inactive, internal clock generator OFF) During memory backup operation, this chip consumes less than 10 μ A of current. A level must continue for more than 134 μ s or the processor does not recognize it as a level change.
4	PSC	Prescaler Control	Outputs the signal which alternates the prescaler division ratio when the pulse swallow system is used for frequency division (for FM reception). Connected to prescaler μ PB553AC. Its frequency division ratios are alternated between 1/16 and 1/17.
5 6	X1 X2	X'tal	A 4.5 MHz crystal is connected across these terminal.
7	SD	Station Detector	A signal is input to this terminal when a broadcast signal is received during AUTO tuning (AUTO UP/DOWN). The signal must be input within 75 ms after the PLL has locked.
8	MUTE	MUTE	Outputs the muting signal which reduces the shock noise generated when the PLL unlocks. The signal level is high when active. The signal level drops to low when a low level signal is applied to the CE terminal. The high level continues: About 700 ms during band switching. About 200 ms (for each step) during MANUAL tuning. About 200 ms after a high level signal has been input to the SD terminal during AUTO tuning, and About 450 ms during preset memory tuning.
9 ~ 13	$\overline{D}_1 \sim \overline{D}_5$	Digit Outputs	These terminals output the display digit drive signals. These signal levels are high when active.
14	VDD	VDD	5V $\pm$ 10% is supplied during normal operation. This can be lowered to 3.0V during backup operation. The rise time of VDD must be less than 500 ms, if it is too long, initialization may fail.
15 ~ 21	Sa ~ Sg	Segment Outputs	These terminals output the display segment drive signals and key return signals. The signal levels are high when active. A voltage of up to 30V can be applied to these terminals, so they can be directly connected to the segment terminals of the FIP (fluorescent display tube).

CIRCUIT DESCRIPTION

Pin No.	Symbol	Terminal name	Description
22 ~ 25	$K_0 \sim K_3$	Key Return Signal Inputs	Key return signals from the external key matrix are input to these terminals.
26	FM	FM Local Oscillator Signal Inputs	The FM local oscillator signal frequency divided by the prescaler (1/16 or 1/17) is input to this terminal. This terminal is connected internally to an AC amplifier; therefore, DC components should be cut from the input signal with a capacitor.
27	GND	GND	Connected to system ground.
28	AM	AM Local Oscillator Signal Inputs	The MW/LW local frequency is input to this terminal. This terminal is internally connected to an AC amplifier; therefore, DC components should be cut from the input signal with a capacitor.



Key Matrix System

In the key matrix system, many key switches are divided into several groups. These groups are scanned sequentially to read the status of each key. This system is also called the dynamic key scan system.

The above figure shows the principle of the key switch input circuit used in the DC-20X. The input terminals are grounded through the pull-down resistors so that they do not float when no key switch is pressed.

Each output terminal is set to high in turn by the program; only one terminal is at high at a time. Therefore, the status of the 4 key switches at the intersections between the 4 input terminal lines and the line (group selection line) connected to the terminal which is currently high can be input at one time.

The status of all 28 key switches can be input in 7 ms when the output terminals are scanned at 1 ms intervals. This period is short enough compared with the time required for a human being to press a key switch that any key depression is always detected by this method. The key pressed can be identified from the input terminal to which the high level is input and the output terminal from which the high level is output.



CIRCUIT DESCRIPTION

1. Key Matrix Configuration

1-1 Key matrix arrangement

OUT \ IN	K0 (25)	K1 (24)	K2 (23)	K3 (22)
Sa (21)	DOWN	UP	MEMORY	TRACKING POINT PRESET
Sb (20)	M4	M3	M2	M1
Sc (19)		M7	M6	M5
Sd (18)		LW	FM	MW
Se (17)				
Sf (16)	9KHz/10KHz		AUTO/MANUAL	
Sg (15)	BAND B	BAND 1	IF 1	IF B

□ denotes a momentary switch.


▨ denotes a mode selecting alternate switch.

▩ denotes an initialization diode switch.

□ denotes an open circuit.

Numbers in parentheses are pin numbers.

1-2. Key matrix switch connection



Key input

○ Momentary switch

▨ Alternate switch

▩ Diode switch

Segment output

Except for KEY LOCK KEY, which is connected without a diode.

or open circuit.

CIRCUIT DESCRIPTION

2. Key Matrix Explanation

2-1. Initialization key matrix

Three types of diode switches are used in the initialization key matrix circuit as shown below. All diode switches are read by the microprocessor when power is first supplied to the VDD terminal, or when the level at the CE terminal changes from low to high.

The 9 kHz/10 kHz switch is read constantly, but the PLL data and display contents do not change until a momentary switch (UP, DOWN, S1 ~ S7, etc.) is pressed.

(1) FM IF offset setting switches

IFO and IF1

(2) FM band frequency range setting switches

BAND 0 and BAND 1

(3) MW band channel space and reference frequency setting switch

9 kHz/10 kHz

Short the intersections of the initialization key matrix with diodes as required and leave the remaining intersections open. (See the following table).

Symbol	Function																																										
IF 1 IF 0	These switches select the IF frequency from among four frequencies as shown below. <table><tr><th>IF 1 (D26)</th><th>IF 0 (D25)</th><th>U.S.A.</th><th>Europe</th><th>Japan</th><th>Reference:</th></tr><tr><td>① Open</td><td>Open</td><td>10.700 MHz</td><td>10.700 MHz</td><td>10.700 MHz</td><td>Ceramic filter center frequency</td></tr><tr><td>② Open</td><td>Short</td><td>10.725 MHz</td><td>10.725 MHz</td><td>10.675 MHz</td><td>Red: 10.700 MHz</td></tr><tr><td>③ Short</td><td>Open</td><td>10.650 MHz</td><td>10.650 MHz</td><td>10.750 MHz</td><td>Blue: 10.675 MHz</td></tr><tr><td>④ Short</td><td>Short</td><td>10.675 MHz</td><td>10.675 MHz</td><td>10.725 MHz</td><td>Orange: 10.725 MHz</td></tr><tr><td></td><td></td><td></td><td></td><td></td><td>Black: 10.650 MHz</td></tr><tr><td></td><td></td><td></td><td></td><td></td><td>White: 10.750 MHz</td></tr></table> In the U.S.A. and Europe, red ceramic filters can be used in the case of ①, orange in the case of ②, black in the case of ③ and blue in the case of ④.	IF 1 (D26)	IF 0 (D25)	U.S.A.	Europe	Japan	Reference:	① Open	Open	10.700 MHz	10.700 MHz	10.700 MHz	Ceramic filter center frequency	② Open	Short	10.725 MHz	10.725 MHz	10.675 MHz	Red: 10.700 MHz	③ Short	Open	10.650 MHz	10.650 MHz	10.750 MHz	Blue: 10.675 MHz	④ Short	Short	10.675 MHz	10.675 MHz	10.725 MHz	Orange: 10.725 MHz						Black: 10.650 MHz						White: 10.750 MHz
IF 1 (D26)	IF 0 (D25)	U.S.A.	Europe	Japan	Reference:																																						
① Open	Open	10.700 MHz	10.700 MHz	10.700 MHz	Ceramic filter center frequency																																						
② Open	Short	10.725 MHz	10.725 MHz	10.675 MHz	Red: 10.700 MHz																																						
③ Short	Open	10.650 MHz	10.650 MHz	10.750 MHz	Blue: 10.675 MHz																																						
④ Short	Short	10.675 MHz	10.675 MHz	10.725 MHz	Orange: 10.725 MHz																																						
					Black: 10.650 MHz																																						
					White: 10.750 MHz																																						
BAND 1 BAND 0	These switches select the FM frequency range as shown below. <table><tr><th>BAND 1 (D28)</th><th>BAND 0 (D27)</th><th>Area</th><th>Frequency range</th><th>Channel space</th></tr><tr><td>Open</td><td>Open</td><td>U.S.A.</td><td>87.9 ~ 107.9 MHz</td><td>200 kHz</td></tr><tr><td>Open</td><td>Short</td><td>Europe</td><td>87.5 ~ 108.0 MHz</td><td>50 kHz</td></tr><tr><td>Short</td><td>Open</td><td>Japan</td><td>76.1 ~ 88.9 MHz</td><td>100 kHz</td></tr></table> * Never short both BAND 0 and BAND 1, or the receiving frequency range will not be correctly set.	BAND 1 (D28)	BAND 0 (D27)	Area	Frequency range	Channel space	Open	Open	U.S.A.	87.9 ~ 107.9 MHz	200 kHz	Open	Short	Europe	87.5 ~ 108.0 MHz	50 kHz	Short	Open	Japan	76.1 ~ 88.9 MHz	100 kHz																						
BAND 1 (D28)	BAND 0 (D27)	Area	Frequency range	Channel space																																							
Open	Open	U.S.A.	87.9 ~ 107.9 MHz	200 kHz																																							
Open	Short	Europe	87.5 ~ 108.0 MHz	50 kHz																																							
Short	Open	Japan	76.1 ~ 88.9 MHz	100 kHz																																							
9 kHz/10 kHz	This switch sets the channel space, reference frequency and frequency range on the MW band, regardless of the position of the BAND switches for FM. <table><tr><th>D24, Q18, S1 (9 kHz/10 kHz)</th><th>Frequency range</th><th>Channel space</th><th>Reference Frequency</th></tr><tr><td>OPEN</td><td>530 ~ 1620 kHz</td><td>10 kHz</td><td>10 kHz</td></tr><tr><td>Short</td><td>522 ~ 1611 kHz</td><td>9 kHz</td><td>9 kHz</td></tr></table> The status of this switch is read by every key matrix scan but the related PLL data and display are not changed until a momentary switch (UP, DOWN, M1 ~ M7, etc.) is pressed.	D24, Q18, S1 (9 kHz/10 kHz)	Frequency range	Channel space	Reference Frequency	OPEN	530 ~ 1620 kHz	10 kHz	10 kHz	Short	522 ~ 1611 kHz	9 kHz	9 kHz																														
D24, Q18, S1 (9 kHz/10 kHz)	Frequency range	Channel space	Reference Frequency																																								
OPEN	530 ~ 1620 kHz	10 kHz	10 kHz																																								
Short	522 ~ 1611 kHz	9 kHz	9 kHz																																								

CIRCUIT DESCRIPTION

2-2. Alternate switch

Symbol	Function
AUTO/MANUAL	ON..... AUTO scan OFF..... MANUAL scan Scanning starts when the UP or DOWN momentary switch is pressed after this switch has been set. Note: AUTO tuning operation is not interrupted even if this switch is switched during the operation. Scanning is not performed or is unstable (i.e. scanning speed is unstable) if the PLL system is defective.
MW FM LW	Band selection switches. A muting signal of about 750 ms is output from the MUTE terminal when the band is switched.
UP DOWN	Tuning key switches for both AUTO and MANUAL operation. These key switches function as follows. ● When the AUTO/MANUAL switch is set to AUTO: (1) The receiving frequency is raised in the sawtooth wave mode when the UP key is pressed. This operation (AUTO UP operation) stops when a high level signal is applied to the SD terminal. AUTO DOWN operation starts when the DOWN key is pressed during AUTO UP operation. (2) The receiving frequency is lowered in the sawtooth wave mode when the DOWN switch is pressed. This operation (AUTO DOWN operation) stops when a high level signal is applied to the SD terminal. AUTO UP operation starts when the UP switch is pressed during AUTO DOWN operation. * AUTO UP or DOWN operation is performed at the rate of 80 ms/step. * Operation continues as long as the UP key is pressed during AUTO UP operation or the DOWN key is pressed during AUTO DOWN operation. As long as either of these key is held down, the corresponding AUTO operation will not stop even if a high level signal is applied to the SD terminal. ● When the AUTO/MANUAL switch is set to MANUAL: (1) The receiving frequency is increased by 1 step each time the UP key is pressed. (2) The receiving frequency is lowered by 1 step each time the DOWN key is pressed. (3) The receiving frequency changes at the rate of 1 step each 80 ms in the applicable direction when either the UP or DOWN key is held for more than 0.5 seconds. Operation stops when the key is released. * 1 step is equal to 1 channel space. FM: U.S.A. 200 kHz Europe 50 kHz Japan 100 kHz AM: U.S.A. 10 kHz Europe 9 kHz Japan 9 kHz
M1 ~ M7	Preset memory write and read keys. Each key corresponds to one FM preset memory channel and one AM (MW + LW) preset memory channel. ● To preset a frequency, press the MEMORY key, then press one of keys M1 through M7 within 5 seconds; the frequency is stored in the corresponding preset memory channel. ● To read a preset memory channel, press the corresponding memory key (M1 ~ M7). When a memory read is performed after VDD has first been supplied, the frequency of the low end of the selected band is read. (In the U.S.A. FM: 87.9 MHz; AM: 530 kHz).
MEMORY	Enables memory write. The currently displayed frequency is stored in memory when one of key's M1 through M7 is pressed within 5 seconds after this key has been pressed. To clear the memory write enable state, press the UP or DOWN switch or switch the mode selector.

CIRCUIT DESCRIPTION

3. Display

3-1. Display connection

Figure 1 shows an example of display connection. D1 through D5 and Sa through Sg correspond to digit terminals ($\overline{D1}$ through $\overline{D5}$) and segment terminals (Sa through Sg) of μ PD 1703C-016, respectively.

The segment terminals of μ PD1703C-016 can be directly connected with FIP (the fluorescent display tube) since up to 30V can be applied to these terminals (pin open drain output terminals). The digit signal output circuits of μ PD1703C-016 are complementary circuits which output low level signals when active. A 1-stage buffer (PNP transistor; 25A733) is required for each output circuit to which FIP is to be connected.




Fig. 1 Display connection

Note 1:

The "kHz" indication is driven by the ORed result of Sa and Sd. If the "LW" indication is not required the "kHz" indication may be driven by Sa alone.

Note 2:

In Europe, frequencies displayed end with either "0" or "5" since the channel spacing is 50 kHz. Care must be taken in connecting the segments. In U.S.A. or Japan, disconnect the last digit or the segment Sg connection.

Segment Digit	Sa	Sb	Sc	Sd	Se	Sf	Sg
$\overline{D1}$	a	b	c	d	e	f	g
$\overline{D2}$	a	b	c	d	e	f	g
$\overline{D3}$	a	b	c	d	e	f	g
$\overline{D4}$		b	c				
$\overline{D5}$	MW	MEMO		LW	—		FM

3-2. Display examples

The following are examples of the display when the fluorescent display tube shown in Figure 1 is used.

(1) FM (U.S.A.)

FM 103.7 MHz

(2) FM (Europe)

FM 89.45 MHz

(3) FM (Japan)

FM 76.1 MHz

(4) MW (Channel space: 10 kHz)

MW 1620 MEMO KHz

(5) MW (Channel space: 9 kHz)

MW 531 KHz

(6) LW (Europe)

LW 200 KHz

* The "MEMO" indication lights for 5 seconds after the MEMORY key (momentary switch) is pressed. It goes off when one of the preset keys (M1 ~ M7) is pressed to preset a frequency.

CIRCUIT DESCRIPTION


Preset memory channel BCD code output

Sg	Sf	Se	Preset memory channel
0	0	1	P1 (M1 key)
0	1	0	P2 (M2 key)
0	1	1	P3 (M3 key)
1	0	0	P4 (M4 key)
1	0	1	P5 (M5 key)
1	1	0	P6 (M6 key)
1	1	1	P7 (M7 key)


5. Timing Chart

5-1. Display and key read timing

(1) D1 ~ D3, D5




(2) D4




5-2. MUTE timing

(1) MANUAL UP/DOWN




Band edge (Max. freq. → Min. freq. or Min. freq. → Max. freq.)




(2) AUTO UP/DOWN


When the SD signal is input:




When the SD signal is not input.



Band edge (Max. freq. → Min. freq. or Min. freq. → Max. freq.)




(3) PRESET MEMORY CALL



When the band is switched (MW → LW or LW → MW)



(4) FM/MW/LW switching and Power ON (CE: Low → High)




- ① KEY ON chatter prevention
- ② Pre-muting
- ③ Dividing ratio set and display data updated
- ④ Post-muting
- ⑤ Scanning
- ⑥ Time required for PLL to lock

CIRCUIT DESCRIPTION

IV. DECK OPERATION

1. Control Keys

a) Layout




b) Key functions

- ① **Rewind** — rewind to a beginning of the current selection, skipping back to the beginning of a previous selection, quick re-recording, one side repeat
- ② **PLAY** — One selection repeat, recording following playback, one side repeat.
- ③ **Fast forward** — fast forward to beginning of the next selection, skipping forward to the beginning of a following selection
- ④ **Stop** — (Program clear)
- ⑤ **Record** — Pause, recording following playback (Note: this unit uses the one-touch recording system.)
- ⑥ **Auto Rec Mute (4 seconds)** — (If this key is pressed again during Auto Rec Mute, Auto Rec Mute will be continued for another 4 seconds from that point.)

Note:

One side repeat: ① and ② are pressed simultaneously.
Recording following playback: ② is pressed with ⑤ held down.

c) LED layout



LED Position	Play	FF	Rew	Rec	Pause	Auto Rec Mute	Re- peat	DPSS
STOP	×	×	×	×	×	×	×	×
Play	○	×	×	×	×	×	×	×
F.F.	×	⊙	×	×	×	×	×	×
Rew	×	×	⊙	×	×	×	×	×

LED Position	Play	FF	Rew	Rec	Pause	Auto Rec Mute	Re- peat	DPSS
Cue	×	⊙	×	×	×	×	×	⊙
Rev	×	×	⊙	×	×	×	×	⊙
Rec	⊙	×	×	○	×	×	×	×
Pause	×	×	×	×	○	×	×	×
Auto Rec Mute	⊙	×	×	○	×	⊙	×	×
During one selection repeat	⊙	×	×	×	×	×	○	⊙
During REW	×	×	⊙	×	×	×	○	⊙
During one side repeat play	⊙	×	⊙	×	×	×	×	×
During one side repeat rewind	⊙	×	⊙	×	×	×	×	×
During REVIEW for quick re-recording	×	×	⊙	×	×	⊙	×	×

- × : Not lit
- : Lit
- ⊙ : Blinking slowly
- ⊙ : Blinking rapidly

2. Forward and reverse program selection

Application:

These functions are used to locate and play a selection which is a certain number of selections before or after the current selection.

Operation:

- 1 Press the $\gg$ or $\ll$ key during playback.
- 2 When the $\gg$ key or $\ll$ key is pressed N times:
 - For the $\gg$ key, the selection which is N selections after the current selection will be located and played.
 - For the $\ll$ key, the selection which is (N-1) selections before the current selection will be located and played.
- 3 Any selection up to the 7th one may be selected in the forward direction, and any selection up to the 6th one may be selected in the reverse direction.
- 4 When the $\gg$ key or $\ll$ key is pressed one time:
 - For the $\gg$ key, the tape will be advanced the beginning of the next selection.
 - For the $\gg$ key, the tape will be rewound to the beginning of the current selection.
- 5 The dot counter will indicate the number of times the key is pressed for both ② and ④ above.
- 6 The dot counter is reduced each time a program is passed during forward or reverse selection to indicate the number of the program which is currently being skipped.

CIRCUIT DESCRIPTION

- 7 Forward/reverse program selection ends when the dot counter goes out and the mechanism automatically shifts to the playback mode of operation.

Note:

Press the applicable key without interruption; it is not possible to add to the program count once the unit enters the program selection mode of operation.

The microprocessor regards any unrecorded section of approximately 100 ms or more as an interval between two selections. The unit always shifts to the PLAY mode of operation via STOP.

3. One selection repeat

Application:

This function is used to cause the selection which is currently being played to be repeated a certain number of times.

Operation:

- 1 Press the ► key during playback.
- 2 Press the key without interruption as many times as you want the selection to be repeated.
- 3 The maximum number of repetitions possible is 7.
- 4 The play mode of operation is maintained after the specified number of repetitions is completed.
- 5 Press the STOP key to reset the unit during repeated playback.
- 6 The dot counter counts the number of repetitions.
- 7 The repeat indicator remains lit during repeated playback.
- 8 The dot counter is reduced each time one repetition is completed to indicate the number of repetitions remaining. The repeat indicator goes out when repeat operation is completed.

Note:

It is not possible to add to the number of repetitions to be made while repeat operation is being performed. One selection repeat operation begins approximately 600 ms after the ► key is released. When an unrecorded section lasting about 3 seconds is encountered, the microprocessor regards it as the unrecorded section between recordings and enters the REVIEW mode of operation. Then, when an unrecorded section lasting about 100 ms is encountered, the unit enters the PLAY mode of operation via STOP.

4. One side repeat

Application:

This function is used to cause the entire side of the tape to be repeated from beginning to end.

Operation:

- 1 Press the ► key and ◀◀ key simultaneously.
- 2 The tape will be played back repeatedly until the STOP key is pressed.
- 3 During playback, the ► and ◀◀ indicators both blink slowly; during rewind, they blink rapidly.

5. Quick re-recording

Application:

This function is used to rewind the tape to the point at which recording was begun when recording is to be started over for any reason. After the tape is rewound, the unit goes to standby.

Operation:

- 1 Press the ◀◀ key while the unit is in the record mode of operation.
- 2 The tape will be rewound until an unrecorded section is detected, then the unit will enter AUTO REC MUTE via STOP and pause in standby.
- 3 The record mode of operation can be restored even during review or AUTO REC MUTE by pressing the record key.

6. Recording following playback

Application:

This function is used when you wish to record additional material immediately after a previously recorded selection.

Operation:

- 1 Play the tape to listen for the location at which recording is to begin.
- 2 While monitoring, press the ► key while holding down the record key.
- 3 Recording will begin the moment the ► key is pressed.

CIRCUIT DESCRIPTION

- Pin 14 (PE₂):** Pin for output of the source ON signal. "H" is output during STOP, FF, REW, REC, PAUSE, tape rewind for quick re-recording, and AUTO REC MUTE; "L" is output during PLAY, one selection repeat, program selection and one side repeat. Output does not change during a momentary STOP.
- Pin 15 (PE₃):** Pin for output of the signal used for driving the motor. "L" is output during STOP and "H" is output at other times. Also, "H" is output for about 320 ms when the power is turned on so that the mechanism will move to the STOP state if it is not already in it.
- Pin 16 (PF₀):** Pin for output of the signal used for switching the output level of the unrecorded section detection circuit. "H" is output during PLAY, REC, AUTO REC MUTE, and one side repeat; "L" is output at other times. This pin is also used for output of the LED drive signal for PLAY.
- Pin 17 (PF₁):** Pin for output of the FF LED drive signal. "H" is output during FF and CUE. "H" is also output when the FF key is pressed for forward program selection.
- Pin 18 (PF₂):** Pin for output of the REW LED drive signal. "H" is output during REW, REVIEW, and one side repeat. "H" is also output when the REW key is pressed for reverse program selection.
- Pin 19 (PF₃):** Pin for output of the repeat LED drive signal. "H" is output during repeat. "H" is also output each time a key is pressed when the number of repetitions is being entered.
- Pin 20 (TEST):** This pin is used for testing the internal logic. This pin is connected to VSS, since it is not required when the microprocessor is used.
- Pin 21 (VSS):** 5V power supply (4.5 ~ 5.5V operating range). The microprocessor will not operate properly if the prescribed supply voltage is not present.
- Pin 22 (PG₀):** This pin outputs "H" during REC and AUTO REC MUTE (approximately 4 seconds).
- Pin 23 (PG₁):** This pin outputs "H" during REC PAUSE.
- Pin 24 (PG₂):** This pin outputs "H" momentarily when the power is turned on. It is used for timer PLAY detection.
- Pin 25 (PG₃):** This pin outputs "H" during REC, PAUSE, and AUTO REC MUTE.
- Pins 26 ~ 32 (PH₀ ~ PI₂):** These pins output the LED drive signals for selection number display and number-of-repetitions display.
- Pin 33 (PA₀):** "H" is input to this pin when the STOP key is pressed.
- Pin 34 (PA₁):** "H" is input to this pin when the PLAY key is pressed.
- Pin 35 (PA₂):** "H" is input to this pin when the FF key or REW key is pressed.
- Pin 36 (PA₃):** "H" is input to this pin when the REC/PAUSE or AUTO REC MUTE key is pressed.
- Pin 37 (PB₀):** "H" is input to this pin when the STOP, FF or AUTO REC MUTE key is pressed.

Pin 38 (PB₁): This pin is used for input of the reverse enable signal when PD₀ is "L". However, this unit does not feature this mode of operation.

When PD₀ is "H", REW solenoid signal ("H" for 80 ~ 100 ms if ON) is input.

Pin 39 (PB₂): This pin is used for input of the beginning-of-selection (unrecord section) detection signal when PD₀ is "L". When "H" is detected continuously, the microprocessor regards it as the interval between selections; when "L" is detected, the microprocessor regards it as a recorded section.

When PD₀ is "H", FF solenoid signal ("H" for 80 ~ 100 ms if ON) is input.

Pin 40 (PB₃): This pin is used for input of the tape end detection signal when PD₀ is "L". Hall IC DN6838 outputs "H" and "L" in alternation while the deck is running. When the deck stops running (that is, when the magnet pulley stops turning), the output of the Hall IC stops changing. This signal is used to cause the microprocessor to perform the auto-shut off operation.

Pin 41 (VGG): GND terminal.

Pin 42 (CL₀): Pin for connecting the external LC oscillator circuit for internal clock signal generation.


VI. TRANSISTOR OPERATION IN THE LOGIC (X05-2060-10) (D/7) unit

Q57: Inverter

Sets pin 6 of connector (50) to "L" during REC, PAUSE, and REC MUTE.

Q58: Used for switching input to PB₁₋₃.

When PD₀ is "L", Q58 is OFF and input terminals PB₁₋₃ are used for reverse enable switching, tape end detection, and beginning-of-selection detection, respectively. When PD₀ is "H", Q58 is on and these terminals are used for inputs of solenoid statuses.



Q59: Used for switching the clock frequency for the microprocessor.

When Q59 is OFF, the clock frequency (approximately 400 kHz) is determined by L26 and C100.

When Q59 is ON, the clock frequency is reduced by adding C101 to the oscillator circuit.

Q59 is turned ON and OFF with the BEAT CANCEL switch.

CIRCUIT DESCRIPTION

Q60: Used to clear reset.

"H" is applied to pin 7 when the power is turned on. Q60 goes ON soon afterwards, pin 7 becomes "L" and the microprocessor is reset and starts operating. When the power is turned off, D97 causes the voltage at the base of Q60 to become negative so that it goes OFF immediately. This causes pin 7 to become "H" momentarily, then to become "L" again so that the microprocessor is reset.

Q61, 63: Used to drive the REW solenoid.

Q62, 64: Used to drive the FF solenoid.

Q65: Inverter

Q66: Inverter

Q67, 68: Used to drive the motor.

Q69: Used for switching the function of PC₀.

Mechanism reset switch (pin 1 of connector 47):

This is an emergency switch which is shorted on both sides to clear the mechanism when it locks. This switch is normally open.

Connector states of the logic (X05-2060-10) (D7)

H: about 5V
L: 0V

MODE Pins	STOP	PLAY	FF	REW	CUE	RE- VIEW	REC	PAUSE	REC MUTE
⑤0-3	L	L	L	L	L	L	H	L	H (4 sec)
⑤0-4	L	H	L	L	L	L	H	L	H (4 sec)
⑤0-5	H	L*	L*	L*	L*	L*	L*	H	H (4 sec)
⑤0-6	H	H	H	H	H	H	L	L	L
④4-1	L	H	L	L	H	H	L	L	L
④4-2	L	L	L	L	H	H	L	L	L
FF SOLE- NOID SW	OFF	ON	ON	OFF	ON	OFF	ON	OFF	—
REW SOLE- NOID SW	OFF	ON	OFF	ON	OFF	ON	ON	OFF	—

* Takes 6 seconds for H to change to L.

STOP — PLAY (H: for 320 mS)

VII. REC AMP (X28-1410-10) A/4

Switching between the playback circuit and the record circuit is performed using transistor switching. The transistor statuses are as shown in the table.

Switching transistor states in REC AMP (X28-1410-10)

Mode Transistor	PLAY	REC	REW	FF	STOP	REC PAUSE	REC MUTE
Q1~4	ON	OFF	ON	ON	ON	OFF	
Q5,6	OFF	ON	OFF	OFF	OFF	ON	
Q7,8	OFF	ON	OFF	OFF	OFF	ON	
Q9,10	OFF	ON	OFF	OFF	OFF	ON	
Q13,14	ON	—	ON	ON	ON	OFF	
Q15,16	ON	OFF	ON	ON	ON	OFF	
Q17,18	OFF	ON	OFF	OFF	OFF	ON	
Q19,20 Q22,23	ON	OFF	ON	ON	ON	ON	ON
Q24,25 Q28	ON	OFF	ON	ON	ON	OFF	OFF
Q26,27	OFF	ON	OFF	OFF	OFF	ON	
Q29	OFF	OFF	ON	ON	ON	ON	
Q30,31	ON	ON	OFF	OFF	OFF	OFF	
Q35	ON	OFF	ON	ON	ON	OFF	OFF
Q36,37	OFF	ON	OFF	OFF	OFF	OFF	ON (4 sec)

1. ALC circuit

When the level of signal input increases during recording, the signal rectified by D1 controls Q21 to place Q13 (Q14) in a semiconducting state so that the level of the input signal to Q11 (Q12) is reduced.

Q 13 (Q14) is ON during PLAY.

2. Unrecorded section detection circuit

This circuit is composed of Q32 and Q33. Although Q29 is OFF during PLAY, it is ON during CUE and REVIEW so that the voltage of the signal to the detection circuit is divided. Q31 goes ON during PLAY so that the performance of the integrating circuit of the detection circuit is enhanced.

ADJUSTMENT (TUNER SECTION)

Alignment points and input and output settings are indicated on each printed circuit board.

NO.	ITEM	SYSTEM CONNECTIONS	TEST INSTRUMENTS SETTING	TUNER (RECEIVER) SETTING	ALIGNMENT POINTS	ALIGN FOR	FIG. NO.
FM SECTION							
1	DISCRIMINATOR	(A)/Connect a DC voltmeter across R9 (X05-2060-10 A/7).	100.1 MHz 1 kHz $\pm$ 75 kHz dev 60 dB (ANT input)	FM 100.1 MHz	L4 (X05-2060-10 A/7)	0V	(a)
2	VCO	(A)/Connect a frequency counter to the junction of R82 and VR6 (X09-1750-10 D/7) via an AC voltmeter.	100.1 MHz 0 dev 60 dB (ANT input)	FM 100.1 MHz	VR6 (X09-1750-10 D/9)	Frequency: 76 kHz $\pm$ 200 Hz	(b)
VCO: Voltage Controlled Oscillator							
3	DISTORTION (STEREO) Except for E type	(C)/(B)	100.1 MHz 1 kHz $\pm$ 68.25 kHz dev Selector: L-R Pilot: $\pm$ 6.75 kHz dev 60 dB (ANT input)	FM 100.1 MHz	T2 (Front end)	Minimum distortion	
3	DISTORTION (STEREO) For E type	(C)/(B)	100.1 MHz 1 kHz $\pm$ 40 kHz dev Selector: L or R Pilot: $\pm$ 6 kHz dev 60 dB (ANT input)	FM 100.1 MHz	T2 (front end)	Minimum distortion	
AM SECTION							
(1)	RF ALIGNMENT (MW)	Connect a DC voltmeter to the junction of R18 and R19 (X05-2060-10 A/7)	—	AM (MW). MANUAL 522 kHz or 530 kHz	L5 (X05-2060-10 A/7)	DC voltage for ground: 1.0V (522 kHz) 1.1V (530 kHz)	(c)
(2)	RF ALIGNMENT (MW)	(D)/(B)	1400 kHz or 1404 kHz 400 Hz, 30% mod	AM (MW) 1400 kHz or 1404 kHz	TC1 (X05-2060-10 A/7)	Maximum amplitude and symmetry of the oscilloscope display	
(3)	IF TRANSFORMER	(D)/(B)	990 kHz 400 Hz, 30% mod	AM (MW) 990 kHz	L10 (X05-2060-10 A/7)	Maximum amplitude and symmetry of the oscilloscope display	
LW SECTION (DC-20XL ONLY)							
(4)	RF ALIGNMENT (LW)	Connect a DC voltmeter to the junction of R18 and R19 (X05-2060-72 A/7)	—	LW, MANUAL 146 kHz	L6 (X05-2060-72 A/7)	DC voltage for ground: 1.2V	
(5)	RF ALIGNMENT (LW)	(D)/(B)	317 kHz 400 Hz, 30% mod	LW 317 kHz	TC2 (X05-2060-72 A/7)	Maximum amplitude and symmetry of the oscilloscope display	

REGLAGES (SECTION TUNER)

Les points de réglage et les réglages de l'entrée et de la sortie sont indiqués sur chaque plaque de circuit imprimée.

N°	ITEM	RACCORDEMENTS DU SYSTEME	REGLAGE DE L'APPAREILLAGE	REGLAGE DU TUNER (AMPLI-TUNER)	POINTS DE L'ALIGNEMENT	ALIGNER POUR	FIG. N°
SECTION MF							
1	DISCRIMINATEUR	(A)/Connecter un voltmètre CC sur R9 (X05-2060-10 A/7)	100,1 MHz 1 kHz $\pm$ 75 kHz dév 60 dB (Entrée ANT)	FM 100,1 MHz	L4 (X05-2060-10 A/7)	0V	(a)
2	OSCILLATEUR CONTROLE PAR LA TENSION	(A)/Connecter un compteur de fréquence à la jonction de R82 et VR6 (X09-1750-10 D/9) par un voltmètre CA.	100,1 MHz 0 dév 60 dB (Entrée ANT)	FM 100,1 MHz	VR6 (X09-1750-10 D/9)	Fréquence: 76 kHz $\pm$ 200 Hz	(b)
3	DISTORSION (STEREO) Excepté E type	(C)/(B)	100,1 MHz 1 kHz $\pm$ 68,25 kHz dév SELECTION: L ou R Signal pilote: $\pm$ 6,75 kHz dév 60 dB (Entrée ANT)	FM 100,1 MHz	T2 (Partie frontale)	Distortion minimale	
3	DISTORTION (STEREO) Pour E type	(C)/(B)	100,1 MHz 1 kHz $\pm$ 40 kHz dév SELECTION: L ou R signal pilote: $\pm$ 6 kHz dév 60 dB (Entrée ANT)	FM 100,1 MHz	T2 (Partie frontale)	Distortion minimale	
SECTION MA							
(1)	ALIGNEMENT H.T. (MW)	Connecter un voltmètre CC à la jonction de R18 et R19 (X05-2060-10 A/7)	—	AM (MW), MANUAL 522 kHz ou 530 kHz	L5 (X05-2060-10 A/7)	Tension continue pour terre: 1,0V (522 kHz) 1,1V (530 kHz)	(c)
(2)	ALIGNEMENT H.T. (MW)	(D)/(B)	1400 kHz ou 1404 kHz 400 Hz, 30% mod	AM (MW) 1400 kHz ou 1404 kHz	TC1 (X05-2060-10 A/7)	Amplitude et symétrie maximale de l'affichage de l'oscilloscope	
(3)	TRANSFORMATEUR F.I.	(D)/(B)	990 kHz 400 Hz, 30% mod	AM (MW) 990 kHz	L10 (X05-2060-10 A/7)	Amplitude et symétrie maximal de l'affichage de l'oscilloscope	
SECTION LW (DC-20XI)							
(4)	ALIGNEMENT H.T. (LW)	Connecter un voltmètre CC à la jonction de R18 et R19 (X05-2060-72 A/7)	—	LW, MANUAL 146 kHz	L6 (X05-2060-72 A/7)	Tension continue pour terre: 1.2V	
(5)	ALIGNEMENT H.T. (LW)	(D)/(B)	317 kHz 400 Hz, 30% mod	LW 317 kHz	TC2 (X05-2060-72 A/7)	Amplitude et symétrie maximale de l'affichage de l'oscilloscope	

ABGLEICH (TUNER-ABTEILUNG)

Die Abgleichpunkte und Eingangs- und Ausgangs- einstellungen sind auf jeder gedruckter Schaltung angegeben.

NR.	GEGENSTAND	SYSTEM-ANSCHLÜSSE	PRÜFEIN-RICTUNG-EINSTELLUNG	TUNER (RECEIVER)-EINSTELLUNG	ABGLEICH-PUNKTE	ABGLEICHEN FÜR	ABB. NR.
UKW-ABTEILUNG							
1	DISKRIMI-NATOR	(A)/Einen Gleichspannungsmesser über R9 anschließen (X05-2060-10 A/7)	100.1 MHz 1 kHz $\pm$ 75 kHz Hub 60 dB (ANT-Eingang)	FM 100.1 MHz	L4 (X05-2060-10 A/7)	0V	(a)
2	SPANNUNGS GEREGLTER OSZILLATOR	(A)/Einen Frequenzmesser zur Verbindung von R82 und VR6 (X09-1750-10 D/9) über einem Wechselspannungsmesser anschließen.	100.1 MHz 0 Hub 60 dB (ANT-Eingang)	FM 100.1 MHz	VR6 (X09-1750-10 D/9)	Frequenz: 76 kHz $\pm$ 200 Hz	(b)
3	KLIRRFAKTOR (STEREO) Ausgenommen E type	(C)/(B)	100.1 MHz 1 kHz $\pm$ 68,25 kHz Hub Wähler: L oder R Pilotton: $\pm$ 6,75 kHz Hub 60 dB (ANT-Eingang)	FM 100.1 MHz	T2 (Frontende)	Minimaler Klirrfaktor	
3	KLIRRFAKTOR (STEREO) Für E type	(C)/(B)	100.1 MHz 1 kHz $\pm$ 40 kHz Hub Wähler: L oder R Pilotton: $\pm$ 6 kHz Hub 60 dB (ANT-Eingang)	FM 100.1 MHz	T2 (Frontende)	Minimaler Klirrfaktor	
MW-ABTEILUNG							
(1)	HF-ABGLEICH (MW)	Einen Gleichspannungsmesser zur Verbindung von R18 und R19 (X05-2060-10 A/7) anschließen.	—	AM(MW). MANUAL 522 kHz oder 530 kHz	L5 (X05-2060-10 A/7)	Gleichspannung für Erde: 1.0V (522 kHz) 1.1V (530 kHz)	(C)
(2)	HF-ABGLEICH (MW)	(D)/(B)	1400 kHz oder 1404 kHz 400 Hz. 30% mod	AM (MW) 1400 kHz ou 1404 kHz	TC1 (X05-2060-10 A/7)	Maximale Amplitude und Symmetries des Oszilloskopbildes.	
(3)	ZF-ÜBERTRAGER	(D)/(B)	990 kHz 400 Hz. 30% mod	AM (MW) 990 kHz	L10 (X05-2060-10 A/7)	Maximale Amplitude und Symmetries des Oszilloskopbildes.	
LW-ABTEILUNG (DC-20XL)							
(4)	HF-ABGLEICH (LW)	Einen Gleichspannungsmesser zur Verbindung von R18 und R19 (X05-2060-72 A/7) anschließen.	—	LW. MANUAL 146 kHz	L6 (X05-2060-72 A/7)	Gleichspannung für Erde: 1.2V	
(5)	HF-ABGLEICH (LW)	(D)/(B)	317 kHz 400 Hz. 30% mod	LW 317 kHz	TC2 (X05-2060-72 A/7)	Maximale Amplitude und Symmetries des Oszilloskopbildes	

ADJUSTMENT (CASSETTE DECK SECTION)

1. Test Instruments, Tools and Jigs

- AC voltmeter
- Audio signal generator: AG
- Oscilloscope
- Frequency counter
- Wow and flutter meter
- Weighting filter
(ASA A characteristic with NAB curve)
- Cassette type torque gage
- Spring balance
- Torque dial
- Head demagnetizer
- Cleaning tape (T93-0014-05)

2. Test Tapes

- a) Test tapes for recording section adjustment

Normal:

Maxell XL1-S (T93-0013-15)

CrO₂:

TDK AC-512 (T93-0019-05)

Metal:

TDK AC-711 (T93-0020-05)

- b) Test tapes for playback section adjustment

Tape speed and wow and flutter:

TEAC MTT-111 (T93-0015-00)

Frequency characteristic and azimuth:

TEAC MTT-216 (T93-0016-00) or

TEAC MTT-216R (T93-0017-00)

3. Notes for Adjustments

- a) Standard level: 0 dBs = 0.775V
- b) When the REC/PLAY head is replaced, its stray magnetism must be completely demagnetized by the head demagnetizer prior to loading the tape.
- c) Unless otherwise designated, adjustment should be carried out with the Dolby NR switch off.

4. Meanings of Technical Words

- a) Standard recording level

The recording level required to obtain the same playback level as a test tape on which a 315 Hz signal has been recorded at a magnetic flux density of 160 nWb/m.

- b) Standard recording condition

The recording condition is which an input signal of 1 kHz, -8.5 dBs is applied to the AUX terminal with the input selector set to AUX and the MIC-MIXING control set to the minimum.

- c) Standard input level

The input level required to obtain the standard recording level. **-8.5 dBs at the AUX terminal.**




- d) Standard output level

Level appearing at the junction of R89 and R91 (L) or the junction of R90 and R92 (R) of PC board X28-1410-10 when a test tape is played on which a 315 Hz signal has been recorded at a magnetic flux density of 160 nWb/m.

The output level is **-4.5 dBs** when MTT-216R 315 Hz (250 nWb/m) is played.

The output level is **-8.5 dBs** when MTT-216 315 Hz (160 nWb/m) is played.

TEST TAPE SPECIFICATIONS

MODEL	TITLE	TIME CONSTANT	DESCRIPTION		APPLICATION
			FREQ/LEVEL	PROGRAM	
MTT-111	FLUTTER	—	3 kHz -10 dB	 30 Min.	Tape Speed Test Wow and Flutter Test
MTT-216R (MTT-116R)	FREQUENCY	3180 µs and 120 µs	40 Hz ~ 10 kHz 0 dB / -10 dB 0 dB = DIN REFERENCE LEVEL		Frequency Response Test
MTT-216 (MTT-116U)	FREQUENCY	3180 µs and 120 µs	31.5 Hz ~ 14 kHz 0 dB / -20 dB 0 dB = DIN REFERENCE LEVEL -4 dB		Frequency Response Test

Output level of standard recorded level of 250 nWb/m is 4 dB higher than that of 160 nWb/m.

ADJUSTMENT (CASSETTE DECK SECTION)

Alignment points and input and output settings are indicated on each printed circuit board.

0 dBs = 0.775V

NO.	ITEM	TEST TAPE	INPUT SETTING	OUTPUT SETTING	CASSETTE TAPE DECK SETTING	ALIGNMENT POINTS		ALIGN FOR
						L	R	
REC/PLAY HEAD								
1	DEMAGNETIZATION AND CLEANING	—	—	—	POWER: OFF Remove the case.	REC/PLAY head, erase head, capstan, pinch roller, drive belt.		Demagnetize the REC/PLAY head with a head demagnetizer. Clean the REC/PLAY head, capstan and pinch roller using a cotton swab slightly damped with alcohol.
2	AZIMUTH OF REC/PLAY HEAD	MTT-216 (MTT-216R) 10 kHz, — 20 dB	—	(a) Connect an AC voltmeter to the junction of R89 and R91 (L) or to the junction of R90 and R92 (R) of X28-1410-10.	Remove the case. TAPE SELECTOR: NORMAL PLAYBACK	REC/PLAY head azimuth adjustment screw (left screw)		Adjust the azimuth adjustment screw so that both channel output levels are maximized, then lock the screw with adhesive.
DC MOTOR								
(i)	TAPE SPEED	MTT-111	—	(b) Connect a frequency counter to the junction of R89 and R91 of X28-1410-10.	PLAYBACK	Trimmer potentiometer in the DC motor (for capstan drive).		Frequency: 3000 Hz
PC BOARD (X28-1410-10)								
(1)	PLAYBACK LEVEL	MTT-216 (MTT-216R) 315 Hz, 0 dB	—	(a) Connect an AC voltmeter to the junction R89 and R91 (L) or to the junction of R90 and R92 (R) of X28-1410-10.	TAPE SELECTOR: NORMAL INPUT SELECTOR: TAPE DOLBY NR: OFF PLAYBACK	VR1	VR2	Output level: — 8.5 dBs (MTT-216) — 4.5 dBs (MTT-216R)
(2)	BIAS TRAP	XL1-S	—	(c) Connect an AC voltmeter to TRAP TP (L) or to TRAP TP (R) of X28-1410-10.	TAPE SELECTOR: NORMAL INPUT SELECTOR: TAPE REC PAUSE	L1	L2	Adjust the cores so that the output levels are minimized with the beat canceller switch set to position (A).
(3)	RECORD LEVEL	XL1-S	(A) INPUT: AUX AG: 1 kHz, — 8.5 dBs Gradually increase the AG output level to — 8.5 dBs. Rapid increase may cause the ALC circuit to operate.	(a) Connect an AC voltmeter to the junction of R89 and R91 (L) or to the junction of R90 and R92 (R) of X28-1410-10.	TAPE SELECTOR: NORMAL INPUT SELECTOR: AUX MIXING VOLUME: SOURCE DOLBY NR: OFF RECORDING → PLAYBACK	VR3	VR4	Output level: — 8.5 dBs Note: Adjusting method If an output level of — 8.5 dBs cannot be obtained, connect an AC voltmeter to the junction between C57 and R85 (C58 and R86). For example, when the playback output level of — 7.3 dBs is obtained, read the reading of the AC voltmeter with this connection during recording. Then, adjust VR3 (VR4) so that the reading of the AC voltmeter reduces by 1.2 dB. Now, the playback output level is set to — 8.5 dBs.
(4)	BIAS CURRENT	XL1-S	(A) INPUT: AUX AG: 1 kHz, — 28.5 dBs 10 kHz, — 28.5 dBs	(a) Connect an AC voltmeter to the junction of R89 and R91 (L) or to the junction of R90 and R92 (R) of X28-1410-10.	TAPE SELECTOR: NORMAL INPUT SELECTOR: AUX MIXING VOLUME: SOURCE DOLBY NR: OFF RECORDING → PLAYBACK	VR5	VR6	Adjust VR5 (VR6) so that the playback output level of 10 kHz is equal to that of 1 kHz.

Repeat alignments (3) and (4) several times.

REGLAGES (SECTION MAGNETOPHONE A CASSETTE)

1. Appareillages de Mesure, Outils et Gabarits

- Voltmètre CA
- Générateur audio fréquences
- Oscilloscope
- Fréquencemètre
- Fluctuomètre
- Filtre de pondération (courbe ASA A avec courbe NAB)
- Cassette de mesure de couple
- Peson
- Torsiomètre
- Démagnétiseur
- Bande de nettoyage (T93-0014-05)

2. Bandes D'essai

- a) Bandes d'essai pour réglage de la section enregistrement
- Normal:
- Maxell XL1-S (T93-0013-15)
- Chrome:
- TDK AC-512 (T93-0019-05)
- Métal:
- TDK AC-711 (T93-0020-05)
- b) Bandes d'essai pour réglage de la section lecture vitesse de défilement et pleurage et scintillement:
- TEAC MTT-111 (T93-0015-00)
- Réponse en fréquence et azimuth:
- TEAC MTT-216 (T93-0016-00) ou
- TEAC MTT-216R (T93-0017-00)




3. Remarques concernant les réglages

- a) Niveau standard: 0 dBs = 0.775V
- b) Lorsque la tête de ENREGISTREMENT/LECTURE est remplacée, son magnétisme parasite doit être complètement éliminé par le démagnétiseur avant de mettre la bande magnétique en place.
- c) Sauf indication contraire, les réglages doivent être effectuées réducteur de bruit Dolby hors service.

4. Significant des Termes Techniques

- a) Niveau d'enregistrement standard
- Niveau d'enregistrement nécessaire pour obtenir le même niveau de lecture qu'une band d'essai sur laquelle est enregistrée un signal de 315 Hz à une densité de flux magnétique de 160 nWb/m.
- b) Conditions d'enregistrement standard
- Conditions d'enregistrement quand un signal d'entrée de 1 kHz, -8,5 dBs est appliqué à la borne AUX le sélecteur d'entrée étant réglé sur AUX et les contrôles MIC-MIXING réglés sur le minimum.
- c) Niveau d'entrée standard
- Le niveau d'entrée requis pour obtenir le niveau d'enregistrement standard. -8,5 dBs à la borne AUX.
- d) Niveau de sortie standard
- Le niveau qui apparait à la jonction de R89 et R91 (L) ou à la jonction de R90 et R92 (R) de la plaque imprimée X28-1410-10 quand on passe une bande d'essai sur laquelle un signal de 315 Hz a été enregistré sous une densité de flux magnétique de 160 nWb/m.
- Le niveau de sortie est de -4,5 dBs pour la lecture de MTT-216R 315 Hz (250 nWb/m).
- Le niveau de sortie est de -8,5 dBs pour la lecture de MTT-216 315 Hz (160 nWb/m).

SPECIFICATIONS DE LA BANDE

MODELE	TITRE	CONSTANTE DE TEMPS	DESCRIPTION		APPLICATION
			FREQ./NIVEAU	PROGRAMME	
MTT-111	FLUTTER	—	3 kHz -10 dB	 30 Min.	Vitesse de défilement Pleurage et scintillement
MTT-216R (MTT-116R)	FREQUENCY	3180 µs et 120 µs	40 Hz ~ 10 kHz 0 dB / -10 dB 0 dB = Niveau de référence DIN		Réponse en fréquence Azimut
MTT-216 (MTT-116U)	FREQUENCY	3180 µs et 120 µs	31.5 Hz ~ 14 kHz 0 dB / -20 dB 0 dB = Niveau de référence DIN -4 dB		Réponse en fréquence Azimut

Le niveau de sortie du niveau enregistré de 250 nWb/m est supérieur de 4 dB à celui de 160 nWb/m.

REGLAGES (SECTION MAGNETOPHONE A CASSETTE)

Les points de réglage et les réglages de l'entrée et de la sortie sont indiqués sur chaque plaque imprimée.

0 dBs = 0.775V

N°	ITEM	BANDE D'ESSAI	REGLAGE DE L'ENTREE	REGLAGE DE LA SORTIE	REGLAGE DU MAGNETOPHONE A CASSETTE	POINTS DE L'ALIGNEMENT		ALIGNER POUR
						G	D	
TETE DE ENREGISTREMENT/LECTURE								
1	DEMAGNETI- SATION ET NETTOYAGE	—	—	—	POWER: OFF Déplacer le caisse.	Tête de ENRE- GISTREMENT/ LECTURE. Tête de ef- facement. Cabestan, Galet-presseur, Courroie d'entraînement		Demagnettiser la tête de ENREGISTREMENT, LECTURE avec un démagnétiseur de tête. Nettoyer la tête de ENREGISTREMENT, LECTURE la tête d'effacement, le cabestan et le galet-presseur avec un coton-tige légère- ment imbibé alcool.
2	AZIMUT DE LA TETE DE ENREGISTRE- MENT/ LECTURE	MTT-216 (MIT-216R) 10 kHz. — 20 dB	—	(a) Connecter un voltmètre CA à la jonction de R89 et R91 (gauche) ou la jonction de R90 et R92 (droite) de X28-1410-10.	Déplacer le caisse. TAPE SELECTOR NORMAL LECTURE	Vis d'azimut (vis de gauche)		Régler la vis d'azimut en sorte que les deux niveaux de sortie de canal soient au maximum, puis bloquer la vis avec l'adhésif.
MOTEUR CC								
(i)	VITESSE DE DEFILEMENT	MTT-111	—	(b) Connecter un compteur de fré- quence à la jonction de R89 et R91 de X28-1410-10	LECTURE	Résistance ajustable du moteur CC (pour entraîne- ment du cabestan)		Fréquence: 3000 Hz
PLAQUE IMPRIMEE (X28-1410-10)								
(1)	NIVEAU DE LECTURE	MTT-216 (MTT-216R) 315 Hz. 0 dB	—	(a) Connecter un voltmètre CA à la jonction de R89 et R91 (gauche) ou la jonction de R90 et R92 (droite) de X28-1410-10.	TAPE SELECTOR: NORMAL INPUT SELECTOR: TAPE DOLBY NR: OFF LECTURE	VR1	VR2	Niveau de sortie: — 8.5 dBs (MTT-216) — 4.5 dBs (MTT-216R)
(2)	REJECTEUR DE POLARI- SATION	XL1-S	—	(c) Connecter un voltmètre CA à TRAP TP (gauche) ou TRAP TP (droite) de X28-1410-10.	TAPE SELECTOR: NORMAL INPUT SELECTOR: TAPE REC PAUSE	L1	L2	Régler les noyaux en sorte que les niveaux de sortie soient au minimum avec le commutateur de battements (BEAT CANCELLER) réglé sur la position (A).
(3)	NIVEAU D' ENREGISTRE- MENT	XL1-S.	(A) Entrée: AUX Générateur de signaux Audio: 1 kHz — 8.5 dBs Elever graduelle- ment le niveau de sortie du générateur de signaux audio jusqu'à — 8.5 dBs. Une aug- mentation rapide pourrant actionner le circuit ALC.	(a) Connecter un voltmètre CA à la jonction de R89 et R91 (gauche) ou la jonction de R90 et R92 (droite) de X28-1410-10	TAPE SELECTOR: NORMAL INPUT SELECTOR: AUX MIXING VOLUME: SOURCE DOLBY NR: OFF ENREGISTRE- MENT→LECTURE	VR3	VR4	Niveau de sortie: — 8.5 dBs Remarque: Méthode de réglage. Si une sortie de — 8.5 dBs ne peut pas être obtenue, connecter un voltmètre CA à la connexion entre C57 et R85 (C58 et R86): Par exemple, quand la sortie de lecture de — 7.3 dBs a été obtenue, relever le niveau de lecture du voltmètre CA avec cette connexion pendant l'enregistrement. Puis régler VR3 (VR4) en sorte que la lecture du voltmètre CA soit réduite de 1.2 dB. Maintenant le niveau de sortie de lecture est réglé sur — 8.5 dBs.
(4)	COURANT DE POLARISA- TION	XL1-S	(A) Entrée: AUX Générateur de signaux audio. 1 kHz. — 28.5 dBs 10 kHz. — 28.5 dBs	(a) Connecter un voltmètre CA à la jonction de R89 et R91 (gauche) ou la jonction de R90 et R92 (droite) de X28-1410-10.	TAPE SELECTOR: NORMAL INPUT SELECTOR: AUX MIXING VOLUME: SOURCE DOLBY NR: OFF ENREGISTRE- MENT→LECTURE	VR5	VR6	Régler VR5 (VR6) en sorte que le niveau de sortie de lecture de 10 kHz égale celui de 1 kHz.

Répéter les alignements (3) et (4) plusieurs fois.

ABGLEICH (KASSETTENGERÄT-ABTEILUNG)

1. Meß- und Prüfgeräte, Werkzeuge und Einspannvorrichtungen

- Wechselspannungsmesser
- NF-Signalgenerator
- Oszilloskop
- Frequenzzähler
- Gleichlauf- Schwankungsmesser
- Ohrkurven-Bewertungsfilter (ASA „A“ mit NAB-Kurve)
- Kassetten-Drehmomentmesser (od. Bandzugmesser)
- Federwaage
- Drehmomentskala
- Tonkopf-Entmagnetisierungs-drossel
- Reinigungsband (T93-0014-05)

2. Bezugsbänder

- a) Bezugsbänder für Abgleich von Aufnahme-Teil
- Normalband:
- Maxell XL1-S (T93-0013-15)
- CrO₂-Band:
- TDK AC-512 (T93-0019-05)
- Reineisenband:
- TDK AC-711 (T93-0020-05)
- b) Bezugsbänder für Abgleich von Ablesungsteil Bandgeschwindigkeit und Gleichlaufschwankungen:
- TEAC MTT-111 (T93-0015-00)
- Frequenzgang und Kopfazimth:
- TEAC MTT-216 (T93-0016-00) oder
- TEAC MTT-216R (T93-0017-00)



3. Hinweise für Abgleich

- a) **Standardpegel:** 0 dBs = 0,775 Volt
- b) Beim Wechseln des AUFNAHME/WIEDERGABE-Kopfes sein Störmagnetismus vollkommen mit dem Tonkopf-Entmagnetisierungs-drossel entmagnetisieren bevor das Band geladen wird.
- c) Wenn nicht anders angegeben, wird der Abgleich mit dem Dolby NR Schalter auf OFF ausgeführt.

4. Bedeutung der Technischen Wörter

- a) **Normalaufnahmepegel**
Der Aufnahmepegel, der erforderlich ist, um den gleichen Wiedergabepegel zu erhalten wie bei einem Bezugsband, mit dem ein 315 Hz-Signal einer Magnetflußdichte von 160 nWb/m aufgenommen wurde.
- b) **Bedingungen für Normalaufnahme**
Die Aufnahmebedingungen bei Anlegen eines Ausgangssignal von 1 kHz, -8,5 dBs an die AUX-Klemme mit den Eingangswahlschalter auf AUX eingestellt und die MIC-MIXING Schaltung aufs Minimum.
- c) **Normaleingangspegel**
Der Eingangspegel erforderlich um den Normalaufnahmepegel -8,5 dBs an der AUX-Klemme zu erhalten.
- d) **Normalausgangspegel**
Der Pegel der an Verbindung von R89 und R91 (L) oder Verbindung von R90 und R92 (R) der gedruckte Schaltplatte X28-1410-10 erscheint wenn ein Bezugsband abgespielt wird auf dem ein Signal von 315 Hz bei einer Magnetflußdichte von 160 nWb/m aufgenommen wurde.
Der Ausgangspegel ist -4,5 dBs, wenn MTT-216R 315 Hz (250 nWb/m) abgespielt wird.
Der Ausgangspegel ist -8,5 dBs, wenn MTT-216 315 Hz (160 nWb/m) abgespielt wird.

TECHNISCHE DATEN DER BEZUGSBÄNDER

TYP	BEZEICHNUNG	ZEIT-KONSTANTE	BESCHREIBUNG		ANWENDUNG
			FREQ/PEGEL	PROGRAM	
MTT-111	Gleichlaufschwankungen (FLUTTER)	—	3 kHz, -10 dB	 30 Min.	Bandlaufgeschwindigkeits-Prüfung Gleichlaufschwankungs-Prüfung
MTT-216R (MTT-116R)	Frequenzgang (FREQUENCY)	3180 µSek. und 120 µSek.	40 Hz ~ 10 kHz 0 dB / -0 dB 0 dB = DIN-Bezugspegel		Prüfung des Frequenzgangs
MTT-216 (MTT-116U)	Frequenzgang (FREQUENCY)	3180 µSek. und 120 µSek.	315 Hz ~ 14 kHz 0 dB / -20 dB 0 dB = DIN-Bezugspegel -4 dB		Prüfung des Frequenzgangs

Der Ausgangspegel des Normalaufnahmepegels von 250 nWb/m ist um 4 dB höher als der von 160 nWb/m.

ABGLEICH (KASSETTENGÄRÄT-ABTEILUNG)

Die Abgleichpunkte und Eingangs- und Ausgangs-einstellungen sind auf jeder gedruckte Schaltplatte angegeben. 0 dBs=0,775V

NR	GEGEN- STAND	BEZUGS BAND	EINGANGS- EINSTELLUNG	AUSGANGS- EINSTELLUNG	KASSETTEN- GERÄT- EINSTELLUNG	ABGLEICH- PUNKTE		ABGLEICHEN FÜR
						L	R	
AUFNAHME/WIEDERGABE -KOPF								
1	ENTMAGNETI- SIERUNG UND REINIGUNG	—	—	—	POWER OFF Den Kasten wegbringen	AUFNAHME/ WIEDERGABE- Kopf, Löschkopf, Tonwelle, Andruckrolle, Antriebsriemen		Entmagnetisierung von dem: AUFNAHME/WIEDERGABE- Kopf mit einem Tonkopf Entmagnetisierungsdrössel AUFNAHME/WIEDERGABE- Kopf, Löschkopf, Tonwelle, Andruckrolle und Antriebs- riemen mit einem leicht mit Alkohol befeuchteten Wattebausch reinigen
2	AUFNAHME/ WIEDERGABE- KOPF- AZIMUTH- EINSTELLUNG	MTT-216 (MTT-216R) 10 kHz. — 20 dB	—	(a) Einen Wechsel- spannungsmesser zur Verbindung von R89 und R91 (L) oder zur Ver- bindung von R90 und R92 (R) von X28-1410-10 anschließen	Den Kasten wegbringen TAPE SELECTOR NORMAL WIEDERGABE	Azimuth- Ein- stellschraube (linke Seite)		Einstellung von Azimuth- Einstellschraube so daß beide Kanal Ausgangspegel maximal sind, dann die Schraube mit Klebstoff festlegen
GLEICHSTROMMOTOR								
(i)	BANDGESCH- WINDIGKEIT	MTT-111	—	(b) Einen Frequenz- messer zur Verbind- ung von R89 und R91 von X28-1410-10 anschließen.	WIEDERGABE	Trimmer potentiometer am Gleich- strommotor (für Tonwellen- antrieb)		Frequenz: 3000 Hz
GEDRUCKTE SCHALTPLATTE (X28-1410-10)								
(1)	WIEDERGABE- PEGEL	MTT-216 (MTT-216R) 315 Hz. 0 dB	—	(a) Einen Wechsel- spannungsmesser zur Verbindung von R89 und R91 (L) oder zur Verbindung von R90 und R92 (R) von X28-1410-10 anschließen	TAPE SELECTOR- NORMAL INPUT SELECTOR: TAPE DOLBY NR: OFF WIEDERGABE	VR1	VR2	Ausgangspegel — 8,5 dBs, (MTT-216) — 4,5 dBs (MTT-216R)
(2)	VORMAGNETI- SIERUNGS- SPERRE	XL1-S	—	(c) Einen Wechsel- spannungsmesser zu TRAP TP (L) oder TRAP TP (R) von X28-1410-10 anschließen	TAPE SELECTOR: NORMAL INPUT SELECTOR: TAPE REC PAUSE	L1	L2	Einstellung von Kerne so daß die Ausgangspegel minimal sind mit dem Schwebungs-Abstellknopf (BEAT CANCELLER) auf (A)
(3)	AUFNAHME- PEGEL	XL1-S	(A) Eingang: AUX NF-Signal- generator 1 kHz, — 8,5dBs Den NF-Signal- generator- Ausgangspegel bis auf — 8,5 dBs allmählich erhöhen. Erhöhung kann Schnelle den Antrieb ALC Strom- Kreis verursa- chen.	(a) Einen Wechsel- spannungsmesser zur Verbindung von R89 und R91 (L) oder zur Verbind- ung von R90 und R92 (R) von X28-1410-10 anschließen.	TAPE SELECTOR: NORMAL INPUT SELECTOR: AUX MIXING VOLUME: SOURCE DOLBY NR: OFF AUFNAHME → WIEDERGABE	VR3	VR4	Ausgangspegel: — 8,5 dBs Bemerkung: Falls ein Ausgangspegel von — 8,5 dBs nicht erhältlich ist, einen Wechselspannungs- messer an die Verbindung zwischen C57 und R85 (C58 und R16) anschließen. Wenn zum Beispiel ein Über- spielausgangspegel von — 7,3 dBs erhalten wurde, den Wechselspannungsmesser mit diesem Anschluß wäh- rend der Aufnahme ablesen. Dann VR3 (VR4) so ein- stellen daß die Ablesung des Wechselspannungsmessers um 1,2 dBs vermindert ist. Jetzt ist der Abspiel- ausgangspegel auf — 8,5 dBs eingestellt.
(4)	VORMAG- NETISIE- RUNGSSTROM	XL1-S	(A) Eingang: AUX NF- Signalgenerator 1 kHz, — 28,5 dBs 10 kHz. — 28,5 dBs	(a) Einen Wechsel- spannungsmesser zur Verbindung von R89 und R91 (L) oder zur Ver- bindung von R90 und R92 (R) von X28-1410-10 anschließen	TAPE SELECTOR: NORMAL INPUT SELECTOR: AUX MIXING VOLUME: SOURCE DOLBY NR: OFF AUFNAHME → WIEDERGABE	VR5	VR6	Abgleich von VR5 (VR6) so daß der Abspiel-Aus- gangspegel von 10 kHz dem von 1 kHz gleich ist.

Abstimmungen (3) und (4) mehrere Male wiederholen.

PC BOARD

TUNER (X-05-2060-10) (A/7) Component Side View


TEST INSTRUMENTS

Oscilloscope	Oscilloscope
AM signal generator	Générateur MA
FM signal generator	Générateur MF
Audio generator	Générateur audio fréquences
AC voltmeter	Voltmètre CA
FM multiplex generator	Générateur multiplex stéréo
Frequency counter	Fréquence
DC voltmeter	Voltmètre CC
Distortion meter	Distorsion
Dummy antenna	Antenne fictive

APPAREILLAGE

MEß-UND PRÜFGERÄTE


Oszilloskop	SCOPE
MW-Signalgenerator	AM-SG
UKW-Signalgenerator	FM-SG
NF-Signalgenerator	AG
Wechselspannungsmesser	
UKW-Multiplexgenerator	FM-MPX
Frequenzzähler	
Gleichspannungsmesser	
Klirrfaktormesser	
Antennennachbildung	





PC BOARD

SYNTH
(X05-2060-10) (B/7)
Component Side View

CONROL SW
(X13-3280-10)
Componet Side View



9/10 KHz SW
(X05-2060-10)(G/7)





to LOGIC
(X05-2060-10)(D/7)

Transistors and ICs

Refer to the schematic diagram for the values of capacitors and resistors.
The PC board drawing is viewed from the side easy to check.


LOGIC
(X05-2060-10) (D/7)
Component Side View




Refer to the schematic diagram for the values of capacitors and resistors. The PC board drawing is viewed from the side easy to check.

PC BOARD


REC AMP (X28-1410-10) (A/4) Component Side View



TAPE SELECTOR (X28-1410-10) (B/4) Component Side View




BEAT CANCEL (X28-1410-10) (C/4) Component Side View




Transistor and ICs
Alignment points

Refer to the schematic diagram for the values of capacitors and resistors.
The PC board drawing is viewed from the side easy to check.




PC BOARD


MAIN AMP
(X09-1752-71) (A/9)
Component Side View




DC-DC CONVERTER
(X28-1410-10) (D/4)
Component Side View




POWER SW
(X09-1750-10) (I/9)
Component Side View



SPEAKER SW
(X09-1750-10) (F/9)
Component Side View



MIC AMP (X09-1750-10) (C/9)
Foil Side View




Transistors and ICs

Refer to the schematic diagram for the values of capacitors and resistors.
The PC board drawing is viewed from the side easy to check.


PC BOARD

AD-12
BATTERY (X00-2180-10)
Component Side View





■ : Transistors and ICs

Refer to the schematic diagram for the values of capacitors and resistors.
The PC board drawing is viewed from the side easy to check.



SPECIFICATIONS


LW TUNER SECTION	
Sensitivity S/N 20 dB	850 μ V/m
S/N Ratio: 1 mV Input	43 dB
Image Rejection Ratio	60 dB



STEREO DECK AMPLI-TUNER

DC-20X

F G H I J K L M N P Q



SPECIFICATIONS


FM TUNER SECTION	
Usable Sensitivity (300Hz)	13.2 dBf (2.5 μV)
50 dB Quieting Sensitivity	17.7 dBf (4.2 μV)
Mono	40 dBf (55 μV)
Stereo	
Signal-to-Noise Ratio at 65 dBf	
Mono	67 dB
Stereo	62 dB
Total Harmonic Distortion at 1,000 Hz	
Mono	0.4%
Stereo	0.5%
Frequency Response	30 Hz to 15 kHz +0.5 dB -1.5 dB
Capture Ratio	1 dB
Image Rejection Ratio	78 dB
IF Response Ratio	90 dB
Alternate Channel Selectivity	55 dB at 400 kHz
Stereo Separation Ratio	36 dB at 1,000 Hz
Antenna Impedance	30 dB at 50 Hz to 10 kHz
FM Frequency Range	300 ohms balanced 87.5 MHz to 108 MHz
AM TUNER SECTION	
Usable Sensitivity	700 μV/m
Signal-to-Noise Ratio	45 dB
Image Rejection	40 dB
Selectivity	35 dB
AM Frequency Range	530 kHz ~ 1620 kHz


Kenwood follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

Kenwood poursuit une politique de progrès constants en ce qui concerne le développement. Pour cette raison, les spécifications sont sujettes à modifications sans préavis.

Kenwood strebt ständige Verbesserungen in der Entwicklung an. Daher bleiben Änderungen der technischen Daten jederzeit vorbehalten.

- DC voltages are measured by a VOM of 20 kΩ/V input impedance
- Les tensions de courant continu sont mesurées par un multimètre d'une impédance d'entrée de 20 kΩ/V
- Die Gleichstrom-Spannungen werden durch ein Vielfachmeßgerät von 20 kΩ/V Eingangs-Impedanz gemessen.





When measuring the signal level of the recording circuit, short-circuit the base of Q36 and GND.

Position	Bias current	Erase current	Test tape
Normal	360μA	60mA	AC-223
CrO2	500μA	80mA	AC-512
Metal	800μA	140mA	AC-711

Measure the DC voltage across R135. (Erase current)
Measure the DC voltage across R1 or R2 (Bias current)

2SC2668

2SD313T-AL (E)
2SD330 (E,F)

2SK105 (H,J)

KB4424A

μPD4035

NE646N
HA1137W

μPD1703C-016

MB74LS42M

μPD651C-23

2SA1127NC PR,S) 2SC1845 (F,E)
2SA733 (A) (Q,P) 2SD592NC (Q,R,S)
2SA992 (F,E) 2SC2378 (Q,P,K)
2SC945 (A) 2SC1685 (R,S)
2SC1384 (Q,R)

2SK55 (E)


2SK61 (Y)

3SK85

μPB553AC

STEREO DECK AMPLI-TUNER

DC-20X



SPECIFICATIONS

TAPE DECK SECTION	
Type	Front Loading Stereo Cassette Deck with Dolby® NR System
Track System	4-Track, 2-Channel Stereo/Mono, Recording/Playback
Recording System	AC Bias System (Bias Frequency 85 kHz)
Erasing System	AC System
Tape Speed	4.76 cm/sec (1-7/8 ips)
Heads	Record and Playback Head x 1 (Permic Hi-B Ferrite)
Motor	Electronically Controlled DC Motor
Fast Winding Time	Approx 105 seconds with C-60 tape
Frequency Response	
Normal Tape	25 Hz to 15000 Hz (30 Hz to 14000 Hz, ±3 dB)
Chrome Tape	25 Hz to 15000 Hz (30 Hz to 14000 Hz, ±3 dB)
Metal Tape	25 Hz to 16000 Hz (30 Hz to 15000 Hz, ±3 dB)
Signal to Noise Ratio	
Dolby NR ON (Over 5 kHz)	60 dB (Normal Tape), 61 dB (Chrome Tape), 61 dB (Metal Tape)
Dolby NR OFF	51 dB (Normal Tape), 52 dB (Chrome Tape), 52 dB (Metal Tape)
Harmonic Distortion	Less than 1% (at 1 kHz, 0 VU w/ht Metal Tape)
Wow and Flutter	0.05% (W R M S)
Built-in Features	Dolby Noise Reduction System, Direct Program Search System by Micro-Computer, Full Auto Shut Off Mechanism in all Modes, Timer Standby Mechanism, Automatic Level Control


* DOLBY and the double-D symbol are trade marks of Dolby Laboratories Licensing Corporation. Noise reduction circuit made under license from Dolby Laboratories Licensing Corporation.


Kenwood follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

Kenwood poursuit une politique de progrès constants en ce qui concerne le développement. Pour cette raison, les spécifications sont sujettes à modifications sans préavis.

Kenwood strebt ständige Verbesserungen in der Entwicklung an. Daher bleiben Änderungen der technischen Daten jederzeit vorbehalten.


- DC voltages are measured by a VOM of 20 kΩ/V input impedance
- Les tensions de courant continu sont mesurées par un multimètre d'une impédance d'entrée de 20 kΩ/V
- Die Gleichstrom-Spannungen werden durch ein Vielfachmeßgerät von 20 kΩ/V Eingangs-Impedanz gemessen.





- 2SC2668
- 2SD313T-AL (E)
- 2SD330 (E.F)
- 2SK105 (H.J)
- KB4424A
- μPD4035
- NE646N
- HA1137W
- μPD1703C-016
- MB74LS42M
- μPD651C-23
- 2SA1127NC (P.R.S)
- 2SA733 (A) (Q.P)
- 2SA992 (F.E)
- 2SC2378 (Q.P.K)
- 2SC945 (A)
- 2SC1685 (R.S)
- 2SC1384 (Q.R)
- 2SC1845 (F.E)
- 2SD592NC (Q.R.S)
- 2SK55 (E)
- 2SK61 (Y)
- 3SK85
- μP...


DC-20X




AUDIO SECTION	
Monitor Power Output	
into 8 ohms at 1,000 Hz, 1% THD	1 7W + 1 7W
Input Sensitivity/Impedance	
PHONO (MM)	2.5 mV/50 kohms
AUX	150 mV/30 kohms
MIC	2 mV/5 kohms
Signal-to-Noise Ratio (A weighted)	
PHONO (MM)	70 dB for 2.5 mV input
AUX	88 dB
MIC	65 dB
Maximum PHONO Input Level	
at 1,000 Hz	55 mV (RMS), THD 0.3%
Frequency Response	
PHONO RIAA Standard Curve	30 Hz to 15 kHz ± 0.2 dB
AUX	20 Hz to 60 kHz ± 0 dB, -3 dB
Tone Control	
BASS	± 10 dB at 100 Hz
TREBLE	± 10 dB at 10 kHz
Loudness Control (VOL. -30 dB)	+8 dB at 100 Hz
Output Level/Impedance	
REC OUT	150 mV/10 kohms
PRE OUT	150 mV/10 kohms

Kenwood strebt ständige Verbesserungen in der Entwicklung an. Daher bleiben Änderungen der technischen Daten jederzeit vorbehalten.

- DC voltages are measured by a VOM of 20 k Ω /V input impedance
- Les tensions de courant continu sont mesurées par un multimètre d'une impédance d'entrée de 20 k Ω /V
- Die Gleichstrom-Spannungen werden durch ein Vielfachmeßgerät von 20 k Ω /V Eingangs-Impedanz gemessen.





SPECIFICATIONS


GENERAL
Power Consumption

Dimensions
(DC-20P + DC-20X)

Weight (Net)


EXPLODED VIEW (1)

Refer to Parts List on page 58.




EXPLODED VIEW (2)

Refer to Parts List on page 58.



EXPLODED VIEW (MECHANISM)

Refer to Parts List on page 63.



PARTS LIST

INSTRUCTION FOR PARTS LIST

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
② ①	18 1A 19 2A 19 2A 19 2A 19 2A	A01-0608-12 A2C-1979-11 A2C-1979-11 A2C-1979-11 A20-1979-11	METALLIC CABINET FRONT PANEL ASSY FRONT PANEL ASSY FRONT PANEL ASSY FRONT PANEL ASSY
⑤	R221 R222 VR1, 2 VR3, 4 VR5, 6	R43-1333-15 R43-1368-15 R12-3301-05 R19-4305-05 R12-2302-05	FL-PROOF RD330 J 2H FL-PROOF RD680 J 2H TRIMMING POT, 20K(B) POTENTIOMETER (OUTPUT) TRIMMING POT, 5K(B)

- ① Exploded view drawing No.
 - ② Position in exploded view
 - ③ Symbol of new parts
 - ④ Area to which parts are shipped. Example: A20-1390-13 is the part No. of FRONT PANEL ASSY for the "K" type products (for U.S.A.). When this column is blank, it means that the same type of parts (same parts No.) are used for the products shipped to all areas.
 - ⑤ Reference No. in schematic diagram.
 - ⑥ Abbreviation of "ceramic capacitor".
All capacitors and resistors are listed using abbreviations.
- * Abbreviations of capacitors (Parts No. with initial letter "C").
- | | |
|---------|---------------------------------|
| ELECTRO | Electrolytic capacitor |
| LL-ELEC | Low leak electrolytic capacitor |
| NP-ELEC | Non-pole electrolytic capacitor |
| MICA | Mica capacitor |
| POLYSTY | Polystyrene capacitor |
| MYLAR | Mylar capacitor |
| CERAMIC | Ceramic capacitor |
| TANTAL | Tantalum capacitor |
| MF | Metallized film capacitor |
| MP | Metallized paper capacitor |
| OIL | Oil capacitor |
- The unit "UF" is used in lieu of "μF".
- * Abbreviations of resistors (Parts No. with initial letters "R").
- | | |
|-------------|---------------------------------------|
| RC | Carbon composition resistor |
| RD | Carbon film resistor |
| FL-PROOF RD | Flame-proof carbon film resistor |
| RW | Wire wound power resistor |
| FL-PROOF RS | Flame-proof metal oxide film resistor |
| RN | Metal film resistor |
| FUSE-RESIST | Resistor with fuse function |
| 2B | Rated wattage 1/8W |
| 2E | Rated wattage 1/4W |
| 2H | Rated wattage 1/2W |
| 3A | Rated wattage 1W |
| 3D | Rated wattage 2W |
| 3F | Rated wattage 3W |
| 3G | Rated wattage 4W |
| 3H | Rated wattage 5W |
- All resistor values are indicated with the unit (Ω) omitted.
- * Abbreviations common to capacitors and resistors.
- | | |
|---|---------------------------------------|
| C | ±0.25pF (Used for capacitors only) |
| D | ±0.5pF (Used for capacitors only) |
| F | ±1% |
| G | ±2% |
| J | ±5% |
| K | ±10% |
| M | ±20% |
| Z | +80% - 20% (Used for capacitors only) |
| P | +100% - 0% (Used for capacitors only) |
- Resistors RD (carbon composition resistors) are not listed in the parts list. For values, refer to the schematic diagram.

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
UNIT	DC-20X	K:USA X:AUSTRIA P:CANADA T:ENGLAND E:AFRICA H:AUDIO CLUB U:PX E:SCANDINAVIA & EUROPE DC20XL E:SCANDINAVIA & EUROPE T:ENGLAND	
1	3C	NO STOCK	SUB PANEL
2	1D	NO STOCK	REAR PANEL
3	3D	NO STOCK	SIDE PLATE (R)
4	2C	NO STOCK	SIDE PLATE (L)
5	1C	NO STOCK	TOP PLATE
6	2A	NO STOCK	MECHANISM ASSY(EJECT)
11	1B	A02-0078-01	PLASTIC CABINET
12	3A	A20-1873-02	FRONT PANEL *KPUMHX
12	3A	A20-1874-02	FRONT PANEL
12	3A	A20-1875-02	FRONT PANEL
12	3A	A20-1876-02	FRONT PANEL
12	3A	A20-1877-02	FRONT PANEL
13	2A	A53-0035-02	CASSETTE HOUSING
14	2A	A53-0036-04	CASSETTE LID
-	-	B46-0055-30	WARRANTY CARD(TK-CANADA)
-	-	B46-0060-00	WARRANTY CARD
-	-	B46-0061-30	WARRANTY CARD
-	-	B46-0062-30	WARRANTY CARD
-	-	B46-0063-13	WARRANTY CARD
-	-	B46-0064-20	WARRANTY CARD
-	-	B46-0078-03	WARRANTY CARD
-	-	B50-3404-00	INSTRUCT MANUAL(E) *KUH
-	-	B50-3405-00	INSTRUCT MANUAL(E,F) *P
-	-	B50-3406-00	INSTRUCT MANUAL(E)
-	-	B50-3407-00	INSTRUCT MANUAL(E)
-	-	B50-3408-00	INSTRUCT MANUAL(4-LANG)
-	-	B50-3409-00	INSTRUCT MANUAL(E,F)
-	-	B50-3411-00	INSTRUCT MANUAL(SP)
-	-	B59-0018-00	SERVICE STATIONS LIST
15	2A	B03-0156-02	DRESSING PLATE
16	3C	B08-0015-02	DISPLAY PANEL
17	3A	B10-0306-03	FRONT GLASS *KPUMHX
17	3A	B10-0307-03	FRONT GLASS
17	3A	B10-0308-03	FRONT GLASS
17	3A	B10-0309-03	FRONT GLASS
18	1A	D15-0186-04	PULLEY ASSY
19	1A	D16-0067-04	BELT
20	1A	D16-0068-04	BELT
21	2A	D40-0236-05	MECHANISM ASSY(CASSETTE)
-	-	E04-0004-05	COAXIAL CONNECTOR
-	-	E23-0015-04	EARTH LUG
22	1D	E20-0229-05	TERMINAL BOARD
23	1A	E30-0505-05	CORD WITH PLUG
24	1B	E30-0687-05	POWER CORD
24	1B	E30-0688-05	POWER CORD
24	1B	E30-0691-05	POWER CORD
24	1B	E30-1328-05	POWER CORD
24	1B	E30-1342-05	POWER CORD
25	2B	G01-0430-04	COIL SPRING(EJECT)
26	2A	G01-0431-04	COIL SPRING
27	3B	G01-0433-04	COIL SPRING
28	3B	G01-0434-04	COIL SPRING
29A	1B	G11-0172-04	CUSHION
29B	1B	G11-0173-04	CUSHION
-	-	H01-3331-04	CARTON BOX *KPUMHX
-	-	H01-3332-04	CARTON BOX
-	-	H01-3333-04	CARTON BOX
-	-	H01-3334-04	CARTON BOX

PARTS LIST

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名/規格	Re- marks 備考
-	H10-1590-03	POLYSTYRENE FIXTURE	*
-	H10-1591-03	POLYSTYRENE FIXTURE	*
-	H12-0088-04	PACKING FIXTURE	*UH [UE]
-	H12-0089-04	PACKING FIXTURE	*
-	H25-0078-04	BAG (235X315)	*
-	H25-0179-04	BAG (530X450)	*
-	H39-0018-05	HANDLE	*
30 1B	J19-0597-04	COVER	*
31 1B	K01-0069-03	HANDLE ASSY	*
32 3C	K23-0355-04	KNOB(VOLUME)	*
33 3A	K27-0630-04	KNOB(SELECTOR)	*
34 3A	K27-0631-04	KNOB(SELECTOR)DC-20X	*
35 1A	K27-0632-04	KNOB(POWER)	*
36 3B	K27-0633-04	KNOB(TAPE,SEL,EJ)	*
37 3B	K27-0634-04	KNOB(TONE)	*
38 3B	K27-0635-04	KNOB(AUTO,MANU)	*
39 3B	K27-0636-04	KNOB(LOUD,ACCU)	*
40 3C	K27-0637-04	KNOB(TIMER)	*
41 3C	K29-0377-14	KNOB(MIC,BALANCE)	*
42 2B	K29-0424-02	KNOB ASSY(CASSETTE)	*
43 3B	K29-0425-02	KNOB ASSY(SYNTH)	*
-	N29-0035-05	PUSH RIVET(3,5X5,5)DC-20XL	*
44 1D	N08-0128-35	GND TERMINAL	*
45 1D	N09-0309-05	SCREW BR-TAP 3X8	*
46 2A	N09-0385-04	SCREW	*
47 1B	N09-0393-05	SCREW(F-TAP,3X8)	*
49 1A	N29-0221-05	PUSH RIVET(3,5X7)	*
50 2A	S46-1008-05	LEAF SWITCH	*
51 2C,3D	T07-0068-05	LOUDSPEAKER(FULL-RANGE)	*
52 1B	T90-0113-05	ROD ANTENNA	*
-	W01-0301-05	HEAD CLEANING BAR	*
53 1A	W01-0104-03	BC-20	*
55 2D,3D	X05-2060-10	TUNER PCB ASSY	* KP
55 2D,3D	X05-2060-71	TUNER PCB ASSY	* X
55 2D,3D	X05-2060-81	TUNER PCB ASSY	UMH [UE]
55 2D,3D	X05-2062-71	TUNER PCB ASSY	TE
55 2D,3D	X05-2062-72	TUNER PCB ASSY	[TE]
56 1C,2C	X09-1750-10	AUDIO AMP PCB ASSY	* KP
56 1C,2C	X09-1750-71	AUDIO AMP PCB ASSY	* X
56 1C,2C	X09-1750-81	AUDIO AMP PCB ASSY	*UMH [UE]
56 1C,2C	X09-1752-71	AUDIO AMP PCB ASSY	TE
56 1C,2C	X09-1752-72	AUDIO AMP PCB ASSY	[TE]
57 2B	X13-3280-10	SWITCH PCB ASSY	*
58 2D	X28-1410-10	REC/PLAY PCB ASSY*KPUMH	UE
58 2D	X28-1412-71	REC/PLAY PCB ASSY	TE [TE]
TUNER K:X05-2060-10 U:X05-2060-81 [E]:X05-2062-72 X:X05-2060-71 E:X05-2062-71			
051 -53	B30-0231-05	LED	*
054 ,55	B30-0312-05	LED	*
056	B30-0231-05	LED	*
057 -63	B30-0241-05	LED	*
064 -70	B30-0312-05	LED	*
C2 -4	C91-0085-05	CERAMIC 0.022UF N	
C5	C24-1710-59	ELECTRO 1UF 50WV	
C6	C52-1739-16	CERAMIC 390PF K	
C7	C24-1710-59	ELECTRO 1UF 50WV	
C8	C91-0085-05	CERAMIC 0.022UF N	
C9	C24-6547-57	ELECTRO 4.7UF 35WV	
C10	C91-0083-05	CERAMIC 0.01UF N	

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名/規格	Re- marks 備考
C11	C24-1747-51	ELECTRO 4.7UF 50WV	
C12 ,13	C91-0083-05	CERAMIC 0.01UF N	
C14	C24-1710-59	ELECTRO 1UF 50WV	
C15	C91-0083-05	CERAMIC 0.01UF N	
C16	C24-1210-69	ELECTRO 10UF 16WV	
C17	C91-0085-05	CERAMIC 0.022UF N	
C18	C55-1747-38	CERAMIC 0.047UF Z	[E]
C19	C47-1751-15	POLYSTY 51PF J	[E]
C20	C70-1715-05	CERAMIC 15PF J	[E]
C21	C47-1718-15	POLYSTY 180PF J	[E]
C22	C70-1768-05	CERAMIC 68PF J	[E]
C23	C91-0085-05	CERAMIC 0.022UF N	[E]
C24	C24-1210-69	ELECTRO 10UF 16WV	[E]
C25	C55-1747-38	CERAMIC 0.047UF Z	[E]
C26	C24-1210-69	ELECTRO 10UF 16WV	
C27	C55-1747-38	CERAMIC 0.047UF Z	[E]
C28	C55-1710-38	CERAMIC 0.01UF Z	[E]
C29	C70-1739-05	CERAMIC 39PF J	[E]
C30	C55-1710-38	CERAMIC 0.01UF Z	[E]
C31	C91-0085-05	CERAMIC 0.022UF N	[E]
C32	C91-0083-05	CERAMIC 0.01UF N	[E]
C33	C24-1210-69	ELECTRO 10UF 16WV	
C34	C91-0085-05	CERAMIC 0.022UF N	
C35	C55-1747-38	CERAMIC 0.047UF Z	
C36	C24-6547-57	ELECTRO 4.7UF 35WV	
C37	C24-1733-59	ELECTRO 3.3UF 50WV	
C38	C55-1747-38	CERAMIC 0.047UF Z	
C39	C24-1733-59	ELECTRO 3.3UF 50WV	
C40	C91-0083-05	CERAMIC 0.01UF N	
C41	C24-1010-79	ELECTRO 100UF 10WV	
C42	C46-1733-36	MYLAR 0.033UF K	
C43	C46-1722-25	MYLAR 0.0022UF J	
C44	C91-0085-05	CERAMIC 0.022UF N	
C45	C53-1710-27	CERAMIC 0.001UF M	
C46	C91-0083-05	CERAMIC 0.01UF N	
C47	C53-1710-27	CERAMIC 0.001UF M	
C48	C91-0085-05	CERAMIC 0.022UF N	
C49	C91-0083-05	CERAMIC 0.01UF N	
C50	C55-1710-38	CERAMIC 0.01UF Z	
C51	C24-1210-69	ELECTRO 10UF 16WV	
C52	C91-0083-05	CERAMIC 0.01UF N	
C56	C24-1210-69	ELECTRO 10UF 16WV	
C57 ,58	C91-0083-05	CERAMIC 0.01UF N	
C59	C55-1710-38	CERAMIC 0.01UF Z	
C60	C24-1210-69	ELECTRO 10UF 16WV	
C61 ,62	C55-1710-38	CERAMIC 0.01UF Z	
C63	C24-0810-79	ELECTRO 100UF 6.3WV	
C64	C91-0083-05	CERAMIC 0.01UF N	
C65 ,66	C71-1733-06	CERAMIC 33PF K	
C67	C24-1210-69	ELECTRO 10UF 16WV	
C68	C24-1047-69	ELECTRO 47UF 10WV	
C69	C25-1710-47	LL-ELEC 0.1UF 50WV	
C70	C25-1722-57	LL-ELEC 2.2UF 50WV	
C71	C46-1710-35	MYLAR 0.01UF J	
C72	C25-1722-57	LL-ELEC 2.2UF 50WV	
C73	C46-1733-35	MYLAR 0.033UF J	
C74	C24-1210-69	ELECTRO 10UF 16WV	
C75	C91-0083-05	CERAMIC 0.01UF N	
C76	C24-1210-69	ELECTRO 10UF 16WV	
C77	C24-1047-69	ELECTRO 47UF 10WV	
C78	C24-1210-69	ELECTRO 10UF 16WV	
C79	C91-0083-05	CERAMIC 0.01UF N	

PARTS LIST

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名/規格	Re- marks 備考
C80	C24-1210-69	ELECTRO 10UF 16WV	
C81	C55-1710-38	CERAMIC 0.01UF Z	
C91	C24-1047-69	ELECTRO 47UF 10WV	
C92 ,93	C24-1410-79	ELECTRO 100UF 25WV	
C94 ,95	C24-6547-57	ELECTRO 4.7UF 35WV	
C96	C24-1222-69	ELECTRO 22UF 16WV	
C97	C24-1047-71	ELECTRO 470UF 10WV	
C98	C52-1710-26	CERAMIC 0.001UF K	
C99	C24-1047-69	ELECTRO 47UF 10WV	
C100	C52-1710-26	CERAMIC 0.001UF K	
C101	C71-1722-05	CERAMIC 22PF J	
C102 ,103	C24-1247-77	ELECTRO 470UF 16WV	
C104	C24-1210-79	ELECTRO 100UF 16WV	
C105	C24-1033-69	LL-ELEC 0.1UF 50WV	
TC1	C05-0302-05	TRIMMER CAPACITOR	
TC2	C05-0303-05	TRIMMER CAPACITOR	E
-	E40-0273-05	PIN CONNECTOR(2P)	
-	E40-0373-05	PIN CONNECTOR(3P)	
-	E40-0473-05	PIN CONNECTOR(4P)	
-	E40-0573-05	PIN CONNECTOR(5P)	
-	E40-0574-05	PIN CONNECTOR(5P)	
-	E40-0673-05	PIN CONNECTOR(6P)	
-	E40-0773-05	PIN CONNECTOR(7P)	
-	E40-0873-05	PIN CONNECTOR(8P)	
-	L79-0147-05	FILTER	* E E
CF1	L72-0128-05	CERAMIC FILTER	K E E
CF1 ,2	L72-0138-05	CERAMIC FILTER	UX E E
CF2	L72-0133-05	CERAMIC FILTER	E E
CF3	L72-0096-05	CERAMIC FILTER	
CF4	L72-0151-05	CERAMIC FILTER	* UX
L1	L19-0026-05	BALUN TRANSFORMER	K
L2	L40-2292-11	INDUCTOR 2.2UH	
L3	L40-1021-12	INDUCTOR 1.0MH	
L4	L30-0372-05	FM-IFT	*
L5	L32-0262-05	MW-OSC COIL	* E
L6	L32-0263-05	LW-OSC COIL	E E
L8	L40-1021-12	INDUCTOR 1.08MH	E
L9	L79-0074-05	FILTER (LPF)	E
L10	L30-0321-05	AM-IFT	
L16	L40-1021-12	INDUCTOR 1.0MH	
L18	L40-1021-12	INDUCTOR 1.0MH	
L20	L40-1021-12	INDUCTOR 1.0MH	
L21 ,22	L40-5611-13	INDUCTOR 560UH	
L23 ,24	L40-1021-12	INDUCTOR 1.0MH	
L25	L40-2211-25	INDUCTOR 220UH	
L26	L32-0264-05	CLOCK OSC COIL	*
X1	L77-0573-05	CRYSTAL RESONATOR 4.5MH	
CP1	R90-0161-05	MULTIPLE COMPONENTS	*
CP2	R90-0176-05	MULTIPLE COMPONENTS	*
CP3	R90-0140-05	MULTIPLE COMPONENTS	*
CP4	R90-0178-05	MULTIPLE COMPONENTS	*
CP5	R90-0132-05	MULTIPLE COMPONENTS	*
CP6	R90-0180-05	MULTIPLE COMPONENTS	*
CP7	R90-0181-05	MULTIPLE COMPONENTS	*
CP8	R90-0179-05	MULTIPLE COMPONENTS	*
CP9	R90-0176-05	MULTIPLE COMPONENTS	*
R33	R92-0210-05	FUSE RESISTOR 33	E E
R38	R92-0210-05	FUSE RESISTOR 33	E E
RL1	S51-2408-05	RELAY	* E
S1 101	S31-2056-05	SLIDE SWITCH(CH SPACE)U	

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名/規格	Re- marks 備考
S2 102	S31-2067-05	SLIDE SWITCH(TIMER)	*
L7 103	T90-0115-05	BAR ANTENNA(MW)	*KU XE
L7 103	T90-0116-05	BAR ANTENNA(MW,LW)	E
104 30	V40-7700-70	7D8A	*KU XE
104 30	V40-7700-80	7G8A	*E
D1	V11-0076-05	1S1555	
D1	V11-0271-05	1S2076	
D2 -5	V11-0076-05	1S1555	E
D2 -5	V11-0271-05	1S2076	E
D6	V11-3178-76	KV1236(22)	
D8 ,9	V11-0076-05	1S1555	
D8 ,9	V11-0271-05	1S2076	
D16 -23	V11-0076-05	1S1555	
D16 -23	V11-0271-05	1S2076	
D24	V11-0076-05	1S1555	UX
D24	V11-0271-05	1S2076	UX
D25 ,26	V11-0076-05	1S1555	E E
D25 ,26	V11-0271-05	1S2076	
D28 -39	V11-0076-05	1S1555	
D28 -39	V11-0271-05	1S2076	
D71 -83	V11-0076-05	1S1555	
D71 -83	V11-0271-05	1S2076	
D83 -87	V11-0271-05	1S2076	
D85 -87	V11-0076-05	1S1555	
D88	V11-4111-90	XZ-041	
D89	V11-0076-05	1S1555	
D89	V11-0271-05	1S2076	
D90	V11-0290-05	V03C	
D91	V11-0076-05	1S1555	
D91	V11-0271-05	1S2076	
D92 ,93	V11-0295-05	W06B	
D94	V11-4111-90	XZ-041	
D95 ,96	V11-0076-05	1S1555	E
D95 ,96	V11-0271-05	1S2076	E
D97	V11-0076-05	1S1555	
D97	V11-0271-05	1S2076	
D98	V11-0051-05	1N60	
D99 -100	V11-0219-05	V06B	
D101	V11-0295-05	W06B	
IC1	V30-0192-05	HA1137W-05	
IC2	V30-0519-10	LA1245	
IC3	V30-0626-10	UPB553AC	
IC4	V30-0609-10	UPD1703C-016	
IC5	V30-0614-10	MB74LS42M	
IC6	V30-0652-10	UPD4035C	
IC7 ,8	V30-1029-16	UPC78L05	
IC9	V30-0653-10	UPD651C-23	
IC10	V30-0355-10	DN6838	
Q2	V03-0945-51	2SC945(A)(Q,P)	E E
Q2	V03-1685-20	2SC1685(R,S)	E E
Q3	V09-0127-40	2SK105(H,J)	
Q6 -15	V03-0945-51	2SC945(A)(Q,P)	
Q6 -15	V03-1685-20	2SC1685(R,S)	
Q16	V03-0945-51	2SC945(A)(Q,P)	
Q16	V03-1685-20	2SC1685(R,S)	E E
Q17	V03-0945-51	2SC945(A)(Q,P)	
Q17	V03-1685-20	2SC1685(R,S)	
Q18	V03-0945-51	2SC945(A)(Q,P)	UX
Q18	V03-1685-20	2SC1685(R,S)	UX
Q19	V03-0945-51	2SC945(A)(Q,P)	E E
Q19	V03-1685-20	2SC1685(R,S)	

PARTS LIST

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
Q20 -24 Q20 -24 Q25 -28 Q25 -28 Q29	V01-0733-40 V01-1127-30 V03-0945-51 V03-1685-20 V01-0733-40	2SA733(A)(Q,P) 2SA1127NC(R,S) 2SC945(A)(Q,P) 2SC1685(R,S) 2SA733(A)(Q,P)	
Q29 Q30 -33 Q30 -33 Q41 -46 Q41 -46	V01-1127-30 V03-0945-51 V03-1685-20 V03-0945-51 V03-1685-20	2SA1127NC(R,S) 2SC945(A)(Q,P) 2SC1685(R,S) 2SC945(A)(Q,P) 2SC1685(R,S)	
Q47 Q47 Q48 -62 Q48 -62 Q63 ,64	V01-0733-40 V01-1127-30 V03-0945-51 V03-1685-20 V04-0592-30	2SA733(A)(Q,P) 2SA1127NC(R,S) 2SC945(A)(Q,P) 2SC1685(R,S) 2SD592NC(Q,R,S)	
Q65 -67 Q65 -67 Q68 Q69 Q69	V03-0945-51 V03-1685-20 V04-0592-30 V03-0945-51 V03-1685-20	2SC945(A)(Q,P) 2SC1685(R,S) 2SD592NC(Q,R,S) 2SC945(A)(Q,P) 2SC1685(R,S)	
W02-0031-05 FM FRONT END			
AUDIO K:X09-1750-10 U:X09-1750-81 E:X09-1752-72 X:X09-1750-71 E:X09-1752-71			
D10 ,11	B30-0312-05	LED	*
C1 ,2 C3 ,4 C5 ,6 C7 ,8 C9 ,10	C24-1210-69 C52-1747-16 C52-2710-26 C24-1010-79 C46-1722-25	ELECTRO 10UF 16WV CERAMIC 470PF K CERAMIC 0.001UF K ELECTRO 100UF 10WV MYLAR 0.0022UF J	
C11 ,12 C13 ,14 C15 ,16 C17 ,18 C19 ,20	C46-1782-25 C24-1710-59 C24-1047-69 C24-1710-59 C52-1747-16	MYLAR 0.0082UF J ELECTRO 1UF 50WV ELECTRO 47UF 10WV ELECTRO 1UF 50WV CERAMIC 470PF K	
C21 ,22 C23 ,24 C25 ,26 C27 ,28 C29 ,30	C52-2710-26 C24-1210-69 C71-1710-02 C24-1210-69 C24-1047-69	CERAMIC 0.001UF K ELECTRO 10UF 16WV CERAMIC 10PF D ELECTRO 10UF 16WV ELECTRO 47UF 10WV	
C31 ,32 C33 ,34 C37 ,38 C39 ,40 C41 ,42	C46-1727-36 C24-1210-69 C24-1747-57 C46-1710-35 C46-1710-45	MYLAR 0.027UF K ELECTRO 10UF 16WV ELECTRO 4.7UF 50WV MYLAR 0.01UF J MYLAR 0.1UF J	
C43 ,44 C45 ,46 C47 ,48 C49 ,50 C51 ,52	C46-1722-25 C46-1727-36 C24-1747-49 C71-1722-15 C24-1010-79	MYLAR 0.0022UF J MYLAR 0.027UF K ELECTRO 0.47UF 50WV CERAMIC 220PF J ELECTRO 100UF 10WV	
C53 ,54 C56 ,57 C58 C59 -61 C62 -64	C24-1210-87 C46-1710-45 C24-1210-87 C24-1010-79 C24-1247-69	ELECTRO 1000UF 16WV MYLAR 0.1UF J ELECTRO 1000UF 16WV ELECTRO 100UF 10WV ELECTRO 47UF 16WV	
C65 C66 C67 C68 C69 ,70	C24-1722-57 C24-1722-57 C24-1010-79 C47-1747-15 C25-1710-57	ELECTRO 2.2UF 50WV ELECTRO 2.2UF 50WV ELECTRO 100UF 10WV POLYSTY 470PF J LL-ELEC 1UF 50WV	EE
C71 C72 C74	C25-1722-47 C46-1747-35 C24-1010-79	LL-ELEC 0.22UF 50WV MYLAR 0.047UF J ELECTRO 100UF 10WV	

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
C75 ,76 C75 ,76 C77 ,78 C79 ,80 C81 ,82	C46-1715-35 C46-1722-35 C46-1733-25 C71-1739-16 C46-1715-26	MYLAR 0.015UF J MYLAR 0.022UF J MYLAR 0.0033UF J CERAMIC 390PF J MYLAR 0.0015UF K	XUE K
C83 -86 C87 C88 C89 ,90 C91 ,92	C24-1710-59 C24-1210-79 C24-6547-57 C24-1210-69 C24-1710-59	ELECTRO 1UF 50WV ELECTRO 100UF 16WV ELECTRO 4.7UF 35WV ELECTRO 10UF 16WV ELECTRO 1UF 50WV	
C93 ,94 C102 C103 ,104 C110 ,90 C115	C24-1747-49 C24-1010-79 C46-1782-25 C24-1210-69 C46-1710-45	ELECTRO 0.47UF 50WV ELECTRO 100UF 10WV MYLAR 0.0082UF J ELECTRO 10UF 16WV MYLAR 0.1UF J	
C116 C120	C24-1033-71 C24-1210-69	ELECTRO 330UF 10WV ELECTRO 10UF 16WV	
- - - - -	E40-0273-05 E40-0373-05 E40-0573-05 E40-0673-05 E40-0773-05	PIN CONNECTOR(2P) PIN CONNECTOR(3P) PIN CONNECTOR(5P) PIN CONNECTOR(6P) PIN CONNECTOR(7P)	
201 3C 202 3C 203 1D	E11-0090-05 E11-0091-05 E13-0434-05	PHONE JACK (3P) PHONE JACK (2P) PHONO JACK (4P)	* * *
L1 L2	L40-1021-11 L79-0125-05	INDUCTOR 1.0MH FILTER BPF	EE
VR1 204 VR2 205 VR3 206 VR4 ,5 207 VR6	R06-5077-05 R01-5036-05 R10-5005-05 R29-4001-05 R12-3057-05	POTENTIOMETER(MIC MIX) POTENTIOMETER(BALANCE) POTENTIOMETER(VOLUME) POTENTIOMETER(TONE) TRIMMING POT 10K(VCO)	
S1 208 S2 209 S3 210 S3 210 S4 211	S40-2133-05 S42-2054-05 S42-5027-05 S42-6011-05 S31-2056-05	PUSH SWITCH(POWER) PUSH SWITCH(2KEY) LOU, AC PUSH SWITCH(5KEY) *KU PUSH SWITCH(6KEY) SLIDE SWITCH(INT-SPKR)	* * * EX *E
S5 212	S31-2056-05	SLIDE SWITCH(EMPHASIS)	*U
D2 D3 D3 D7 D7	V11-4175-36 V11-0076-05 V11-0271-05 V11-0076-05 V11-0271-05	WZ-096 1S1555 1S2076 1S1555 1S2076	
D8 D12 D13 ,14 D13 ,14 IC1 ,2	V11-4163-46 V11-4103-60 V11-0076-05 V11-0271-05 V30-0353-10	XZ-080 XZ-051 1S1555 1S2076 AN6551	
IC3 IC4 IC5 Q1 ,2 Q1 ,2	V30-0645-10 V30-0646-10 V30-0516-10 V03-0945-51 V03-1685-20	HA1374A KB4424A MB84066B 2SC945(A)(Q,P) 2SC1685(R,S)	
Q3 ,4 Q3 ,4 Q5 ,6 Q7 Q8	V03-1845-60 V03-2378-20 V04-0592-30 V04-0313-50 V03-0945-51	2SC1845(1)(E,F) 2SC2378(Q,P,K) 2SD592NC(Q,R,S) 2SD313T-AL(E) 2SC945(A)(Q,P)	EE EE
Q8 Q9	V03-1685-20 V03-0945-51	2SC1685(R,S) 2SC945(A)(Q,P)	EE EE

PARTS LIST

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名/規格	Re- marks 備考
Q9	V03-1685-20	2SC1685(R,S)	
Q10 -13	V03-0945-51	2SC945(A)(Q,P)	
Q10 -13	V03-1685-20	2SC1685(R,S)	
Q14	V01-0733-40	2SA733(A)(Q,P)	
Q14	V01-1127-30	2SA1127NC(R,S)	
Q15 ,16	V03-0945-51	2SC945(A)(Q,P)	
Q15 ,16	V03-1685-20	2SC1685(R,S)	
Q17	V01-0733-40	2SA733(A)(Q,P)	
Q17	V01-1127-30	2SA1127NC(R,S)	
Q18 -21	V03-0945-51	2SC945(A)(Q,P)	
Q18 -21	V03-1685-20	2SC1685(R,S)	
Q24	V03-0945-51	2SC945(A)(Q,P)	
Q24	V03-1685-20	2SC1685(R,S)	
SWITCH (X13-3280-10)			
D1 -5	B30-0258-05	LED	
-	E40-0673-05	PIN CONNECTOR(6P)	
-	E40-0773-05	PIN CONNECTOR(7P)	
-	E40-1073-05	PIN CONNECTOR(10P)	
S1 -14	S40-1040-05	PUSH SWITCH	*
S15 302	S40-2111-05	PUSH SWITCH(AUTO/MAN)	*
REC/PLAY K:X28-1410-10, E:X28-1412-71			
C1 ,2	C52-1747-16	CERAMIC 470PF K	
C3 ,4	C25-1447-57	LL-ELEC 4.7UF 25WV	
C5 ,6	C52-1710-26	CERAMIC 0.001UF K	
C7 ,8	C24-1010-79	ELECTRO 100UF 10WV	
C9 ,10	C46-1733-35	MYLAR 0.033UF J	
C11 ,12	C24-1210-69	ELECTRO 10UF 16WV	
C13 ,14	C46-1712-35	MYLAR 0.012UF J	
C15 -18	C24-1710-59	ELECTRO 1UF 50WV	
C19 -26	C24-1210-69	ELECTRO 10UF 16WV	
C27 ,28	C24-1710-49	ELECTRO 0.1UF 50WV	
C29 ,30	C24-1733-49	ELECTRO 0.33UF 50WV	
C31 ,32	C24-1210-79	ELECTRO 100UF 16WV	
C33 ,34	C24-1022-79	ELECTRO 220UF 10WV	
C35 ,36	C24-1210-69	ELECTRO 10UF 16WV	
C37 ,38	C46-1756-25	MYLAR 0.0056UF J	
C39 ,40	C46-1747-25	MYLAR 0.0047UF J	
C41 ,42	C46-1727-35	MYLAR 0.027UF J	
C43 ,44	C46-1747-35	MYLAR 0.047UF J	
C45 ,46	C52-1768-16	CERAMIC 680PF K	
C47 ,48	C24-1210-69	ELECTRO 10UF 16WV	
C49 ,50	C24-1710-59	ELECTRO 1UF 50WV	
C51 -54	C24-1210-69	ELECTRO 10UF 16WV	
C55 ,56	C24-1747-49	ELECTRO 0.47UF 50WV	
C57 ,58	C24-1210-69	ELECTRO 10UF 16WV	
C59 ,60	C46-1710-35	MYLAR 0.01UF J	
C61 ,62	C46-1710-25	MYLAR 0.001UF J	
C63 ,64	C71-1733-16	CERAMIC 330PF K	
C65 ,66	C71-1722-15	CERAMIC 220PF J	
C67	C91-0345-05	FIXED CAPACITOR	
C68	C46-1733-25	MYLAR 0.0033UF J	
C69	C46-1722-25	MYLAR 0.0022UF J	
C70	C46-1747-25	MYLAR 0.0047UF J	
C71	C24-1710-59	ELECTRO 1UF 50WV	
C72	C24-1210-69	ELECTRO 10UF 16WV	
C73	C24-1010-79	ELECTRO 100UF 10WV	
C74	C24-1210-79	ELECTRO 100UF 16WV	
C75 ,76	C24-1033-79	ELECTRO 330UF 10WV	
C76	C24-1010-79	ELECTRO 100UF 10WV	
C77	C24-1710-59	ELECTRO 1UF 50WV	
C78	C24-1247-69	ELECTRO 47UF 16WV	


Ref. No. 参照番号	Parts No. 部品番号	Description 部品名/規格	Re- marks 備考
C79	C24-1210-79	ELECTRO 100UF 16WV	
C80	C24-1710-59	ELECTRO 1UF 50WV	
C81	C52-1747-16	CERAMIC 470PF K	
C82 ,83	C24-1733-49	ELECTRO 0.33UF 50WV	
C84	C24-1710-49	ELECTRO 0.1UF 50WV	
C85	C24-1047-69	ELECTRO 47UF 10WV	
C86	C24-1710-49	ELECTRO 0.1UF 50WV	
C87	C24-1710-59	ELECTRO 1UF 50WV	
C89	C49-2015-25	POLYSTYRENE CAPACITOR	
C90	C49-2033-25	MYLAR 0.0033UF J	
C91 ,92	C46-1712-35	MYLAR 0.012UF J	
C93 ,94	C46-1727-35	MYLAR 0.027UF J	
C95 ,96	C46-1739-35	MYLAR 0.039UF J	
C97 ,98	C46-1733-35	MYLAR 0.033UF J	
C99	C46-1710-35	MYLAR 0.01UF J	
C100	C71-1710-15	CERAMIC 100PF J	
C101,102	C24-1210-79	ELECTRO 100UF 16WV	
C103	C55-1710-38	CERAMIC 0.01UF Z	
C104	C24-1222-79	ELECTRO 220UF 16WV	
C105	C24-1210-69	ELECTRO 10UF 16WV	
C106,107	C55-1710-38	CERAMIC 0.01UF Z	
C108	C24-6510-77	ELECTRO 100UF 35WV	
C109	C24-1410-79	ELECTRO 100UF 25WV	
C110,111	C24-1447-69	ELECTRO 47UF 25WV	
C112,113	C24-1447-69	ELECTRO 47UF 25WV	
C114	C24-1047-69	ELECTRO 47UF 10WV	
C115	C24-1410-79	ELECTRO 100UF 25WV	
C116,117	C24-1447-69	ELECTRO 47UF 25WV	
-	E40-0373-05	PIN CONNECTOR(3P)	
-	E40-0673-05	PIN CONNECTOR(6P)	
-	E40-0773-05	PIN CONNECTOR(7P)	
L1 ,2	L39-0304-05	TRAP COIL 10MH	*
L3 ,4	L79-0144-05	LC FILTER	
L5 ,6	L40-8225-28	INDUCTOR 8.2MH	*
L7	L32-0260-05	OSCILLATING COIL	
L8	L40-1511-25	INDUCTOR 150UH	
L9	L19-0030-05	TRANSFORMER	*
L10 ,11	L40-5611-12	INDUCTOR 560UH	
L12 -14	L40-1021-12	INDUCTOR 1.0MH	
L16	L40-1021-12	INDUCTOR 1.0MH	
L18	L40-1021-12	INDUCTOR 1.0MH	
R55 ,56	R43-1233-05	FL-PROOF RD33 J 2E	
R131	R43-1212-05	FL-PROOF RD12 J 2E	
R132,133	R43-1210-05	FL-PROOF RD10 J 2E	
R146	R43-1213-15	FL-PROOF RD130 J 2E	
VR1 -4	R12-4302-05	TRIMMING POT 50K	
VR5 ,6	R12-5302-05	TRIMMING POT 100K	
S1 401	S31-2059-05	SLIDE SWITCH(BEAT CANCEL)	*
S2 402	S42-4017-05	PUSH SWITCH(4KEY)TAPE	*
D1 ,2	V11-0051-05	1N60	
D3 -15	V11-0076-05	1S1555	
D3 -15	V11-0271-05	1S2076	
D16	V11-4175-16	WZ-052	
D17	V11-4167-06	XZ-090	
IC1	V30-0651-10	UPC1032H	*
IC2	V30-0353-10	AN6551	
IC3 ,4	V30-0648-10	NE646N	*
Q1 -4	V03-1845-10	2SC1845(F,E)	
Q5 -10	V03-0945-51	2SC945(A)(Q,P)	
Q5 -10	V03-1685-20	2SC1685(R,S)	

PARTS LIST

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
Q11 ,12 Q13 -21 Q13 -21 Q22 Q22	V03-1845-10 V03-0945-51 V03-1685-20 V01-0733-40 V01-1127-30	2SC1845(F,E) 2SC945(A)(Q,P) 2SC1685(R,S) 2SA733(A)(Q,P) 2SA1127NC(R,S)	
Q23 ,24 Q23 ,24 Q25 Q26 Q26	V03-0945-51 V03-1685-20 V01-0992-10 V01-0733-40 V01-1127-30	2SC945(A)(Q,P) 2SC1685(R,S) 2SA992(F,E) 2SA733(A)(Q,P) 2SA1127NC(R,S)	
Q27 Q27 Q28 Q28 Q29 -31	V03-0945-51 V03-1685-20 V01-0733-40 V01-1127-30 V03-0945-51	2SC945(A)(Q,P) 2SC1685(R,S) 2SA733(A)(Q,P) 2SA1127NC(R,S) 2SC945(A)(Q,P)	
Q29 -31 Q32 Q33 -36 Q33 -36 Q37	V03-1685-20 V03-1845-10 V03-0945-51 V03-1685-20 V04-0592-30	2SC1685(R,S) 2SC1845(F,E) 2SC945(A)(Q,P) 2SC1685(R,S) 2SD592NC(Q,R,S)	
Q38 ,39 Q40 ,41	V03-0373-05 V04-0592-30	2SC1384(Q,R) 2SD592NC(Q,R,S)	
AD-12			
501 3B 502 3B	NO STOCK NO STOCK	METALLIC CABINET MAIN CHASSIS	
503 3B	E03-0047-05	AC INLET	
504 3B 504 3B 504 3B 504 3B	L01-2461-05 L01-2462-05 L01-2465-05 L01-2466-05	POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER	* KP *T *U *E
-	S31-2053-05	SLIDE SWITCH(POWER SEL)	UE
505 3B 505 3B 505 3B 505 3B	X00-2180-10 X00-2180-81 X00-2181-01 X00-2182-71	POWER SUPPLY PCB ASSY POWER SUPPLY PCB ASSY POWER SUPPLY PCB ASSY POWER SUPPLY PCB ASSY	*K *U *P *E
POWER SUPPLY K:X00-2180-10 P:X00-2181-01 U:X00-2180-81 E:X00-2182-71			
C1 C1 C2 C3 ,4 C5	C91-0023-05 C91-0079-05 C55-1710-38 C90-0562-05 C24-1410-79	CERAMIC 0.01UF AC250V CERAMIC 0.01UF AC125V CERAMIC 0.01UF Z ELECTRO 2200UF 25WV ELECTRO 100UF 25WV	U KPE * K
C6 C7 C8 C9	C24-1010-79 C24-1210-79 C55-1710-38 C55-1710-38	ELECTRO 100UF 25WV ELECTRO 100UF 25WV CERAMIC 0.01UF Z CERAMIC 0.01UF Z	K E
- - -	F05-2521-05 F05-2525-05 F06-5014-05	FUSE 250V 2.5A FUSE 250V T2.5A FUSE 250V 0.5A	U E KP
- -	J13-0041-05 J13-0054-05	FUSE CLIP FUSE CLIP	K UP E
D1 D2 Q1 ,2 Q3 ,4 Q5	V11-2400-20 V11-4109-90 V04-0330-20 V03-0945-90 V03-0945-90	W02 EZ-056 2SD330(E,F) 2SC945(A) 2SC945(A)	K
FM FRONT END (W02-0031-05)			
D1 -4 Q1 Q2	V11-2103-50 V09-0150-10 V03-2668-16	1SV55 3SK85 2SC2668	

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
Q3 Q4	V09-0121-10 V09-0124-20	2SK55(E) 2SK61(Y)	
MECHANISM ASSY (D40-0237-05)			
701 3F 702 3E 703 2E 704 3E 705 3E	NO STOCK NO STOCK NO STOCK NO STOCK NO STOCK	CHASSIS HEAD BASE SUB CHASSIS BASE STOPPER PLATE STOPPER(A)SPRING	
706 3E 707 3F 708 2F 709 2F 710 9F	NO STOCK NO STOCK NO STOCK NO STOCK NO STOCK	STOPPER(B) BRAKE PLATE SPRING PLATE BRAKE RELEASE LEVER PULLEY	
711 2E,2F 712 3F 713 3F 714 2F 715 3F	NO STOCK NO STOCK NO STOCK NO STOCK NO STOCK	CAP PLAY LEVER(1) PLAY LEVER(2) PLAY LEVER(3) LEVER ASSY	
716 1E 717 2E 718 2E 719 2E 720 2F	NO STOCK NO STOCK NO STOCK NO STOCK NO STOCK	CUSHION FF/REW LINK SOLENOID SPRING(A) SOLENOID SPRING(B) STOPPER(A)	
721 2F 722 2F 723 1F,2F 724 1E 725 1B	NO STOCK NO STOCK NO STOCK NO STOCK NO STOCK	PLATE SPRING STOPPER SPRING(B) CAM GEAR FF LEVER REW LEVER	
726 1F 727 1F 728 1F 729 1F 730 3E	NO STOCK NO STOCK NO STOCK NO STOCK NO STOCK	LEVER HOLDER CAM ASSY COLLAR FF/REW LEVER ASSY ANTI-ERASE LEVER	
741 3F 742 3E 743 2F 744 3F 745 2F	D01-0040-08 D03-0206-08 D13-0073-08 D14-0070-08 D15-0189-08	FLYWHEEL REEL DISK ASSY FF/REW GEAR ASSY PINCH ROLLER PULLEY	* * * * *
746 3F 747 2F 748 2F 749 3E 750 3E	D16-0069-08 D16-0070-08 D19-0059-08 D90-0022-08 D90-0023-08	MAIN BELT REEL BELT PLAY CLUTCH ASSY STEAL BALL STEAL BALL	* * * * *
751 3E 752 3E 753 3E 754 3F 755 2F	G01-0395-08 G01-0454-08 G01-0455-08 G01-0456-08 G01-0457-08	AZIMUTH SPRING PINCH ROLLER SPRING BACK TENTION SPRING BRAKE SPRING PLAY CLUTCH SPRING	* * * * *
756 1E,1F 757 1E	G01-0458-08 G01-0459-08	LEVER SPRING PLAY LEVER SPRING	*
758 3E 759 1E	N09-0391-08 N09-0392-08	HEAD SCREW F LOCK SCREW	* *
760 1F 761 3E	S46-1014-08 S50-1023-08	SW OPERATIONAL PLATE SENSITIVE SWITCH	* *
762 3E 763 3E 764 1E 765 2E 766 2E	T32-0302-08 T34-0302-08 T42-0012-08 T94-0021-08 T94-0022-08	ERASE HEAD REC/PLAY HEAD DC MOTOR SOLENOID(BLUE) SOLENOID(RED)	* * * * *

DC-20P



ADJUSTMENT IDLE CURRENT

In this model, fixed resistor R45 (R46) and R47 (R48) are used, instead of a trimming potentiometer, to adjust the idle current to 20 ~ 120 mA. Some units employ R45 (R46) or R47 (R48) and some units employ both R45 (R46) and R47 (R48).

When replacing the power or drive transistors, always check that the idle current is 20 ~ 120 mA.

REGLAGES

COURANT DE POLARISATION

Ce modèle est équipé des résistors non réglables R45 (R46) et R47 (R48), au lieu d'un potentiomètre trimmer, pour régler le courant de polarisation sur 20 ~ 120 mA. Certains dispositifs sont équipés de R45 (R46) ou R47 (R48) et d'autres sont équipés à la fois de R45 (R46) et R47 (R48).

Lors du remplacement du transistor d'alimentation ou du transistor d'entraînement, toujours s'assurer que le courant de polarisation est de 20 ~ 120 mA.

ABGLEICH

LEERLAUFSTROM

Dieses Modell ist mit Festwiderstand R45 (R46) und R47 (R48) ausgestattet, an Stelle von einem Trimpotentiometer, um den Leerlaufstrom auf 20 ~ 120 mA einzustellen. Einige Modelle sind mit R45 (R46) und R47 (R48) zusammen.

Beim Wechseln des Krafttransistors oder des Antriebstransistors, vergewissern Sie sich immer daß der Leerlaufstrom 20 ~ 120 mA ist.

< CHECKING PROCEDURE >

- (1) Set the volume control to a minimum.
- (2) Connect a DC voltmeter between the emitter of Q15 (Q16) and the collector of Q17 (Q18).
- (3) Confirm that the DC voltmeter reading is 8.8 ~ 52.8 mV.
- (4) If the DC voltmeter reading is not as specified, change the resistance of R45 (R46) and/or R47 (R48) to obtain the specified value.

< METHODE DE VERIFICATION >

- (1) Régler le contrôle du volume sur le minimum.
- (2) Connecter un voltmètre CC entre l'émetteur de Q15 (Q16) et le collecteur de Q17 (Q18).
- (3) S'assurer que la lecture du voltmètre CC indique 8.8 ~ 52.8 mV.
- (4) Si la lecture du voltmètre CC n'est pas comme spécifiée, changer la résistance de R45 (R46) et/ou R47 (R48) pour obtenir la valeur spécifiée.


< PRÜFUNGSANG >

- (1) Den Lautstärke knopf aufs Minimum stellen.
- (2) Einen Gleichspannungsmesser zwischen den Emitter von Q15 (Q16) und den kollektor von Q17 (Q18).
- (3) Sich vergewissern, daß der Gleichspannungsmesser 8.8 ~ 52.8 mV.
- (4) Falls die Anzeige des Gleichspannungsmesser nicht wie angegeben ist, dem Widerstand von R45 (R46) und/oder R47 (R48) ändern um den angegebenen Wert zu erhalten.


* Refer to Parts List.

EXPLODED VIEW

Refer to Parts List on page 68.



DC-20P



DC-20P

Transistors


Refer to the schematic diagram for the values of capacitors and resistors.
The PC board drawing is viewed from the side easy to check.

When replacing transistor Q17, cut its leads shortly as possible to prevent them from touching with AC outlet.


2SA733
2SA1127
2SC945
2SC1845
2SC1685

2SA850
2SC1735

2SD716



cut its leads shortly as possible to prevent them from touching with AC outlet.



SPECIFICATIONS

POWER AMPLIFIER SECTION

Power Output
20 watts* per channel minimum RMS, both channels driven at 8 ohms from 40 Hz to 20,000 Hz with no more than 0.1% total harmonic distortion.

Total Harmonic Distortion (40 Hz to 20 kHz from POWER-IN)

rated power into 8 ohms 0.1%

1/2 watt power into 8 ohms 0.07%

Intermodulation Distortion (80 Hz : 7 kHz = 4 : 1 SMPTE)

rated power into 8 ohms 0.02%

Damping Factor 35 at 1 kHz, 8 ohms

Input Sensitivity/Impedance

POWER-IN 150 mV/50 kohms

Signal-to-Noise Ratio (A weighted)

POWER-IN 100 dB for 150 mV input

Frequency Response 10 Hz to 100 kHz ± 0 dB, -3 dB

GENERAL

Power Consumption 1A (UL and CSA)

120W (IEC)

120W (8 ohms at rated power)

AC Outlet Switched 1

Dimensions (DC-20P + DC-20X) W: 290 mm (11-13/32")

H: 309 mm (12-5/32")

D: 150 mm (5-29/32")

Weight (Net) 3.5 kg (7.7 lb)

* Measured pursuant to Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifier in U.S.A.

Kenwood follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

Kenwood poursuit une politique de progrès constants en ce qui concerne le développement. Pour cette raison, les spécifications sont sujettes à modifications sans préavis.

Kenwood strebt ständige Verbesserungen in der Entwicklung an. Daher bleiben Änderungen der technischen Daten Jederzeit vorbehalten.

• DC voltages are measured by a VOM of 20 k Ω /V input impedance.

• Les tensions de courant continu sont mesurées par un multimètre d'une impédance d'entrée de 20 k Ω /V.

• Die Gleichstrom-Spannungen werden durch ein Vielfachmeßgerät von 20 k Ω /V Eingangs-Impedanz gemessen.

PARTS LIST

INSTRUCTION FOR PARTS LIST

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名/規格	Re- marks 備考
② ① 1 3A 2 2A 3 2A 4 1A, 1B 5 1A	- - - - A20-1666-08	MAIN CHASSIS ASS'Y (30L) FRONT CHASSIS FLUOR DISPLAY HOLDER FRONT PANEL FRONT PANEL ASS'Y	# ③ ④ ⑤ ⑥
⑤ PS3 RS1 RL1	S42-3201-08 S01-1204-08 S51-2204-08	PUSH SW. (SELECTOR) 111 ROTARY SW. (FUNC.) 105 RELAY FIG. 104	* ① *H

① Exploded view drawing No.

② Position in exploded view.

③ Symbol of new parts

④ Area to which parts are shipped. Example: A20-1666-08 is the part No. of FRONT PANEL ASS'Y for the "K" type products (for U.S.A.). When this column is blank, it means that the same type of parts (same parts No.) are used for the products shipped to all areas.

⑤ Reference No. in schematic diagram.

⑥ (30L) and # are KT30L

Abbreviations

* Abbreviations of capacitors (Parts No. with initial letter "C")

ELECTRO	Electrolytic capacitor
LL-ELEC	Low leak electrolytic capacitor
NP-ELEC	Non-pole electrolytic capacitor
MICA	Mica capacitor
POLYSTY	Polystyrene capacitor
MYLAR	Mylar capacitor
CERAMIC	Ceramic capacitor
TANTAL	Tantalum capacitor
MF	Metallized film capacitor
MP	Metallized paper capacitor
OIL	Oil capacitor

The unit "UF" is used in lieu of "μF"

* Abbreviations of resistors (Parts No. with initial letters "R")

RC	Carbon composition resistor
RD	Carbon film resistor
FL-PROOF RD	Flame-proof carbon film resistor
RW	Wire wound power resistor
FL-PROOF RS	Flame-proof metal oxide film resistor
RN	Metal film resistor
FUSE-RESIST	Resistor with fuse function
2B	Rated wattage 1/8W
2E	Rated wattage 1/4W
2H	Rated wattage 1/2W
3A	Rated wattage 1W
3D	Rated wattage 2W
3F	Rated wattage 3W
3G	Rated wattage 4W
3H	Rated wattage 5W

All resistor values are indicated with the unit (Ω) omitted.

* Abbreviations common to capacitors and resistors.

C	± 0.25pF (Used for capacitors only)
D	± 0.5pF (Used for capacitors only)
F	± 1%
G	± 2%
J	± 5%
K	± 10%
M	± 20%
Z	+ 80%, - 20% (Used for capacitors only)
P	+ 100%, - 0% (Used for capacitors only)

Resistors RD (carbon composition resistors) are not listed in the parts list. For values, refer to the schematic diagram.


Ref. No. 参照番号	Parts No. 部品番号	Description 部品名/規格	Re- marks 備考
K:USA X:AUSTRARIA P:CANADA T:ENGLAND UE:AAFES H:AUDIO CLUB U:PX E:SCANDINAVIA & EUROPE M:OTHER AREAS			
DC-20P(UNIT)			
1 3R	NO STOCK	MAIN CHASSIS	
2 2B	NO STOCK	HEAT SINK	
11 1R	A01-0414-03	METALLIC CABINET	* UE
12 3A	A20-1856-03	FRONT PANEL *KPUMXH	*T *E
12 3A	A20-1857-03	FRONT PANEL	
12 3A	A20-1885-03	FRONT PANEL	
13 3A	A22-0302-02	SUB PANEL	
-	B46-0655-30	WARRANTY CARD	
-	B46-0660-00	WARRANTY CARD	T
-	P46-0661-30	WARRANTY CARD	K
-	B46-0662-30	WARRANTY CARD	UE UH
-	B46-0663-13	WARRANTY CARD	UE UH
-	B46-0664-20	WARRANTY CARD	X
-	B46-0078-03	WARRANTY CARD	E
-	B50-3398-00	INSTRUCT MANUAL(E) *PUMXH	UE MX
-	B50-3399-00	INSTRUCT MANUAL(F) *P	*M
-	B50-3400-00	INSTRUCT MANUAL(SP)	
-	B50-3401-00	INSTRUCT MANUAL(E)	*T
-	B50-3402-00	INSTRUCT MANUAL(4-LANG)	*E
-	B50-3441-00	INSTRUCT MANUAL(E)	*K
-	B59-0018-00	SERVICE STATIONS LIST UH	UE
14 2A	P30-0301-05	LED	*
C1 2A	C91-0023-05	CERAMIC 0.01UF AC250V	UM HX
C1 2A	C91-0023-05	CERAMIC 0.01UF AC250V	UE
C1 2A	C91-0023-05	CERAMIC 0.01UF AC250V	UE
C1 2A	C91-0079-05	CERAMIC 0.01UF AC125V	KP
C1 2A	C91-0079-05	CERAMIC 0.01UF AC125V	TC
15 3R	E03-0018-05	AC OUTLET KUMXH	UE
15 3B	E03-0042-05	AC OUTLET	P
16 3F	E20-0448-05	TERMINAL BOARD	*
17 3B	E30-0181-05	POWER CORD	KP
17 3B	E30-0459-05	POWER CORD	E
17 3B	E30-0545-05	POWER CORD UMH	UE
17 3B	E30-0587-15	POWER CORD	T
17 3B	E30-0649-05	POWER CORD	X
-	H01-3335-04	CARTON BOX *KPUMXE	UE
-	H01-3336-04	CARTON BOX	*T
-	H10-1592-03	POLYSTYRENE FIXTURE	*
-	H10-1593-03	POLYSTYRENE FIXTURE	*
-	H25-0078-04	BAG (235X315)	
-	H25-0182-14	BAG	
-	H39-0019-05	HANDLE	
18 3A, 3B	J02-0109-05	FOOT	
19 3R	J42-0083-05	POWER CORD BUSHING KPUM	TE
19 3R	J42-0083-05	POWER CORD BUSHING H	UE
19 3D	J42-0085-05	POWER CORD BUSHING	X
20 2A, 2B	K27-0632-04	KNOB (POWER, SP)	
21 2P	L01-2451-05	POWER TRANSFORMER	*K
21 2D	L01-2452-05	POWER TRANSFORMER	*T
21 2R	L01-2455-05	POWER TRANSFORMER *UMXH	UE
21 2B	L01-2456-05	POWER TRANSFORMER	*E
21 2E	L01-2457-05	POWER TRANSFORMER	*P
22 1A, 1B	N09-0373-05	SCREW M3X6(RI-TAP)SLV	
S1 2A	S40-1034-05	PUSH SWITCH (POWER) UMXEH	UE
S1 2A	S40-1035-05	PUSH SWITCH (POWER)	KP
S1 2A	S40-1037-05	PUSH SWITCH (POWER)	TE
S2	S31-2053-05	SLIDE SWITCH (POWER SEL)	UM
S2	S31-2053-05	SLIDE SWITCH (POWER SEL)	XE

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
S2	S31-2053-05	SLIDE SWITCH (POWER SEL)	UE
S2	S31-2053-05	SLIDE SWITCH (POWER SEL)	H
23 2R	V04-0716-00	2S0716	
24 2A, 3D	X07-1930-10	POWER AMP PCB ASSY	*K
24 2A, 3B	X07-1930-81	POWER AMP PCB ASSY *UMXH	UE
24 2A, 3B	X07-1931-01	POWER AMP PCB ASSY	*P
24 2A, 3H	X07-1932-71	POWER AMP PCB ASSY *	TE
25 2B	X13-3250-01	AUXILIARY PCB ASSY *UMXH	TE
25 2E	X13-3250-01	AUXILIARY PCB ASSY	UE
25 2R	X13-3250-10	AUXILIARY PCB ASSY *	KP
POWER AMP(X07-1930-10) K:0-10 U:0-81 P:1-01 E:2-71			
-	217-1016-05	PLASTIC TUBE	
C3 ,4	C25-1710-57	LL-ELEC 1UF 50WV	
C5 ,6	C24-6522-71	ELECTRO 220UF 35WV	
C7 ,8	C52-1733-16	CERAMIC 330PF K	
C11 ,12	C52-1710-26	CERAMIC 0.001UF K	
C17 ,18	C24-1047-69	ELECTRO 47UF 10WV	
C19 ,20	C71-1703-01	CERAMIC 3PF C	
C21 ,22	C71-1709-02	CERAMIC 9PF D	
C23 ,24	C71-1706-02	CERAMIC 6PF D	
C25 ,26	C24-1210-69	ELECTRO 10UF 16WV	
C27 -30	C71-1722-15	CERAMIC 220PF J	
C31 ,32	C46-1710-45	MYLAR 0.1UF J	
C33 ,34	C90-0558-05	ELECTRO 3300UF 35WV	
C35 ,36	C54-2710-39	CERAMIC 0.01UF P	
C37	C91-0023-05	CERAMIC 0.01UF AC250V	U
C37	C91-0079-05	CERAMIC 0.01UF AC125V	KFE
-	E23-0077-05	TERMINAL	
101 2B	E13-0215-05	PHONO JACK	*
F1 ,2	F05-4022-05	FUSE 250V 4A	U
F1 ,2	F05-4025-05	FUSE 250V 14A	E
F1	F06-2027-05	FUSE 250V 2A	KP
-	J13-0041-05	FUSE HOLDER	K
-	J13-0054-05	FUSE HOLDER	UP
R19 ,20	R42-1256-25	FL-PROOF RD5.6K J 2E	
R23 ,24	R42-1220-15	FL-PROOF RD200 J 2E	
R29 ,30	R42-1247-05	FL-PROOF RD47 J 2E	
R31 ,32	R42-1233-15	FL-PROOF RD330 J 2E	
R33 ,34	R42-1222-05	FL-PROOF RD22 J 2E	
R35 ,36	R42-1210-15	FL-PROOF RD100 J 2E	
R37 -40	R92-0166-05	METAL-PLATE 0.22 K 30	
R49 ,50	R47-5510-05	FL-PROOF RS10 J 30	
D1 -6	V11-0076-05	1S1555	
D1 -6	V11-0271-05	1S2076	
D7 ,8	V11-5100-80	STV-2H(W)	
D9 -12	V11-1301-40	S2V20*1	
D13 ,14	V11-0076-05	1S1555	
D13 ,14	V11-0271-05	1S2076	
Q1 -4	V03-1845-10	2SC1845(F,E)	
Q5 -8	V01-0733-40	2SA733(A)(Q,P)	
Q5 -8	V01-1127-30	2SA1127NC(R,S)	
Q9 ,10	V03-0945-51	2SC945(A)(Q,P)	
Q9 ,10	V03-1685-20	2SC1685(R,S)	
Q11 ,12	V03-0452-05	2SC1735	
Q13 ,14	V01-0173-05	2SA850	
AUXILIARY(X13-3250-10)			
C1	C24-6510-77	ELECTRO 100UF 35WV	
C2	C24-6547-61	ELECTRO 47UF 35WV	

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
C3	C24-1733-59	ELECTRO 3.3UF 50WV	
C4	C25-1733-67	LL-ELEC 33UF 50WV	
R7	R40-8368-16	RC 680 K 2H	
S1	S42-2052-05	PUSH SWITCH FIG201	*
D1 ,2	V11-0076-05	1S1555	
D1 ,2	V11-0271-05	1S2076	
D3	V11-0295-05	W068	
D4 ,5	V11-0076-05	1S1555	
D4 ,5	V11-0271-05	1S2076	
D6	V11-0273-05	1S2076A	
D7	V11-0076-05	1S1555	
D7	V11-0271-05	1S2076	
D8	V11-0295-05	W068	
Q1	V01-0733-40	2SA733(A)(Q,P)	
Q1	V01-1127-30	2SA1127NC(R,S)	
Q2	V03-0945-51	2SC945(A)(Q,P)	
Q2	V03-1685-20	2SC1685(R,S)	
Q3	V01-0733-40	2SA733(A)(Q,P)	
Q3	V01-1127-30	2SA1127NC(R,S)	
Q4	V03-0945-51	2SC945(A)(Q,P)	
Q4	V03-1685-20	2SC1685(R,S)	


EXTERNAL VIEW

DC-20S




Removal of Grille ass'y

The grille ass'y is bonded to the enclosure.
When removing the grille ass'y, warm up the adhesives by a hair drier so that the adhesives will become soft.
Then the grille ass'y can be removed.



SCHEMATIC DIAGRAM



PARTS LIST/SPECIFICATIONS

PARTS LIST


Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
K:USA X:AUSTRIA P:CANADA T:ENGLAND UE:AAFES H:AUDIO CLUB U:PX E:SCANDINAVIA & EUROPE M:OTHER AREAS			
UNIT			
-	B06-0170-03	GRILLE ASSY	*
-	B06-0171-03	GRILLE ASSY KMXUPEHUE	*
-	B42-0368-04	EP MARK	U
-	B46-0055-30	WARRANTY CARD	P
-	B46-0060-00	WARRANTY CARD	T
-	B46-0061-30	WARRANTY CARD	K
-	B46-0062-30	WARRANTY CARD UH	UE
-	B46-0063-13	WARRANTY CARD	U
-	B46-0064-20	WARRANTY CARD	X
-	B46-0076-03	WARRANTY CARD	E
-	B50-3786-00	INSTRUCT MANUAL(6-LANG)	*K
-	B50-3786-00	INSTRUCT MANUAL(6-LANG)	Mx
-	B50-3786-00	INSTRUCT MANUAL(6-LANG)	UP
-	B50-3786-00	INSTRUCT MANUAL(6-LANG)	E
-	B50-3786-00	INSTRUCT MANUAL(6-LANG)	UE
-	B50-3788-00	INSTRUCT MANUAL(ENG)	*T
-	C23-1733-56	ELECTRO 3.3UF 50WV	
-	E29-0625-05	TERMINAL BOARD	*
-	E30-1016-05	SPEAKER CORD	
-	H01-3962-03	CARTON BOX KMXUPEHUE	*
-	H01-3963-03	CARTON BOX	*T
-	H10-2139-03	POLYSTYRENE FIXTURE	*
-	H25-0078-04	BAG (235X315)	
-	H39-0126-05	PACKING PARTS	
-	L38-0135-05	COIL 0.5MH	
-	N99-0716-05	SCREW NUT SET	*
-	T10-0147-05	WOOFER	*
-	T16-0058-05	TWEETER	*
-	T96-0291-00	PASSIVE RADIATOR	*

SPECIFICATIONS

System.....	2-Way, 2-Speaker, 1-Passive Cone System
Enclosure.....	Passive Cone Type
Mounted Speakers	
Woofer.....	100 mm (3-15/16") Cone Type
Tweeter.....	25 mm (1") Soft Dome Type
Maximum Input Power.....	30 Watts
Rated Input Power.....	20 Watts
Frequency Response.....	70 Hz to 20,000 Hz
Crossover Frequency.....	3,000 Hz
Impedance.....	8 ohms
Dimensions.....	W: 128 mm (5-1/32") H: 309 mm (12-5/32") D: 129 mm (5-3/32")
Weight.....	5 kg (11 lbs.)

(Kenwood follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.)

PACKING



	Carton box
T	H01-3963-03
Other than T	H01-3962-03

A product of

TRIO-KENWOOD CORPORATION

Shionogi Shibuya Building, 17-5, 2-chome Shibuya, Shibuya-ku, Tokyo 150 Japan

KENWOOD ELECTRONICS, INC.

1315 E Watsoncenter Rd. Carson, California 90745, U.S.A.

75 Seaview Drive, Secaucus, New Jersey 07094, U.S.A.

1098 North Tower Lane, Bensenville, Illinois 60106, U.S.A.

TRIO-KENWOOD CANADA INC.

1070 Jayson Court Mississauga, Ontario Canada L4W 2V5

TRIO-KENWOOD ELECTRONICS, N.V.

Leuvensesteenweg 504, B-1930 Zaventem, Belgium

TRIO-KENWOOD ELECTRONICS, GmbH

Rudolf-Braas-Str. 20, 6056 Heusenstamm, West Germany

TRIO-KENWOOD FRANCE S.A.

5, Boulevard Ney, 75018 Paris, France

TRIO-KENWOOD SVENSKA AB

Kemistvagen 10A, 183-21 Taby, Sweden

TRIO-KENWOOD AG

Unterboesch 6331 Huenenberg/ZUG Switzerland

TRIO-KENWOOD (AUSTRALIA) PTY. LTD.

30 Whiting St., Artarmon, N.S.W. 2064, Australia

KENWOOD & LEE ELECTRONICS, LTD.

Wang Kee Building, 5th Floor, 34-37, Connaught Road Central, Hong Kong