

Operations in Order	SIGNAL GENERATOR		RECEIVER		
	Output Connections to Receiver	Dial Setting	Dial Setting	Control Settings	Adjust Compen- sators in Order
1	High side to No. 3 terminal loop panel	455 K. C.	580 K. C.	Yol. Max. Range Switch "S. W." Positions	15A, 15B 38A, 43A
2	Use loop on generator	1500 K.C.	1500 K. C.	Vol. Max. Range Switch Broadcast	27, 7A
3	Use loop on generator	580 K. C.	580 K. C.	Vol. Max. Range Switch Broadcast	25
4	Use loop on generator	Perform operation No. 2 again			
5	Use loop on generator	12 M. C.	12 M, C,	Range Switch "SW-I"	27B, 8A
6	Use loop on generator	18 M. C.	18 M. C.	Range Switch "SW-2"	27A, 8

ELECTRIC PUSH-BUTTON TUNING: The automatic tuning mechanism of each model is identical and consists of eight (8) electric tuning push-buttons, seven (7) of the push-buttons are used for selecting broadcast stations, and one as the power control (On-Off switch).

When aligning the R.F. padders a loop is made from a few turns of wire and connected to the signal generator output terminals; the loop is then placed two or three feet from the loop in the cabinet. Do not remove the receiving loop from the cabinet. It is necessary when adjusting the padders, that the receiver be left in the cabinet.

After connecting the aligning indicator, adjust the compensators in the order shown in the tabulation below. Locations of the compensators are shown on the schematic diagram. If the output meter pointer goes off scale when adjusting the compensators, reduce the strength of the signal from the generator.

NOTE A—DIAL CALIBRATION: In order to adjust the receiver correctly, the dial must be aligned to track properly with the tuning condenser. To adjust the dial, proceed as follows: With the tuning condenser closed (maximum capacity), set the dial pointer on the extreme left index line at the low frequency end of the broadcast scale. The arrangement of the drive cable in this position is shown in the schematic.

Model 41-256, Code 121
PHILCO

