

WEBCOR Model 1954-1, using Amplifier 14X280-1

NEEDLE AND CARTRIDGE REPLACEMENT

If distortion or harshness of treble tones is encountered, it is probable that the cartridge and needle assembly (Webcor Part No. 21P586) requires replacement. To replace the cartridge and needle assembly, grasp the cartridge with thumb and forefinger and gently pull cartridge free.

CONNECTION JACKS

Stereo Output Jack: The Stereo Output Jack on the rear of the Holiday Coronet Cabinet makes it possible to connect a second sound system (amplifier and speakers) for Stereafonic reproduction. Webcor Model 4905 Companion Stereafonic Sound System is designed for use with the Holiday Coronet. When using the 4905 Sound System, connection to the Holiday Coronet is made with Stereo Connecting Cord No. 2933.

