



## TRANSFORMER SY3GT SY3

BASS

VOLUME

SPEARER LEADS

0

V2A 12AUT 3 1.2 MA.
V2B 12AUT 8 1.6 MA.
V3 6C45 7 2.13 MA.
V4 6AQ5 2 24.1 MA.
V5 6AQ5 2 24.1 MA.
V6 5Y3GT 5 54.3 MA.

## CRITICAL LEAD DRESS

- 1. Dress all capacitors except C3, and C12 against
- chassis.

  2. Dress R29 at feast % inch away from chassis and transformer.
- 3. Dress all heater leads close to chassis.
- 4. Keep leads on R1, R2, R30, and C1 as short as possible.